

[Manuals.plus](#) /

› [COGO](#) /

› COGO Pirate Ship Building Set Model 3118 Instruction Manual

COGO 3118

COGO Pirate Ship Building Set - Model 3118 Instruction Manual

Brand: COGO | Model: 3118

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and care of your COGO Pirate Ship Building Set, Model 3118. This creative construction toy is designed for children aged 6 years and older, offering an engaging pirate adventure experience with 167 pieces.



Image 1.1: The COGO Pirate Ship Building Set (Model 3118) fully assembled.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Always supervise children during play, especially with small components.
- The building set is made from non-toxic ABS plastic, ensuring safety for children.
- Keep all packaging materials away from children to prevent suffocation.
- Do not put pieces in mouth.

3. WHAT'S IN THE BOX

Your COGO Pirate Ship Building Set package should contain the following items:

- 167 Pieces of Plastic Bricks (for the pirate ship and accessories)
- 1 Color Instruction Manual



Packing Included:

- 1. 167 Pieces Plastic Bricks**
- 2. A Color Manual**

Image 3.1: Packaging contents, including 167 building pieces and the instruction manual.

If any pieces are missing, please contact customer support.

4. SETUP AND ASSEMBLY

Follow the step-by-step instructions provided in the included color manual to assemble your pirate ship. Assembly is required for this product.

1. Unpack all components and verify that all 167 pieces are present using the parts list in the manual.
2. Begin assembly by following the numbered steps in the color instruction manual.
3. Ensure all bricks are firmly connected to create a stable structure.
4. Pay close attention to the orientation of specialized pieces, such as the cannons, mast, and rudder.



Image 4.1: Children engaged in the assembly process of the building set.

5. OPERATING THE PIRATE SHIP

Once assembled, your COGO Pirate Ship is ready for imaginative play. The set includes features designed to enhance the play experience:

- **Adjustable Cannons:** The cannons on the ship can be adjusted to different angles, allowing for dynamic play scenarios.
- **Rotating Rudder:** The ship features a rotating rudder for steering the vessel in imaginative adventures.
- **Movable Mast:** The mast can be positioned to simulate sailing conditions.
- **Pirate Figures:** The set includes 3 pirate figures and guard weapons to populate your ship and create various role-playing scenarios.



Image 5.1: Detailed view of the ship's adjustable features.



Image 5.2: A child enjoying the assembled pirate ship.

6. MAINTENANCE

To ensure the longevity and cleanliness of your COGO Pirate Ship Building Set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the plastic bricks with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic.
- **Storage:** Store the assembled ship or disassembled pieces in a clean, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect all pieces for any signs of wear or damage. Replace any broken or severely worn pieces to maintain safety and play quality.

7. TROUBLESHOOTING

If you encounter any issues during assembly or play, consider the following common solutions:

Problem	Possible Cause	Solution
Pieces do not fit together properly.	Incorrect orientation or incompatible pieces.	Refer to the instruction manual to ensure correct piece selection and orientation. Apply gentle, even pressure.
Assembled structure is unstable.	Pieces not fully connected or steps missed.	Review previous assembly steps to ensure all connections are secure. Press pieces firmly together.
Missing pieces.	Packaging error or pieces misplaced.	Carefully check all packaging materials. If still missing, contact COGO customer support.

8. SPECIFICATIONS

- **Model Number:** 3118
- **Number of Pieces:** 167
- **Material:** ABS Plastic
- **Recommended Age:** 6 years and up
- **Assembled Dimensions (approx.):** 7.9 inches (L) x 5.1 inches (W) x 8.7 inches (H) (20.0 cm x 13.0 cm x 22.0 cm)
- **Product Weight:** 340 g (0.75 lbs)
- **Batteries Required:** No
- **Educational Value:** Creative thinking, practical ability, logical thinking, imagination.




Image 8.1: Approximate dimensions of the assembled pirate ship.

9. WARRANTY AND SUPPORT

COGO is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any potential claims.

For customer support, missing parts, or any inquiries regarding your COGO Pirate Ship Building Set, please contact the retailer where the product was purchased or visit the official COGO website for contact information.

We value your feedback and are here to assist you.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question