

Bloomingville A97306650

Bloomingville Metal Bread Bin with Bamboo Lid (Model A97306650) Instruction Manual

Model: A97306650 | Brand: Bloomingville

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Bloomingville Metal Bread Bin with Bamboo Lid. Designed to store bread and baked goods, this product combines functionality with a classic aesthetic. Please read these instructions carefully before first use to ensure optimal performance and longevity of your bread bin.

2. SAFETY INFORMATION

- Keep the bread bin on a stable, flat surface to prevent tipping.
- Do not place the bread bin near heat sources such as ovens, stovetops, or direct sunlight, as this may affect the stored contents and the product materials.
- The metal components may have edges; handle with care during cleaning and placement.
- Keep out of reach of children to prevent accidental injury or misuse.

3. PRODUCT OVERVIEW

The Bloomingville Metal Bread Bin features a durable metal body and a natural bamboo lid. Its design is intended to provide a suitable environment for storing various types of bread and baked goods, helping to maintain their freshness.



Front view of the Bloomingville Metal Bread Bin with its bamboo lid securely in place.

Key Features:

- **Material:** Metal bin, Bamboo lid
- **Dimensions:** 11.75 inches (L) x 5.25 inches (W) x 7 inches (H)
- **Color:** Gray (as per product variant)
- **Design:** Classic, enameled finish with "bread" inscription

4. SETUP

1. **Unpack:** Carefully remove all packaging materials from the bread bin and its lid.
2. **Inspect:** Check the product for any signs of damage during transit. If any damage is found, do not use the product and contact customer support.
3. **Initial Cleaning:** Before first use, wash the metal bin and bamboo lid by hand with mild soap and warm water. Rinse thoroughly and dry completely. Refer to the "Maintenance and Care" section for detailed cleaning instructions.
4. **Placement:** Place the bread bin on a clean, dry, and stable countertop or pantry shelf. Ensure it is away from direct heat, moisture, and strong odors.

5. OPERATING INSTRUCTIONS

1. **Opening the Bin:** Gently lift the bamboo lid from the metal bin. The lid is designed to rest on top of the bin, not to create an airtight seal.
2. **Storing Bread:** Place your bread, rolls, pastries, or other baked goods inside the clean, dry bin. For best results, it is recommended to keep bread in its original packaging or a breathable bag before placing it in the bin.
3. **Closing the Bin:** Carefully place the bamboo lid back onto the metal bin, ensuring it sits evenly to cover the opening.



The bread bin with its bamboo lid removed, ready for bread storage.

The bamboo lid can also be used as a cutting surface for bread. Simply remove the lid, flip it over, and use the flat side for slicing. Ensure the surface is clean before use.



Detailed view of the bamboo lid, highlighting its natural grain and texture.

6. MAINTENANCE AND CARE

- **Cleaning the Bin:** Hand wash the metal bin with mild dish soap and warm water. Use a soft cloth or sponge. Avoid abrasive cleaners or scouring pads that could scratch the finish. Rinse thoroughly and dry immediately to prevent water spots or rust.
- **Cleaning the Lid:** Hand wash the bamboo lid with mild soap and warm water. Do not soak the bamboo lid, as this can cause warping or cracking. Dry immediately with a clean cloth. For prolonged life, occasionally treat the bamboo with food-grade mineral oil.
- **Dishwasher Safety:** This product is **NOT** dishwasher safe. High heat and harsh detergents can damage both the metal finish and the bamboo lid.
- **Microwave Safety:** This product is **NOT** microwave safe.
- **Storage:** Store the bread bin in a cool, dry place when not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bread not staying fresh.	Lid not properly seated; high humidity; bread not in original packaging.	Ensure the lid is fully and evenly placed on the bin. Store the bread bin in a cool, dry area. Keep bread in its original packaging or a breathable bag inside the bin.
Lid appears warped or does not fit correctly.	Exposure to excessive moisture or heat; physical damage.	Avoid soaking the bamboo lid in water and keep it away from high heat. If warping is minor, allow it to dry completely in a flat position. If severely warped or damaged, the lid may need replacement.
Scratches or dents on the metal bin.	Impact with hard objects; abrasive cleaning.	Handle the bin with care. Avoid using abrasive cleaning tools. Minor cosmetic damage typically does not affect functionality.

8. SPECIFICATIONS



The Bloomingville Metal Bread Bin with its key dimensions indicated.

Feature	Detail
Product Dimensions	11.75"L x 5.25"W x 7"H
Material	Metal (bin), Bamboo (lid)
Color	Gray
Item Weight	2.14 Pounds
Recommended Use	Bread storage
Care Instructions	Hand Wash Only
Dishwasher Safe	No

Feature	Detail
Microwave Safe	No
Model Number	A97306650

9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact Bloomingville customer service directly. Keep your proof of purchase for any warranty claims.