**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Kingsleeve 104069

# Kingsleeve 300 cm Round Aluminum Crank Parasol

Model: 104069 | Brand: Kingsleeve

## Introduction

Thank you for choosing the Kingsleeve 300 cm Round Aluminum Crank Parasol. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your parasol. Please read these instructions carefully before use and retain them for future reference.

### Safety Information

- Always ensure the parasol is securely anchored in a stable base (base not included).
- Close the parasol during strong winds, heavy rain, or other adverse weather conditions to prevent damage or injury.
- Do not use the parasol near open flames or heat sources.
- Keep children and pets away from the parasol during assembly and operation.
- Regularly inspect all parts for wear and tear. Do not use if any components are damaged.

## Package Contents

Please check that all components are present and undamaged before proceeding with assembly.

- 1x Parasol Canopy with Ribs
- 1x Upper Pole Section (with crank mechanism)
- 1x Lower Pole Section
- 1x Storage Strap (attached to canopy)



Image: The Kingsleeve 300 cm round parasol in blue, fully open, showcasing its design and size.

## Setup Instructions

1. **Connect Pole Sections:** Carefully insert the upper pole section (with the crank) into the lower pole section. Ensure they are fully engaged and the locking mechanism (if present) is secured.
2. **Insert into Base:** Place the assembled pole into a suitable, heavy-duty parasol base (not supplied). Ensure the base is stable and capable of supporting the parasol's size and weight.
3. **Positioning:** Position the parasol in your desired location, ensuring it is clear of any obstructions and has sufficient clearance when opening.




Image: A detailed view highlighting key features such as the UV 50+ protection label, the crank handle for opening/closing, the tilt mechanism, and the 3.8 cm pole diameter.

## Operating Instructions

1. **Opening the Parasol:** Turn the crank handle clockwise until the canopy is fully extended and taut. Do not overtighten.
2. **Closing the Parasol:** Turn the crank handle counter-clockwise until the canopy is fully closed. Secure it with the attached storage strap to prevent it from opening unintentionally.
3. **Adjusting Tilt:** To tilt the parasol, locate the tilt mechanism on the upper pole. Press the button or lever and adjust the canopy to the desired angle (up to 45 degrees). Release the button/lever to lock it in place.
4. **Wind Vent:** The integrated wind vent at the top of the canopy helps to improve stability by allowing air to escape, reducing pressure build-up and heat accumulation underneath the parasol.

## Maintenance

- **Cleaning the Canopy:** Clean the polyester canopy with a mild soap solution and a soft brush or cloth. Rinse thoroughly with clean water and allow it to air dry completely before closing or storing. Do not use harsh chemicals or abrasive cleaners.
- **Pole Maintenance:** The aluminum pole is rust-resistant. Wipe it clean with a damp cloth as needed.
- **Storage:** For prolonged periods of non-use, especially during winter or harsh weather, disassemble the pole into two parts for compact storage. Store the parasol in a dry, protected area to extend its lifespan.
- **Inspection:** Periodically check all screws, bolts, and moving parts to ensure they are tight and functioning correctly.



Image: An underside view of the parasol canopy, illustrating the stable rib structure that supports the fabric.

## Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Parasol difficult to open/close. | Crank mechanism may be stiff or obstructed. | Apply a silicone-based lubricant to the moving parts of the crank mechanism. Ensure no fabric is caught. |
| Parasol is unstable. | Base is too light or not properly secured. Pole sections not fully connected. | Use a heavier, more stable parasol base. Ensure pole sections are fully engaged. Close parasol in windy conditions. |
| Canopy color fading. | Prolonged exposure to direct sunlight. | While the canopy offers UV protection, continuous exposure to intense sunlight can lead to some color fading over time. Store the parasol when not in use to minimize exposure. |

## Specifications

- **Model Number:** 104069
- **Diameter:** 300 cm (approx. 9.8 ft)
- **Height:** 248 cm (approx. 8.1 ft)
- **Pole Diameter:** 38 mm (approx. 1.5 inches)
- **Pole Material:** Aluminum
- **Canopy Material:** 100% Polyester
- **UV Protection:** UV 80+
- **Water Resistance:** Waterproof canopy
- **Features:** Crank mechanism, 45-degree tilt function, wind vent, 2-part pole for storage.
- **Color:** Blue

## Warranty and Support

Kingsleeve products are manufactured to high-quality standards. For any questions regarding your product, or if you require technical support, please contact your retailer or the Kingsleeve customer service department. Please have your model number (104069) and purchase information ready when contacting support.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B071ZFHRH4**

More documents and user manuals: **https://manuals.plus/**