

## Campingaz C 206 GLS

# Campingaz C 206 GLS Pierceable Gas Cartridges User Manual

Model: C 206 GLS

---

## 1. INTRODUCTION

Thank you for choosing Campingaz C 206 GLS Pierceable Gas Cartridges. These cartridges are designed to provide a reliable and efficient fuel source for a variety of Campingaz 206 line appliances, including camping stoves, soldering lamps, and camping lanterns. This manual provides essential information for the safe and correct use, installation, and storage of your gas cartridges. Please read all instructions carefully before use and retain this manual for future reference.

**Important Safety Notice:** Gas cartridges contain highly flammable gas under pressure. Improper handling can lead to serious injury or property damage. Always follow safety guidelines.

## 2. PRODUCT OVERVIEW

The Campingaz C 206 GLS cartridge contains a high-energy butane/propane gas mixture (80/20 ratio) for efficient performance even in varying weather conditions. It features an innovative Gas-Lock system designed to minimize gas leakage if the cartridge is accidentally detached after piercing.

### Key Features:

- Pierceable cartridge design for secure connection to compatible appliances.
- Butane/Propane gas mixture (80/20) for reliable ignition and high calorific value.
- Innovative Gas-Lock system to prevent significant gas leaks upon accidental detachment.
- Compatible with all Campingaz 206 line appliances.

### Package Contents:

- Campingaz C 206 GLS Pierceable Gas Cartridges (quantity as purchased, e.g., 4-pack)



Image 1: Campinggaz C 206 GLS Pierceable Gas Cartridges. This image displays a pack of four blue gas cartridges, each with a white label indicating the model C 206 GLS and safety warnings. The cartridges are cylindrical with a domed top.

### 3. SETUP AND INSTALLATION

Always perform installation in a well-ventilated area, away from ignition sources, open flames, and other people. Ensure the appliance is turned off and cooled down before installation.

1. **Prepare the Appliance:** Ensure your Campinggaz 206 line appliance is clean, in good working order, and its gas valve is fully closed.
2. **Unpack the Cartridge:** Carefully remove one C 206 GLS gas cartridge from its packaging.
3. **Align and Attach:** Position the cartridge correctly into the appliance's cartridge housing. The appliance will have a piercing mechanism. Align the cartridge so that the piercing pin on the appliance will correctly engage the top of the cartridge.
4. **Pierce the Cartridge:** Following your appliance's specific instructions, securely attach the cartridge. This action will pierce the cartridge, creating a gas-tight seal. **Once pierced, the cartridge cannot be removed until it is completely empty, as gas will escape.**
5. **Check for Leaks:** After installation, check for any gas leaks. You can do this by listening for a hissing sound or by applying a soapy water solution to the connection point. If bubbles appear, there is a leak.

Immediately turn off the appliance, disconnect the cartridge (if safe to do so, or move to a very well-ventilated area), and re-examine the connection. Do not use the appliance if a leak is detected.

**Note:** The innovative Gas-Lock system is designed to minimize gas escape if the cartridge is accidentally detached after piercing. However, it is crucial to ensure a proper, tight connection during installation to prevent any leaks.

## 4. OPERATING INSTRUCTIONS

---

Once the cartridge is securely installed, you can operate your Campingaz 206 line appliance according to its specific user manual.

1. **Ignition:** Slowly open the gas valve on your appliance and ignite the gas using the appliance's ignition system or a long-stemmed lighter/match.
2. **Adjust Flame:** Adjust the gas flow to achieve the desired flame size or heat output.
3. **During Use:** Always use the appliance in a well-ventilated area. Never leave an operating appliance unattended. Keep children and pets away from the appliance.
4. **Shut Down:** When finished, turn the gas valve on the appliance fully off. Allow the appliance to cool down completely before handling or storing.

**Important:** Do not attempt to refill these cartridges. They are designed for single use only.

## 5. MAINTENANCE AND STORAGE

---

### Storage:

- Store unused cartridges in a cool, dry, well-ventilated area, away from direct sunlight and temperatures exceeding 50°C (122°F).
- Keep cartridges away from ignition sources, open flames, and heat.
- Store out of reach of children and pets.
- Do not store near corrosive materials.

### Disposal:

Empty cartridges should be disposed of according to local regulations for hazardous waste. Do not puncture, incinerate, or dispose of in general household waste. Ensure the cartridge is completely empty before disposal.

## 6. TROUBLESHOOTING

---

- **No Gas Flow:**
  - Ensure the cartridge is correctly installed and pierced.
  - Check if the appliance's gas valve is open.
  - The cartridge might be empty. Replace with a new one (only after the current one is fully depleted and safely removed/disposed of).
- **Gas Leak Detected:**
  - Immediately turn off the appliance.
  - Move the appliance and cartridge to a well-ventilated outdoor area.
  - Re-check the connection for proper seating. If the leak persists, do not use the cartridge or

appliance. Contact Campingaz customer support or a qualified technician.

- **Weak Flame:**

- The cartridge may be running low on gas.
- Ensure the appliance's gas valve is fully open.
- Check for blockages in the appliance's gas line (refer to your appliance's manual).

## 7. SPECIFICATIONS

<b>Model</b>	C 206 GLS
<b>Gas Type</b>	Butane/Propane (80/20 ratio)
<b>Net Weight per Cartridge</b>	190 g
<b>Cartridge Type</b>	Pierceable
<b>Dimensions (approx.)</b>	9 x 9 cm
<b>Compatibility</b>	Campingaz 206 line appliances
<b>Manufacturer</b>	Campingaz
<b>ASIN</b>	B07219V7KY

## 8. SAFETY INFORMATION

**WARNING:** Failure to follow these instructions may result in fire, explosion, serious injury, or death.

- Use only in well-ventilated areas. Do not use indoors, in tents, or in unventilated spaces.
- Keep away from heat, hot surfaces, sparks, open flames, and other ignition sources. No smoking.
- Do not puncture or incinerate, even after use.
- Do not expose to temperatures exceeding 50°C (122°F).
- Keep out of reach of children.
- Use only with Campingaz 206 line appliances designed for pierceable cartridges.
- Always check for leaks after connecting the cartridge.
- Never attempt to refill the cartridge.
- Store in a cool, dry place.
- In case of gas leak:
  - Extinguish any open flames.
  - Ventilate the area.
  - If possible, close the gas supply.
  - Evacuate the area.

## 9. WARRANTY AND SUPPORT

Specific warranty information for Campingaz C 206 GLS cartridges is not provided in this manual. For details regarding product warranty, please refer to the packaging or contact Campingaz directly.

For technical support, product inquiries, or to report an issue, please contact Campingaz customer service

through their official website or the retailer where the product was purchased. Please have your product model (C 206 GLS) and ASIN (B07219V7KY) available when contacting support.

**Manufacturer:** Campingaz

---

© 2026 Campingaz. All rights reserved.