Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Timex /
- > Timex Transcend 34mm Women's Analog Watch Instruction Manual

Timex TW2R361009J

Timex Transcend 34mm Women's Analog Watch Instruction Manual

Model: TW2R361009J

Introduction

This instruction manual provides essential information for the proper setup, operation, and maintenance of your Timex Transcend 34mm Women's Analog Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

Product Overview

The Timex Transcend watch combines a modern stylish design with reliable analog-quartz movement. It features a 34mm case diameter and a stainless steel mesh bracelet, offering both elegance and comfort. The watch is water-resistant to 30 meters (100 feet).




Front view of the Timex Transcend 34mm Women's Analog Watch, showcasing its gold-tone case and mesh bracelet.

Setup

Setting the Time

- 1. Locate the crown on the right side of the watch case.
- 2. Gently pull the crown outwards to position 2. You will feel a slight click.
- 3. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
- 4. Once the time is set, push the crown back into its original position (position 1) to start the watch movement.



Side view of the watch, highlighting the crown used for time adjustment.

Adjusting the Mesh Bracelet

The stainless steel mesh bracelet features an adjustable clasp for a comfortable fit. To adjust:

- 1. Open the safety clasp and lift the main clasp lever.
- 2. Using a small, flat tool (like a small screwdriver or a paperclip), gently pry open the locking plate on the clasp.
- 3. Slide the clasp along the mesh band to the desired position. Ensure the clasp is centered on your wrist.
- 4. Press the locking plate back down firmly until it clicks into place. Ensure it is securely fastened.
- 5. Close the main clasp lever and then the safety clasp.



Close-up of the adjustable mesh bracelet clasp.

Operating

Your Timex Transcend watch is designed for reliable timekeeping. Once the time is set, the watch will operate continuously until the battery requires replacement.

Water Resistance

This watch is water resistant to 30 meters (100 feet). This means it can withstand splashes or brief immersion in water. It is **not** suitable for swimming, bathing, showering, or diving. Avoid operating the crown while the watch is wet to prevent water intrusion.

Maintenance

Battery Replacement

The watch requires one CR2 battery (included). When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

Cleaning

To clean your watch, wipe the case and bracelet with a soft, damp cloth. For the mesh bracelet, a soft brush can be used to gently remove dirt from the links. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.

Troubleshooting

- Watch not running: Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Time is inaccurate:** Ensure the crown is fully pushed in after setting the time. If the issue persists, the battery may be low or the movement may require servicing.
- Bracelet feels loose/tight: Refer to the "Adjusting the Mesh Bracelet" section for instructions on how to resize the band.

Specifications

Feature	Detail
Brand	Timex
Model Number	TW2R361009J
Case Diameter	34mm
Movement	Analog-Quartz
Water Resistance	30m (100ft)
Material	Brass (case)
Bracelet Material	Stainless Steel Mesh
Battery Type	1 CR2 battery

Warranty and Support

Your Timex watch is covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty details, registration, or to access customer support, please visit the official Timex website or contact their customer service department. Keep your proof of purchase for warranty claims. For further assistance, you may visit the Timex Store on Amazon.

	Timex Diamond Collection Watch User Manual and Instructions Official user manual and guide for the Timex Diamond Collection watch, providing instructions on operation, water resistance, time setting, bracelet adjustment, and warranty information.
The state of the s	Timex Watch User Manual and Instructions Comprehensive user manual and instructions for Timex watches, covering setup, water resistance, time/date setting, bracelet adjustment, and battery safety. Includes warranty information.
TIMEX TOWNS TO	Timex Analog Watch User Guide and Instructions Comprehensive user guide for Timex Analog watches, covering setup, water resistance, time and date setting, bracelet adjustment, and warranty information.
TIMEX TOWN	Timex 732-096000 Analog Watch User Manual and Instructions Official user manual and instructions for the Timex 732-096000 Analog watch. Learn how to start, set time/date, adjust bracelet, and understand water resistance.
	Timex Watch User Manual and Warranty Information A comprehensive guide for Timex watches, covering setup, operation, features like INDIGLO night-light, bracelet adjustment, water and shock resistance, battery care, and international warranty details.
TIMEX Compared to the compa	Timex Analog Watch User Manual - Features, Settings, and Care Comprehensive user guide for Timex Analog watches, covering setup, features like INDIGLO® Night-Light, water resistance, alarms, perpetual calendar, and maintenance. Available in multiple languages.