

Manuals.plus /

- › Braun /
- › Braun AW50 Quartz Watch Instruction Manual

Braun AW50

Braun AW50 Quartz Watch Instruction Manual

1. PRODUCT OVERVIEW

The Braun AW50 Quartz Watch is designed for clear readability and minimalist aesthetics. This manual provides essential information for the proper setup, operation, and maintenance of your watch.





Figure 1: Front view of the Braun AW50 Quartz Watch.

2. SETUP AND INITIAL USE

2.1 Setting the Time

1. Gently pull the crown (located on the right side of the watch case) outwards to the first position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to start the watch movement.



Figure 2: Close-up of the watch dial and crown for time adjustment.

2.2 Adjusting the Strap

The genuine leather strap features a traditional buckle clasp. Adjust the strap by selecting the appropriate hole for a comfortable and secure fit on your wrist. Ensure the watch is not too tight or too loose.



Figure 3: Watch strap and buckle detail.

3. OPERATING THE WATCH

The Braun AW50 is a quartz watch designed for accurate timekeeping. It features an analogue display with hour, minute, and second hands. The watch also includes a date display function.

3.1 Reading the Time and Date

- The long, thin hand indicates the seconds.
- The shorter, wider hand indicates the hours.
- The longer, wider hand indicates the minutes.
- The date is displayed in the window on the dial.

4. MAINTENANCE AND CARE

4.1 Cleaning

To clean your watch, wipe the case and crystal with a soft, dry cloth. For the leather strap, use a slightly damp cloth and allow it to air dry completely. Avoid using harsh chemicals or abrasive materials.

4.2 Water Resistance

This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. It is not suitable for swimming, showering, or diving. Avoid operating the crown while the watch is wet.

4.3 Battery Replacement

The watch is powered by a Lithium Ion battery. When the watch stops running, it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

5. TROUBLESHOOTING

5.1 Watch Not Running

- Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
- If the watch still does not run, the battery may need to be replaced. Consult a professional watch technician.

5.2 Incorrect Time

- Ensure the time is set correctly as described in Section 2.1.
- If the time continues to be inaccurate, there may be an issue with the quartz movement. Seek professional service.

6. SPECIFICATIONS

Feature	Specification
Model Number	AW50
Movement Type	Quartz
Case Material	Matt Stainless Steel
Crystal	Scratch Resistant Mineral Glass
Strap Material	Genuine Leather
Water Resistance	30 Meters (3 ATM)
Case Diameter	34 Millimeters
Case Thickness	7 Millimeters
Band Width	20 Millimeters
Item Weight	23 Grams
Included Components	Watch, Presentation Box, Instruction Manual, 2-Year Warranty



Figure 4: Side profile of the Braun AW50 watch.



Figure 5: Back of the watch with engraved specifications.

7. WARRANTY AND SUPPORT

7.1 Manufacturer Guarantee

This Braun AW50 Quartz Watch comes with a 2-year manufacturer guarantee from the date of purchase. This guarantee covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, service, or warranty claims, please contact Braun customer support through their official website or the retailer where the watch was purchased. Do not attempt to repair the watch yourself, as this may void the warranty.