

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DYMO](#) /

› [DYMO LabelWriter Wireless Label Printer LWW Machine Instruction Manual](#)

DYMO LWW Machine

DYMO LabelWriter Wireless Label Printer LWW Machine Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your DYMO LabelWriter Wireless Label Printer LWW Machine. This direct thermal printer offers cable-free convenience, allowing you to print labels from Macs, PCs, smartphones, and tablets via Wi-Fi. It is designed for various labeling needs, including shipping labels, warehouse labels, name badges, and barcodes, without the need for ink or toner.



Image 1.1: The DYMO LabelWriter Wireless Label Printer LWW Machine.

2. PACKAGE CONTENTS

Verify that all items are present in your product package:

- DYMO LabelWriter Wireless Label Printer
- AC Adapter
- USB Cable
- Starter Roll of DYMO LabelWriter Labels
- Quick Start Guide



Image 2.1: Included components: printer, AC adapter, and USB cable.

3. PRINTER OVERVIEW

Familiarize yourself with the main components of your LabelWriter Wireless printer.

- **Power Button:** Turns the printer on or off.
- **Feed Button:** Feeds a single blank label.
- **Wi-Fi Indicator:** Shows the status of the wireless connection.
- **Label Exit Slot:** Where printed labels emerge.
- **Power Port:** Connects the AC adapter.
- **USB Port:** For direct connection to a computer (optional).



Built-in Wi-Fi for cable-free label printing

Image 3.1: Control panel with power, feed, and Wi-Fi indicator.

4. SETUP

4.1. Connecting Power

1. Connect the AC adapter to the power port on the back of the printer.
2. Plug the other end of the AC adapter into a power outlet.
3. Press the power button to turn on the printer. The power indicator light will illuminate.

4.2. Loading Labels

1. Open the top cover of the printer.
2. Place the label roll onto the spindle, ensuring the labels feed from underneath the roll.
3. Insert the label roll and spindle into the label compartment.
4. Feed the leading edge of the labels into the label exit slot until the printer automatically grips the labels.
5. Close the top cover.



Image 4.1: Loading a label roll into the printer.

4.3. Software Installation

To print labels, you need to install the appropriate software:

- **For Mac/PC:** Download and install the DYMO Label software from the official DYMO website. This software allows for label design and printing, including integration with Microsoft Office applications.
- **For Smartphones/Tablets:** Download the DYMO Connect mobile app from your device's app store (iOS or Android).

4.4. Wireless (Wi-Fi) Setup

The DYMO LabelWriter Wireless printer connects to your network via Wi-Fi. Follow these steps for initial setup:

1. Ensure your printer is powered on and within range of your Wi-Fi network.
2. On your computer or mobile device, open the DYMO Label software or DYMO Connect app.
3. Follow the on-screen instructions to add a new printer and connect it to your Wi-Fi network. You will need your network name (SSID) and password.
4. The Wi-Fi indicator light on the printer will change to a solid blue when successfully connected.

Note: If you experience connectivity issues, ensure your printer is not automatically joining another network. For business environments, ensure the printer's MAC address is whitelisted on your router if MAC filtering is enabled. Disabling SNMP in Windows TCP/IP port settings for the printer can also resolve offline issues.




Image 4.2: Multiple users can share a single wireless printer.

5. OPERATION

5.1. Printing from a Computer (Mac/PC)

1. Open the DYMO Label software.
2. Select your desired label type and design your label using the available tools.
3. Ensure the correct printer is selected in the software.
4. Click the 'Print' button.

You can also print directly from Microsoft Word, Excel, or Outlook using the DYMO Label software plugins.



Image 5.1: Printing labels in an office environment.

5.2. Printing from a Mobile Device

1. Open the DYMO Connect mobile app on your smartphone or tablet.
2. Select your printer and design your label.
3. Tap the 'Print' icon.




Image 5.2: Designing labels using the DYMO Connect mobile app.

6. MAINTENANCE

6.1. Cleaning the Printer

Regular cleaning helps maintain print quality and extends the life of your printer.

- Turn off and unplug the printer before cleaning.
- Use a soft, lint-free cloth to wipe the exterior of the printer.
- To clean the print head, use a DYMO LabelWriter cleaning card or a cotton swab lightly dampened with isopropyl alcohol. Gently wipe the print head.
- Clean the label path to remove any adhesive residue or dust.

6.2. Replacing Label Rolls

When a label roll is empty, replace it by following the 'Loading Labels' instructions in Section 4.2.

7. TROUBLESHOOTING

If you encounter issues with your DYMO LabelWriter Wireless printer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Printer not connecting to Wi-Fi or frequently goes offline.	Incorrect Wi-Fi password, network interference, printer entering standby, MAC filtering on router, SNMP enabled in Windows port settings.	Verify Wi-Fi password. Ensure printer is within range. Check router settings for MAC filtering. In Windows, disable SNMP for the printer's TCP/IP port. Restart printer and router.
Labels are jamming or feeding incorrectly.	Labels not loaded correctly, incorrect label type, adhesive residue on rollers.	Reload labels according to instructions. Ensure you are using genuine DYMO LabelWriter labels. Clean the label path and rollers.
Poor print quality (faded, streaky, or blank labels).	Print head is dirty, labels are old or damaged, incorrect label type.	Clean the print head. Replace the label roll with a new one. Ensure labels are stored properly.
Software/App not detecting printer.	Printer is off, not connected to Wi-Fi, or software/app is outdated.	Ensure printer is on and Wi-Fi indicator is solid blue. Restart software/app. Update software/app to the latest version. Try connecting via USB if Wi-Fi fails.

8. SPECIFICATIONS

Feature	Specification
Model Name	LWW Machine
Item Model Number	2002150
Brand	DYMO
Printing Technology	Thermal
Connectivity Technology	Wireless (Wi-Fi), USB
Maximum Media Size	2-5/16" x 4"
Maximum Black and White Print Resolution	203 dpi
Max Copy Speed (Black & White)	51 ppm
Compatible Devices	Laptops, PC, Smartphones
Item Weight	1.46 pounds
Product Dimensions	10 x 7.25 x 7 inches (or 5"D x 9.9"W x 4.88"H)
Memory Storage Capacity	64 MB

Feature	Specification
Material Type	Plastic

9. WARRANTY INFORMATION

The DYMO LabelWriter Wireless Label Printer LWW Machine comes with a limited warranty. Please refer to the warranty documentation included with your product or visit the official DYMO website for specific terms and conditions regarding warranty coverage and duration.

10. CUSTOMER SUPPORT

For further assistance, technical support, or to access additional resources such as software downloads and FAQs, please visit the official DYMO support website or contact their customer service department. Contact information can typically be found on the DYMO website or in the product's quick start guide.

© 2025 DYMO. All rights reserved.

Related Documents - LWW Machine

 <p>DYMO LabelWriter® 550 LabelWriter® 550 Turbo LabelWriter® 5XL Használati útmutató</p> <p>newell</p>	<p><u>DYMO LabelWriter 550 Series User Manual</u></p> <p>Comprehensive user manual for the DYMO LabelWriter 550, 550 Turbo, and 5XL label printers, covering setup, operation, maintenance, troubleshooting, and technical specifications.</p>
 <p>DYMO LabelWriter® 550 LabelWriter® 550 Turbo LabelWriter® 5XL User Guide</p> <p>newell</p>	<p><u>DYMO LabelWriter 550, 550 Turbo, 5XL User Guide</u></p> <p>A comprehensive user guide for DYMO LabelWriter 550, 550 Turbo, and 5XL label printers, detailing setup, operation, maintenance, troubleshooting, and technical specifications.</p>
 <p>DYMO LabelWriter® 550 LabelWriter® 550 Turbo LabelWriter® 5XL User Guide</p> <p>newell</p>	<p><u>DYMO LabelWriter 550, 550 Turbo, 5XL User Guide</u></p> <p>User guide for DYMO LabelWriter 550, 550 Turbo, and 5XL label printers, covering setup, operation, maintenance, and troubleshooting.</p>

 <p>DYMO LabelWriter Quick Start Guide Version 3.0 (2012)</p>	<p>DYMO LabelWriter 550 Series Quick Start Guide</p> <p>A quick start guide for the DYMO LabelWriter 550, 550 Turbo, and 5XL label printers, covering software installation, power connection, computer connection, and label loading.</p>
 <p>DYMO LabelWriter 550, 550 Turbo, 5XL User Guide November 25, 2012 (Version 21, 2012) Home ENGLISH DYMO LabelWriter 550, 550 Turbo, 5XL User Guide 21 Print this page Feedback Copyright © 2012 DYMO LabelWriter 550, 550 Turbo, 5XL User Guide 21 This document is the property of DYMO Corporation. It is intended for internal use only and may not be reproduced in whole or in part without the express written consent of DYMO Corporation. All rights reserved. Trademarks</p>	<p>DYMO LabelWriter 550, 550 Turbo, 5XL User Guide</p> <p>A comprehensive user guide for the DYMO LabelWriter 550, 550 Turbo, and 5XL label printers, covering setup, operation, maintenance, and troubleshooting.</p>
 <p>Momentus[®] Mobile Solution Hardware Install Guide PAYD Pro Plus[®] Mobile Solution</p>	<p>PAYD Pro Plus Mobile Solution: Hardware Install Guide</p> <p>This guide provides instructions on how to set up and install the hardware associated with the PAYD Pro Plus Mobile Solution, including Bluetooth barcode scanners, receipt printers, cash drawers, and DYMO LabelWriters.</p>