

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Brinkmann](#) /
- › [Brinkmann Grill King Smoker Grill Cover User Manual](#)

Brinkmann 812-3210-0

Brinkmann Grill King Smoker Grill Cover User Manual

Model: 812-3210-0

INTRODUCTION

This manual provides essential information for the proper use and care of your Brinkmann Grill King Smoker Grill Cover, model 812-3210-0. This cover is an original equipment manufacturer (OEM) accessory designed specifically to fit Brinkmann Grill King Charcoal Grills with one shelf, including model 810-3210-V. Its primary purpose is to protect your grill from environmental elements.

SETUP AND INSTALLATION

Before installing the cover, ensure your grill is cool and clean. Unpack the cover from its packaging. The cover is designed to fit snugly over the specified Grill King models.



The image displays the Brinkmann Grill King Smoker Grill Cover, model 812-3210-0, as it appears in its original clear plastic packaging. The cover is black with the 'BRINKMANN' logo visible in white lettering. The packaging also features a label indicating it is for 'Grill King Grill Cover' and 'Smokeshop Smoking Headquarters'.

Carefully place the cover over your grill, ensuring it fully encloses the grill body and any attached shelves as intended. The cover's design accounts for the dimensions of compatible Grill King charcoal grills.

OPERATING INSTRUCTIONS

The grill cover is intended for outdoor use to protect your grill from various weather conditions, including rain, dust, and UV exposure. Always ensure the grill is completely cool before covering it to prevent damage to the cover or the grill.

- **Protection:** Use the cover when the grill is not in use and stored outdoors to shield it from harsh elements.
- **Ventilation:** While the cover provides protection, ensure adequate air circulation around the grill when covered to prevent moisture buildup.

CARE AND MAINTENANCE

Regular cleaning and proper storage will extend the life of your grill cover.

- **Cleaning:** Wipe the cover with a damp cloth and mild soap solution as needed. Rinse thoroughly with water and allow it to air dry completely before storing or reapplying to the grill. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the cover in a dry, cool place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically inspect the cover for any signs of wear, tears, or damage.

TROUBLESHOOTING

If you encounter issues with your grill cover, consider the following:

- **Cover Does Not Fit:** Ensure your grill is a compatible Brinkmann Grill King Charcoal Grill model, such as 810-3210-V. This cover is specifically designed for certain dimensions.
- **Moisture Under Cover:** Ensure the grill is completely dry before covering. Adequate air circulation can help prevent condensation.
- **Damage:** If the cover is torn or significantly damaged, its protective capabilities may be compromised. Consider replacement if the damage is extensive.

PRODUCT SPECIFICATIONS

Brand	Brinkmann
Model Number	812-3210-0
Compatible Grill Model	Grill King Charcoal Grill 810-3210-V (with one shelf)
Item Weight	2.2 pounds
Package Dimensions	13.5 x 12 x 3 inches

ASIN	B0727L3ZF9
------	------------

WARRANTY INFORMATION

Specific warranty details for the Brinkmann Grill King Smoker Grill Cover are typically provided at the time of purchase or can be obtained directly from the manufacturer. Please refer to any documentation included with your product or contact Brinkmann customer support for warranty claims and information.

CUSTOMER SUPPORT

For further assistance, questions, or to report issues with your Brinkmann Grill King Smoker Grill Cover, please contact Brinkmann customer support. Contact information can usually be found on the product packaging or the official Brinkmann website.