

Zippo ZO30075

Zippo Typhoon Match Kit ZO30075 Instruction Manual

Brand: Zippo | Model: ZO30075

1. INTRODUCTION

The Zippo Typhoon Match Kit is engineered for reliability in challenging environments. This kit provides a dependable fire-starting solution, featuring heavy-duty construction and a sealed strike pad to protect the included Typhoon Matches. Designed to float in water and ensure matches remain dry, it facilitates fire ignition even in severe conditions. Its ergonomic design allows for easy one-hand use, making it suitable for camping, backpacking, hunting, and emergency preparedness.

2. KEY FEATURES

- Includes 15 Typhoon Matches for reliable ignition.
- Water-resistant storage case protects matches from moisture.
- Integrated water-resistant strike pad cap with additional strike pads for extended use.
- Ergonomic design with textured grip for secure handling.
- Floats in water, preventing loss and keeping contents dry if dropped.
- Reusable ABS plastic construction ensures durability.
- Molded lanyard hole for easy attachment and carrying.

3. SETUP

Upon receiving your Zippo Typhoon Match Kit, ensure all components are present and in good condition. The kit includes the water-resistant case, 15 Typhoon Matches, and an instruction sheet. The matches are pre-loaded into the case, and spare strike pads are typically included within the packaging.



Figure 1: The Zippo Typhoon Match Kit as it appears in its retail blister packaging, highlighting the matches and the water-resistant case.

4. OPERATING INSTRUCTIONS

1. **Accessing Matches:** Unscrew the red cap from the top of the gray case. The matches are stored inside, protected by an O-ring seal.
2. **Exposing the Strike Pad:** The strike pad is integrated into the bottom cap of the case. Flip open the black cover to expose the strike pad surface.
3. **Striking a Match:** Remove one Typhoon Match from the case. Hold the match firmly and strike the match head against the exposed strike pad with a swift, firm motion. Ensure the strike pad is dry for optimal performance.
4. **Applying Flame:** Once lit, the Typhoon Match will produce a strong, windproof, and water-resistant flame that burns for approximately 30 seconds. Carefully apply the flame to your tinder or kindling to start a fire. Always ensure the match is extinguished completely before disposal.
5. **Safety Note:** Due to the match's robust burning properties, it cannot be easily blown out. Be prepared to let it burn for its full duration or extinguish it on a non-flammable surface.



Figure 2: The Zippo Typhoon Match Kit, shown open, revealing the included matches and the separate, sealed strike pad cap.



Figure 3: A hand demonstrating the process of striking a Typhoon Match against the kit's integrated strike pad to ignite it.



Figure 4: A Zippo Typhoon Match burning with a robust, visible flame, illustrating its powerful ignition.



Figure 5: A remarkable demonstration of the Typhoon Match's stormproof capabilities, burning even when fully submerged in water.

Video 1: This official product video showcases the Zippo Typhoon Match Kit, demonstrating its water-resistant case, the process of striking a match, and the match's ability to burn in challenging conditions.

5. MAINTENANCE

- **Replacing Strike Pads:** The kit includes additional strike pads. If the integrated strike pad becomes worn or ineffective, carefully peel off the old pad and replace it with a new one.
- **Maintaining Waterproof Seal:** Periodically inspect the O-ring seal on the cap for any signs of wear or damage. Ensure it is clean and free of debris to maintain the water-resistant integrity of the case.
- **Match Storage:** Always store matches inside the water-resistant case to protect them from moisture and damage.



Figure 6: The Zippo Typhoon Match Kit, illustrating the inclusion of extra strike pads for prolonged usability.



Figure 7: A detailed view of the integrated, sealed strike pad located on the bottom of the match kit, designed for reliable ignition.

6. TROUBLESHOOTING

- **Matches Not Lighting:** Ensure the strike pad is completely dry. If the pad is wet or worn, replace it with a fresh one. Ensure the match head is also dry.
- **Case Difficult to Open/Close:** Check the O-ring seal for any dirt, debris, or damage. Clean the O-ring and the threading, or replace the O-ring if necessary.
- **Water Inside Case:** Verify that the cap was securely tightened and the O-ring is intact and clean. If the O-ring is damaged, replace it to restore the water-resistant seal.

7. SPECIFICATIONS

Item Package Dimensions L x W x H	5.59 x 3.03 x 1.93 inches
Package Weight	0.14 Kilograms
Item Dimensions LxWxH	0.28 x 0.28 x 4.19 inches
Brand Name	Zippo
Country of Origin	China
Model Name	ZO30075
Color	Grey and Red
Material	Other
Number of Items	1
Manufacturer	Zippo Manufacturing Company
Part Number	40483
Style	Match Kit

Included Components	typhoon matches, waterproof case, instruction sheet
Size	One Size




8. WARRANTY INFORMATION




This Zippo Typhoon Match Kit is covered by a Manufacturer Warranty. For specific details regarding coverage, duration, and claims process, please refer to the warranty documentation included with your product or contact Zippo customer support.

9. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Zippo Typhoon Match Kit, please visit the official Zippo website or contact their customer service department. Contact information can typically be found on the product packaging or the Zippo website.

Related Documents - ZO30075

	<p>Zippo Arc Lighter Insert User Manual and Safety Guide</p> <p>Comprehensive user manual and safety instructions for the Zippo Arc Lighter Insert, Double Beam model #Z8C23. Includes operating, ignition, recharging, compatibility, and safe battery disposal information.</p>
	<p>Zippo Windproof Lighter: Instructions, Maintenance & Guarantee</p> <p>Learn how to properly fill, re-flint, and maintain your Zippo Windproof Lighter with this comprehensive instruction manual. Includes important safety warnings and details on the Zippo Lifetime Guarantee.</p>
	<p>Zippo Mini MPL Candle Lighter Instructions - User Guide</p> <p>Official instructions for the Zippo Mini MPL Candle Lighter. Learn how to operate, refill, and adjust the flame safely. Includes warranty information and safety warnings.</p>

	<p>Zippo HeatBank 6 Rechargeable Hand Warmer Z4A20 User Manual and Instructions</p> <p>Comprehensive instructions and safety guidelines for the Zippo HeatBank 6 Rechargeable Hand Warmer (Model Z4A20). Covers operation, charging, warranty, and disposal.</p>
	<p>Zippo HeatBank 3 Instructions: Rechargeable Hand Warmer & Portable Charger Guide</p> <p>Comprehensive instructions for the Zippo HeatBank 3, covering safety warnings, operating procedures, charging, mobile device charging, and battery disposal. Learn how to use your Zippo HeatBank 3 effectively and safely.</p>
	<p>Zippo Butane Torch Lighter Inserts: Safety Warnings and Instructions</p> <p>Essential safety warnings, usage instructions, and disposal guidelines for Zippo Butane Torch Lighter Inserts, including models Z8A19 and 28819. Learn how to safely refill and maintain your Zippo torch lighter insert.</p>