

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Steelplay](#) /
- › [Steelplay HP45 Wired Stereo Headset User Manual](#)

## Steelplay HP45

# Steelplay HP45 Wired Stereo Headset User Manual

Model: HP45 | Brand: Steelplay

## INTRODUCTION

Welcome to the user manual for your new Steelplay HP45 Wired Stereo Headset. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your headset to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

## PRODUCT OVERVIEW

The Steelplay HP45 is a high-quality wired stereo headset designed for an immersive audio experience. It features a comfortable design and clear sound reproduction, making it suitable for various gaming and audio needs.



Image: Front view of the Steelplay HP45 Wired Stereo Headset, showcasing its black and green design with the microphone extended.

### Key Features:

- Wired connectivity for stable audio transmission.
- Stereo sound for clear audio.
- Integrated microphone for communication.
- Durable Polycarbonate (PC) material construction.
- Compatible with Xbox Series X, Xbox Series S, PS5, PS4, Nintendo Switch, and PC.

## PACKAGE CONTENTS

Please check the package carefully to ensure all items are present:

- Steelplay HP45 Wired Stereo Headset
- User Manual (this document)



Image: The Steelplay HP45 Wired Stereo Headset shown within its retail packaging, highlighting compatibility with various gaming platforms.

## SETUP

Follow these steps to set up your Steelplay HP45 headset:

1. **Identify the Audio Jack:** The HP45 headset uses a standard 3.5mm audio jack for connection.
2. **Connect to Your Device:**
  - **For Game Consoles (Xbox Series X/S, PS5, PS4, Nintendo Switch):** Plug the 3.5mm jack directly into the controller's headset port.

- **For PC:** If your PC has a combined audio/microphone jack, plug the 3.5mm jack directly. If your PC has separate audio (green) and microphone (pink) jacks, you may need a Y-splitter adapter (not included) to use both functions.
3. **Adjust Headset Fit:** Gently extend or retract the headband to ensure a comfortable and secure fit over your ears. The earcups should fully cover your ears.
  4. **Position the Microphone:** Adjust the flexible microphone boom so that the microphone is positioned near your mouth for clear voice pickup.



Image: Side view of the Steelplay HP45 headset, illustrating the wired connection point and the adjustable microphone.

# OPERATING INSTRUCTIONS

---

Once connected, your Steelplay HP45 headset is ready for use. Here are some general operating tips:

- **Volume Control:** Adjust the audio volume using the volume controls on your connected device (console, PC, or mobile device). The HP45 headset does not feature inline volume controls.
- **Microphone Usage:** Ensure the microphone is positioned correctly for clear communication. Microphone settings (e.g., sensitivity, mute) are typically managed through your connected device's audio settings.
- **Audio Output Selection:** On some devices, you may need to manually select the headset as the primary audio output and input device in the system's sound settings.

## MAINTENANCE

---

Proper care will extend the life of your Steelplay HP45 headset:

- **Cleaning:** Use a soft, dry cloth to wipe down the earcups and headband. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the speaker grilles or microphone. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the headset in a clean, dry place away from direct sunlight and extreme temperatures. Avoid tangling the cable.
- **Cable Care:** Do not pull on the cable to disconnect the headset. Always grasp the plug firmly. Avoid sharp bends or kinks in the cable.

## TROUBLESHOOTING

---

If you encounter issues with your Steelplay HP45 headset, try the following solutions:

### No Sound from Headset:

- Ensure the 3.5mm jack is fully inserted into the device's port.
- Check the volume settings on your connected device and ensure it is not muted.
- Verify that the headset is selected as the audio output device in your device's sound settings.
- Test the headset with another device to rule out a device-specific issue.

### Microphone Not Working:

- Ensure the microphone boom is positioned correctly.
- Check the microphone settings on your connected device; ensure it is not muted and the input level is adequate.
- Verify that the headset microphone is selected as the input device in your device's sound settings.
- If using a PC with separate jacks, ensure you have a compatible Y-splitter if needed.

### Sound Distortion or Poor Quality:

- Reduce the volume on your device if the sound is distorted at high levels.
- Ensure the audio jack is clean and free of debris.
- Test with another audio source or device.

## SPECIFICATIONS

---

<b>Brand</b>	Steelplay
<b>Model</b>	HP45
<b>Connectivity Technology</b>	Wired
<b>Material</b>	Polycarbonate (PC)
<b>Age Range (Description)</b>	Adult
<b>ASIN</b>	B0727XSXDM
<b>Manufacturer</b>	Steelplay
<b>Date First Available</b>	May 19, 2022

## WARRANTY AND SUPPORT

### Warranty Information:

The Steelplay HP45 Wired Stereo Headset comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

*Note: Information regarding spare parts availability and software updates is not available.*

### Customer Support:

For further assistance, technical support, or warranty claims, please contact Steelplay customer service through their official website or the retailer from whom you purchased the product. Refer to the product packaging for specific contact details.

## Related Documents - HP45

	<p><a href="#">Steelplay HP-43 Wired Headset User Manual</a></p> <p>Steelplay HP-43 Wired Gaming Headset User Manual: Get detailed information on features, specifications, safety, setup, and warranty for the Steelplay HP-43 headset.</p>
	<p><a href="#">Steelplay HP-51 Wired Headset User Manual</a></p> <p>User manual for the Steelplay HP-51 wired headset, providing instructions on setup, usage, features, safety guidelines, and warranty information for this gaming headset.</p>

 <p>The cover of the Steelplay Pro Light Pad Evo Wired Controller User Manual. It features the Steelplay logo at the top, followed by the product name 'PRO LIGHT PAD EVO WIRED CONTROLLER' and 'USER MANUAL' at the bottom.</p>	<p><a href="#">Steelplay Pro Light Pad Evo Wired Controller User Manual</a></p> <p>User manual for the Steelplay Pro Light Pad Evo Wired Controller, detailing setup, features, safety information, and warranty for PlayStation 4 systems.</p>
 <p>The cover of the Steelplay MetalTech Wired Controller for PS4 User Manual. It features a grid of small images showing various controller features and components.</p>	<p><a href="#">Steelplay MetalTech Wired Controller for PS4 User Manual</a></p> <p>Comprehensive user manual for the Steelplay MetalTech Wired Controller for PS4, detailing setup, features, safety guidelines, warranty information, and troubleshooting.</p>
 <p>The cover of the Steelplay Wired Controller for Nintendo Switch - User Manual. It features an image of the controller and the text 'WIRED WIRELESS CLASSIC EDITION'.</p>	<p><a href="#">Steelplay Wired Controller for Nintendo Switch - User Manual</a></p> <p>Comprehensive user manual for the Steelplay Wired Controller (Model SP5028 / JVASWI00028), designed for Nintendo Switch. Covers product features, safety guidelines, usage instructions, firmware updates, customer support, warranty, and disposal information.</p>
 <p>The cover of the Steelplay Impulse Bluetooth Headset User Manual. It features an image of the headset and the text 'IMPULSE'.</p>	<p><a href="#">Steelplay Impulse Bluetooth Headset User Manual</a></p> <p>User manual for the Steelplay Impulse Bluetooth Headset, covering specifications, functions, compatibility, and warranty information.</p>