

Vintage Electronics MT-35

Vintage Electronics Turntable Belt User Manual

For Fisher MT-35 Turntable

Model: MT-35

INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your new Vintage Electronics turntable drive belt, specifically designed for the Fisher MT-35 turntable. This belt is manufactured to meet original equipment manufacturer (OEM) specifications, ensuring optimal performance for your audio equipment.

Please read these instructions carefully before proceeding with installation to ensure correct setup and to maximize the lifespan of your turntable belt.

SETUP AND INSTALLATION

Proper installation of the drive belt is crucial for the correct operation of your Fisher MT-35 turntable. Follow these steps carefully:

- Power Disconnection:** Before beginning any work, ensure the turntable is completely unplugged from the power outlet to prevent electrical shock or damage to the unit.
- Platter Removal:** Carefully remove the turntable platter. This usually involves lifting it straight up. Some models may require removing a retaining clip or screw first. Refer to your Fisher MT-35 turntable's original manual for specific platter removal instructions.
- Old Belt Removal:** Locate the old drive belt, if present. Gently remove it from the motor pulley and the inner rim of the platter or sub-platter.
- Cleaning:** Clean the motor pulley and the inner rim of the platter or sub-platter where the belt makes contact. Use a lint-free cloth and isopropyl alcohol to remove any residue from the old belt, oil, or dust. This ensures optimal grip for the new belt.
- New Belt Installation:** Carefully stretch the new Vintage Electronics drive belt around the motor pulley and the inner rim of the platter or sub-platter. Ensure the belt is seated evenly and is not twisted. Avoid overstretching the belt during installation.

6. **Platter Reinstallation:** Carefully place the platter back onto the turntable spindle, ensuring it is properly seated and level.
7. **Testing:** Reconnect the turntable to power. Select a record speed (e.g., 33 1/3 RPM) and observe if the platter rotates smoothly and at a consistent speed.




Image: A new turntable drive belt, similar to the one provided for the Fisher MT-35. This belt is designed to connect the motor pulley to the platter, enabling rotation.

OPERATING INSTRUCTIONS

Once the drive belt is correctly installed, the turntable should operate as intended. The belt's primary function is to transfer rotational energy from the motor to the platter, ensuring stable and accurate playback speeds.

- Ensure the turntable is placed on a stable, level surface.
- Select the appropriate playback speed (33 1/3 or 45 RPM) for your record.
- Lower the tonearm gently onto the record. The new belt will help maintain consistent platter rotation for optimal audio quality.

MAINTENANCE

To ensure the longevity and optimal performance of your turntable belt, consider the following maintenance tips:

- **Keep Clean:** Periodically inspect the belt, motor pulley, and platter rim for dust or debris. Clean with a dry, lint-free cloth. Avoid using harsh chemicals.
- **Avoid Contaminants:** Keep oil, grease, and other liquids away from the belt, as these can degrade the rubber material and cause slippage.
- **Proper Storage:** If the turntable is to be stored for an extended period, it is advisable to remove the belt to prevent it from developing flat spots or becoming stretched out of shape. Store it in a cool, dry place.
- **Gentle Handling:** When handling the belt, avoid excessive stretching or sharp bending, which can cause damage.

TROUBLESHOOTING

If you encounter issues after installing the new belt, consider these common troubleshooting steps:

- **Platter Not Spinning or Spinning Slowly:**
 - Ensure the belt is correctly seated on both the motor pulley and the platter's inner rim.
 - Check for any obstructions preventing the platter from rotating freely.
 - Verify the turntable is plugged in and powered on.
- **Inconsistent Speed (Wow and Flutter):**
 - Re-check belt tension and seating. The belt should be taut but not excessively stretched.
 - Ensure the motor pulley and platter rim are clean and free of residue.
 - Confirm the turntable is on a level surface.
- **Belt Slipping Off:**
 - Clean the motor pulley and platter rim thoroughly to remove any slick residue.
 - Ensure the belt is not twisted during installation.
 - Verify the belt is the correct size for your Fisher MT-35 turntable.

SPECIFICATIONS

- **Product Type:** Turntable Drive Belt
- **Compatibility:** Fisher MT-35 Turntable
- **Material:** Rubber (manufactured to OEM specifications)
- **Brand:** Vintage Electronics
- **Model Name:** MT-35
- **UPC:** 614632683649
- **ASIN:** B07288BG3H

WARRANTY INFORMATION

This Vintage Electronics turntable belt comes with a**Lifetime Warranty**. This warranty covers manufacturing defects and ensures the belt meets its specified performance standards under normal use. For warranty claims or further details, please contact Vintage Electronics customer support.

SUPPORT

Vintage Electronics offers outstanding technical support with 45 years of experience in the field. If you have any questions regarding the installation, operation, or maintenance of your turntable belt, or if you require assistance with troubleshooting, please do not hesitate to contact our support team.

Contact information for support can typically be found on the Vintage Electronics website or through your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question