

Lysol SYNCHKG121014

Lysol Disinfectant 144 Ounce Refill Bottle Advanced Deep Clean Lemon Breeze User Manual

Model: SYNCHKG121014

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of the Lysol Disinfectant 144 Ounce Refill Bottle, Advanced Deep Clean Lemon Breeze. This product is formulated to clean, disinfect, and deodorize various hard, non-porous surfaces in your home or workplace. Please read all instructions carefully before use to ensure optimal results and safety.

SAFETY INFORMATION

WARNING: Causes substantial but temporary eye injury. Harmful if swallowed. May cause skin irritation.

- **Keep Out of Reach of Children and Pets:** Store in a secure location inaccessible to children and animals.
- **Eye Contact:** Avoid contact with eyes. In case of eye contact, immediately flush eyes with plenty of water for at least 15 minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If irritation persists, seek medical attention.
- **Skin Contact:** Avoid prolonged or repeated contact with skin. If contact occurs, wash thoroughly with soap and water. If irritation develops, seek medical attention.
- **Ingestion:** Do not ingest. If swallowed, do not induce vomiting. Call a poison control center or doctor immediately for treatment advice.
- **Ventilation:** Use in a well-ventilated area.
- **Protective Measures:** For sensitive skin or prolonged use, wear rubber gloves.
- **Surface Compatibility:** Test on an inconspicuous area before use on all surfaces, especially painted or delicate finishes. Do not use on brass, copper, aluminum, or unsealed natural stone surfaces.

SETUP AND PREPARATION

The Lysol Disinfectant 144 Ounce Refill Bottle is designed to replenish your existing Lysol spray bottles or other suitable containers. Ensure the container you are refilling is clean and empty before proceeding.

1. **Open the Refill Bottle:** Twist the cap counter-clockwise to open the 144-ounce refill bottle.
2. **Prepare Receiving Bottle:** Ensure your empty spray bottle or container is clean and dry.

3. **Refill:** Carefully pour the Lysol Disinfectant liquid from the refill bottle into your designated container. Avoid overfilling.
4. **Secure Cap:** Tightly close the cap on both the refill bottle and the receiving container after use.



Image: Lysol Disinfectant 144 Ounce Refill Bottle. This image shows the large 144-ounce bottle of Lysol Disinfectant, ready for refilling smaller spray bottles.

OPERATING INSTRUCTIONS

This product can be used for cleaning, deodorizing, and disinfecting hard, non-porous surfaces.

For Cleaning and Deodorizing:

- Apply undiluted product to surface with a cloth or sponge.
- Wipe clean. No rinsing is required for cleaning.

For Disinfecting:

Pre-clean heavily soiled surfaces before disinfecting.

- Apply undiluted product to hard, non-porous surfaces until thoroughly wet.
- Allow surface to remain wet for **10 minutes** to disinfect.
- Wipe clean with a damp cloth or sponge. For surfaces that may come into contact with food, a rinse with potable water is recommended after disinfection.

Specific Uses:

- **Bathtub:** Spray or apply with a sponge, let stand for 10 minutes, then wipe.
- **Countertop:** For non-food contact surfaces, spray or apply, let stand for 10 minutes, then wipe. For food contact surfaces, rinse with potable water after wiping.
- **Floor:** For general cleaning, dilute as per instructions below. For disinfecting, apply undiluted, let stand for 10 minutes, then wipe.
- **Toilet:** Apply to toilet bowl surfaces, scrub, let stand for 10 minutes, then flush.

Dilution Instructions:

For general cleaning and light sanitizing, Lysol Disinfectant can be diluted. A common dilution ratio is 1 part Lysol to 4 parts water (e.g., 1 cup Lysol to 4 cups water). However, for full disinfection efficacy, the product should be used undiluted as specified in the 'For Disinfecting' section.

MAINTENANCE AND STORAGE

Storage:

- Store in original container in a cool, dry place away from direct sunlight and heat.
- Keep container tightly closed when not in use.
- Do not store near food or feed.

Disposal:

- **Container Disposal:** Non-refillable container. Do not reuse or refill this container. Offer for recycling if available, or place in trash.
- **Product Disposal:** Dispose of unused product in accordance with all local, state, and federal regulations.

TROUBLESHOOTING

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Product not cleaning effectively	Ensure surfaces are pre-cleaned of heavy soil. Apply undiluted product. Allow adequate contact time.
Strong odor persists after use	Ensure adequate ventilation during and after use. The Lemon Breeze scent is designed to deodorize, but strong odors may require repeated application or longer contact time.
Surface appears streaky or sticky	Wipe surfaces thoroughly with a clean, damp cloth after the recommended contact time. Avoid over-application.

SPECIFICATIONS

Feature	Detail
Brand Name	Lysol
Item Model Number	SYNCHKG121014
Item Form	Liquid
Scent	Advanced Deep Clean Lemon Breeze
Specific Uses For Product	Bathtub, Countertop, Floor, Toilet
Surface Recommendation	Floor (and other hard, non-porous surfaces)
Special Features	Refill
Contains Liquid Contents?	Yes
Item Volume	144 Fluid Ounces
Unit Count	144.0 Fluid Ounces
Item Weight	144 Ounces (9 Pounds)
UPC	036241934972
Material Features	Eco-Friendly
Manufacturer	Lysol
Date First Available	April 26, 2017

WARRANTY AND SUPPORT

For specific warranty information, product support, or to address any concerns not covered in this manual, please refer to the manufacturer's official website or contact their customer service directly. Lysol products are manufactured by Reckitt Benckiser. You can typically find contact information and frequently asked questions on the official Lysol website:www.lysol.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question