

[Manuals.plus](#) /

› [Beacon Pet](#) /

› Beacon Pet 1.6L Automatic Flower Pet Water Fountain with Green Silicone Pad Instruction Manual

Beacon Pet 43235-164761

Beacon Pet 1.6L Automatic Flower Pet Water Fountain Instruction Manual

Model: 43235-164761

INTRODUCTION

Thank you for choosing the Beacon Pet 1.6L Automatic Flower Pet Water Fountain. This device is designed to provide a continuous supply of fresh, filtered water for your cats and dogs, encouraging healthy hydration habits. Please read this manual thoroughly before setup and operation to ensure proper use and maintenance.

PRODUCT OVERVIEW

The Beacon Pet Automatic Flower Pet Water Fountain is a 1.6-liter capacity drinking system for pets. It features a unique flower design that creates flowing water streams, appealing to pets. The fountain includes a filtration system to purify water and comes with a green silicone pad to help contain spills and protect your floors.



Image 1: Beacon Pet 1.6L Automatic Flower Pet Water Fountain with Green Silicone Pad. The fountain is white with a green interior and a white flower spout, sitting on a round green silicone mat decorated with white daisies.

SAFETY INSTRUCTIONS

- Always unplug the fountain before cleaning or performing any maintenance.
- Ensure the power cord is not damaged and is placed where pets cannot chew on it.
- Do not immerse the power adapter or electrical plug in water.
- Use only the original power adapter provided with the fountain.
- Keep the fountain on a level surface to prevent spills.
- This product is for indoor use only.
- Supervise pets during initial use to ensure they adapt safely to the fountain.

PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1x Pet Water Fountain Main Unit (1.6L capacity)
- 1x Flower Spout Attachment
- 1x Water Pump
- 1x Filter Element
- 1x Power Adapter (12V)
- 1x Green Silicone Pad
- 1x Instruction Manual (this document)

SETUP

1. **Clean Components:** Before first use, wash all parts of the fountain (excluding the pump and power adapter) with mild soap and water. Rinse thoroughly.
2. **Install Pump:** Place the water pump into the designated area at the bottom of the fountain reservoir. Ensure the suction cups firmly attach the pump to the base.
3. **Insert Filter:** Rinse the filter element under cold water for 30 seconds to remove any loose carbon dust. Place the rinsed filter into the filter tray.
4. **Assemble Flower Spout:** Attach the flower spout to the top of the pump. You can adjust the flower petals to control the water flow pattern.
5. **Fill with Water:** Fill the fountain reservoir with clean water up to the maximum fill line. Do not overfill.
6. **Position Silicone Pad:** Place the green silicone pad on a flat, stable surface where you intend to keep the fountain.
7. **Place Fountain:** Carefully place the assembled fountain onto the center of the silicone pad.
8. **Connect Power:** Connect the power adapter to the pump's cable, then plug the adapter into a standard electrical outlet.

The fountain should start operating immediately, providing a continuous flow of water.

OPERATING INSTRUCTIONS

- **Initial Operation:** After setup, the fountain will begin circulating water once plugged in.
- **Water Level:** Regularly check the water level. Refill the fountain when the water level is low to prevent the pump from running dry, which can shorten its lifespan.
- **Adjusting Flow:** The flower spout can be adjusted or removed to change the water flow. Removing the flower provides a bubbling surface, while the flower creates streams.
- **Placement:** Position the fountain in an easily accessible area for your pet, away from direct sunlight or heat sources.

MAINTENANCE

Regular maintenance is crucial for the longevity of your fountain and the health of your pet.

1. **Daily:** Check water level and refill as needed.
2. **Weekly:**
 - Unplug the fountain.
 - Disassemble all parts (reservoir, flower spout, filter tray, pump).

- Wash the reservoir, flower spout, and filter tray with mild soap and water.
- Clean the pump: Remove the pump cover and impeller. Clean the impeller and the pump's interior with a small brush to remove any hair or debris.
- Rinse all components thoroughly.
- Clean the silicone pad with soap and water.
- Reassemble the fountain.

3. **Filter Replacement:** Replace the filter element every 2-4 weeks, or more frequently if you have multiple pets or if the water appears dirty. Rinse the new filter before installation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not flowing water	No power Low water level Pump clogged	Check power connection and outlet. Refill water to the appropriate level. Clean the pump and impeller thoroughly.
Fountain is noisy	Low water level Pump dirty or obstructed Fountain not on a level surface	Add water. Clean the pump and impeller. Ensure the fountain is on a flat, stable surface.
Water tastes or smells bad	Dirty water or fountain Filter needs replacement	Clean the entire fountain thoroughly. Replace the filter element.

SPECIFICATIONS

- **Brand:** Beacon Pet
- **Model Number:** 43235-164761
- **Capacity:** 1.6 Liters
- **Power Input:** 12V (via included adapter)
- **Main Unit Material:** Plastic (implied by typical fountain construction)
- **Silicone Pad Material:** Silicone
- **Silicone Pad Dimensions:** Approximately 33.6 x 15.6 x 0.08 cm
- **Color:** Green (Silicone Pad), White/Green (Fountain)

WARRANTY AND SUPPORT

For information regarding returns or defective/damaged products, please refer to the retailer's return policy. Typically, products can be returned within 30 days of receipt if you change your mind. For specific details on purchases made through a marketplace, consult the relevant help pages provided by the marketplace.

For further assistance or inquiries, please contact Beacon Pet customer support through the retailer's platform or their official website, if available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question