

[manuals.plus](#) /› [ALIGATOR](#) /› [Aligator A670 Mobile Phone User Manual - Senior-Friendly with SOS Button](#)

## ALIGATOR A670

# Aligator A670 Mobile Phone User Manual

Senior-Friendly Mobile Phone with SOS Button and Locator

## 1. INTRODUCTION

Welcome to the user manual for your Aligator A670 mobile phone. This device is designed for ease of use, particularly for seniors, featuring a large color display, comfortable keys, and essential functions like an SOS button with a locator. Please read this manual carefully to understand how to operate your phone safely and efficiently.

### Key Features:

- 2.2-inch color display with backlight
- Comfortable SOS emergency call button
- VGA Camera
- Large selection keys
- Phonebook with 100 entries
- Up to 7 hours talk time, up to 360 hours standby time
- Flashlight, alarm clock, calculator, FM radio
- Vibration alarm, Bluetooth
- Supports Micro SD memory cards up to 32 GB
- Remote monitoring of phone position (SOS locator)
- Hands-free calling

## 2. SETUP

### 2.1 Package Contents

Before you begin, please ensure all items are present in the package:

- Aligator A670 Mobile Phone
- Travel Charger
- Desktop Charging Station





Image: The Aligator A670 mobile phone securely placed in its desktop charging station, ready for use.

## 2.2 Inserting the SIM Card and Battery

1. **Remove the back cover:** Gently pry open the back cover of the phone.
2. **Insert the SIM card:** Locate the SIM card slot. Insert your GSM SIM card into the designated slot, ensuring the gold contacts face downwards and the cut corner aligns correctly.
3. **Insert the Micro SD card (optional):** If you wish to expand storage, insert a Micro SD card (up to 32 GB) into its dedicated slot.
4. **Insert the battery:** Place the battery into the battery compartment, aligning the contacts.
5. **Replace the back cover:** Securely attach the back cover until it clicks into place.

## 2.3 Charging the Battery

Before first use, fully charge the phone's battery.

- **Using the Travel Charger:** Connect the travel charger to the phone's charging port and plug it into a power outlet.
- **Using the Desktop Charging Station:** Place the phone into the desktop charging station. Ensure the charging station is connected to a power outlet using the travel charger. The phone will indicate when it is charging.

## 2.4 Powering On/Off

- **To Power On:** Press and hold the red **Power/End Call** button until the screen lights up.
- **To Power Off:** Press and hold the red **Power/End Call** button until the power-off options appear, then confirm.

# 3. OPERATING INSTRUCTIONS

---

## 3.1 Making and Receiving Calls

- **To Make a Call:** Dial the number using the keypad and press the green **Call** button.
- **To Answer a Call:** Press the green **Call** button when the phone rings.
- **To End a Call:** Press the red **Power/End Call** button.
- **Hands-free Calling:** The phone supports hands-free operation.

## 3.2 Sending and Receiving SMS Messages

Navigate to the 'Messages' menu to compose new SMS messages or read received ones. Use the large keypad for easy text input.

## 3.3 SOS Emergency Button and Locator

The SOS button is a critical safety feature. In an emergency, press and hold the SOS button located on the back of the phone.

- The phone will automatically dial pre-set emergency contacts.

- It will also send an SMS message with your current location (SOS locator function) to these contacts.
- Ensure emergency contacts are properly configured in the phone settings.



Image: Front and back views of the Aligator A670, showing the large keypad and the prominent SOS button on the rear.

### 3.4 Phonebook

The phonebook can store up to 100 entries. You can add, edit, and delete contacts.

- Navigate to the 'Contacts' or 'Phonebook' menu.
- Select 'Add New Contact' to save a new number.
- Assign contacts to speed dial keys for quick access.

### 3.5 Camera

The Aligator A670 features a VGA camera for basic photo capture.

- Access the camera from the main menu.
- Point the camera at your subject and press the designated button to take a photo.
- Photos are saved to the phone's memory or the inserted Micro SD card.

### 3.6 Additional Functions

- **Flashlight:** Activate the built-in flashlight for illumination in dark environments.
- **FM Radio:** Tune into your favorite FM radio stations. Headphones may be required to act as an antenna.
- **Alarm Clock:** Set multiple alarms for reminders.
- **Calculator:** Perform basic arithmetic calculations.
- **Bluetooth:** Connect to compatible Bluetooth devices such as headsets for hands-free communication.
- **Vibration Alarm:** Enable vibration for incoming calls or messages.
- **Music Files:** The phone supports playback of music files stored on the Micro SD card.

## 4. MAINTENANCE

---

### 4.1 General Care

- Keep the phone dry. Moisture can damage electronic circuits.
- Avoid extreme temperatures. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone. Wipe it with a soft, damp cloth.
- Handle the phone gently. Do not drop, knock, or shake it. Rough handling can break internal circuit boards and fine mechanics.

### 4.2 Battery Care

- Use only approved batteries and chargers.
- Do not short-circuit the battery.
- Do not dispose of batteries in fire.
- Recycle batteries according to local regulations.

## 5. TROUBLESHOOTING

---

If you encounter issues with your Aligator A670, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Phone does not power on	Battery is depleted or not inserted correctly.	Charge the battery. Ensure the battery is correctly inserted.
Cannot make or receive calls	No SIM card, SIM card not inserted correctly, or no network signal.	Ensure SIM card is inserted correctly. Check network coverage. Contact your service provider.
SOS button not working	Emergency contacts not set up or incorrect.	Verify and configure emergency contacts in the phone settings.
Poor sound quality	Low signal strength or speaker/microphone obstruction.	Move to an area with better signal. Clean speaker/microphone openings.
Battery drains quickly	Excessive use, background applications, or old battery.	Reduce screen brightness. Close unused applications. Consider replacing the battery if it's old.

If the problem persists, please contact customer support.

## 6. SPECIFICATIONS

---

Feature	Detail
Brand	ALIGATOR
Model Name	A670
Color	Black
Product Type	Bar Phone
Operating System	No Operating System (Feature Phone)
Screen Size	2.2 Inches
Connectivity	Bluetooth, GSM Mobile Network
Memory Storage Capacity	Supports Micro SD up to 32 GB
Camera Resolution	0.3 MP (VGA)
Battery	1 Lithium-ion (included)
Talk Time	Up to 7 hours
Standby Time	Up to 360 hours
Manufacturer	ADART Computers
Country of Origin	China



Image: Multiple views of the Aligator A670, illustrating its compact design and key features from different angles.

## 7. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact your retailer.

For technical support or further assistance, please visit the manufacturer's website or contact their customer service department.

- **Manufacturer:** ADART Computers
- **Website:** [www.aligator.cz](http://www.aligator.cz)



Image: The product packaging displaying regulatory markings (CE 0700) and supported GSM frequencies (850, 900, 1800, 1900 MHz).

## Related Documents - A670

 S6700 Senior Návod k použití	<p><a href="#"><u>ALIGATOR S6700 Senior User Manual</u></a></p> <p>User manual for the ALIGATOR S6700 Senior mobile phone, covering setup, features like DUAL SIM and SOS Locator, Android OS, connectivity, safety, and ecological disposal.</p>
--	---

 <p>A670 Návod k použití Návod na použitie</p>	<p><a href="#"><b>Návod k použití ALIGATOR A670 – Mobilní telefon s funkcí SOS Locator</b></a></p> <p>Kompletní návod k použití mobilního telefonu ALIGATOR A670. Zjistěte, jak ovládat funkce, nastavit SOS Locator a další.</p>
 <p>A880 GPS Návod k použití Návod na použitie Bedienungsanleitung</p>	<p><a href="#"><b>ALIGATOR A880 GPS Návod k použití</b></a></p> <p>Komplexní návod k použití mobilního telefonu ALIGATOR A880 GPS. Obsahuje informace o nastavení, funkcích jako GPS a SOS Locator, volání, zprávách a bezpečnostních pokynech.</p>
 <p>A930 GPS Senior 4G Návod k použití Návod na použitie Bedienungsanleitung Használati útmutató</p>	<p><a href="#"><b>ALIGATOR A930 GPS Senior 4G: Návod k použití</b></a></p> <p>Kompletní návod k použití pro mobilní telefon ALIGATOR A930 GPS Senior 4G, navržený pro seniory s funkcemi GPS a SOS pro snadné ovládání a bezpečnost.</p>
 <p>D950 DualSIM Návod k použití Návod na použitie Bedienungsanleitung Használati útmutató</p>	<p><a href="#"><b>ALIGATOR D950 DualSIM Návod k použití</b></a></p> <p>Kompletní uživatelský manuál pro mobilní telefon ALIGATOR D950 DualSIM, který poskytuje podrobné pokyny k nastavení, ovládání a využívání funkcí, včetně SOS Locator a SMS ovládání.</p>
 <p>Aligator MiTag lokátor pro Android™ – s podporou Find Hub</p>	<p><a href="#"><b>Aligator MiTag Locator: User Manual, Setup, and Specifications</b></a></p> <p>Comprehensive user manual for the Aligator MiTag locator, detailing setup, operation, battery replacement, technical specifications, and safety guidelines. Compatible with Android devices and Find Hub.</p>