Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DogRook OB3

DogRook Dog Bark Collar Instruction Manual

Smart Collar for Dog Training | No Shock | Beep & Vibration

Introduction Package Contents Product Features Setup Operating Instructions Care & Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

The DogRook Dog Bark Collar is a humane and effective training device designed to help manage excessive barking in dogs. This collar utilizes sound and vibration, without any static shock, to gently deter barking. It is suitable for a wide range of dog sizes, from 12 to 110 lbs, and features smart sensitivity adjustments to detect your dog's unique bark.



Image: The DogRook Dog Bark Collar, showcasing its sleek design with a blue bone-shaped front panel and black adjustable strap.

2. Package Contents

Please ensure all items are present in your package:

- Dog Bark Control Unit
- Adjustable Strap
- USB Charging Cable
- User Guide
- Prong Covers (for long-haired dogs)



Image: A visual representation of all components included in the DogRook Bark Collar package: the collar unit, adjustable strap, USB cable, user guide, and prong covers.

3. Product Features

- **No Shock Training:** Utilizes only beep and vibration to train your dog, ensuring a humane and gentle approach to bark deterrence.
- **Smart Sensitivity Adjustment:** Equipped with a microphone that accurately detects your dog's unique bark, minimizing false triggers from other noises.
- **Customizable Vibration & Sound:** Features 2 distinct vibration modes and 7 progressive sound stages, allowing for tailored training without discomfort.
- **Rechargeable & Waterproof:** Offers up to 14 days of use on a single charge and boasts an IP67 waterproof rating, making it suitable for both indoor and outdoor training environments.
- **Adjustable Fit:** Designed to fit dogs weighing between 12 to 110 lbs, with an adjustable strap up to 22 inches. Includes additional prong covers for dogs with long hair to ensure proper contact.



Image: The DogRook collar with text highlighting its no-shock feature, emphasizing sound and vibration only for training.



Image: The DogRook collar submerged in water, illustrating its IP67 waterproof capability for outdoor use.

4. Getting Started (Setup)

4.1 Charging the Collar

Before first use, fully charge the collar. Connect the provided USB charging cable to the collar's charging port and plug the other end into a USB power source (e.g., USB adapter, power bank, car charger, or laptop). A full charge typically provides up to 14 days of battery life.




Image: The DogRook collar being charged via its USB port, with an indication of 14 days battery life.

4.2 Fitting the Collar

Proper fit is crucial for the collar's effectiveness and your dog's comfort. The collar should be snug but not too tight, allowing two fingers to fit comfortably between the collar and your dog's neck. Ensure the contact points (prongs) are touching your dog's skin. For long-haired dogs, use the included longer prong covers to ensure proper contact.

- Adjust the strap to fit your dog's neck, ensuring it is centered.
- The collar is designed for dogs weighing 12 to 110 lbs and adjusts up to 22 inches.
- If necessary, trim any excess strap length after fitting.



Image: A line of diverse dog breeds, from small to large, all wearing the DogRook collar, demonstrating its adjustable fit for various sizes.

5. Operating Instructions

The DogRook Bark Collar operates automatically once turned on. It detects your dog's bark and responds with a series of progressive corrections (beep and vibration) to deter barking.

5.1 Sensitivity Adjustment

The collar features 5 sensitivity levels to adapt to different environments and your dog's barking volume. Adjust the sensitivity from the lowest setting and gradually increase it until the collar reliably detects your dog's bark without false triggers.

- **Levels 1-3:** Suitable for high noise environments (e.g., dog park, music playing).
- **Levels 3-4:** Ideal for normal noise levels (e.g., watching TV, conversation).
- **Levels 4-5:** Best for low noise environments (e.g., reading, sleeping).



Image: A close-up of the DogRook collar's display, indicating the two vibration modes (regular and strong) and the five sensitivity levels.



Image: A graphic illustrating the five sensitivity levels of the collar and recommended environments for each setting, from high noise to low noise.

5.2 Vibration Modes and Sound Progression

The collar offers two vibration modes: regular and strong. When your dog barks, the collar will emit a beep followed by a vibration. If barking continues, the intensity of the sound and vibration will progressively increase through 7 stages. If your dog stops barking for 1 minute, the collar resets to the lowest stage.




Image: A detailed diagram explaining the two vibration modes (regular and strong) and the automatic sound progression through multiple steps when barking persists.

5.3 Training Tip

To enhance training, say "NO!" loud and clear every time your dog barks and the collar activates. This helps your dog associate the command with the collar's response and the undesirable behavior.

6. Care & Maintenance

- **Cleaning:** The collar can be hand washed. Ensure the electronic unit is dry before charging or prolonged storage.
- **Regular Inspection:** Periodically check the collar for any signs of wear or damage. Ensure the contact points are clean and free of debris.
- **Charging:** Recharge the collar regularly to maintain optimal performance. Avoid completely draining the battery for extended periods.
- **Storage:** Store the collar in a cool, dry place when not in use.

7. Troubleshooting

Problem	Possible Cause	Solution
Collar not activating when dog barks.	Collar is off; battery is low; sensitivity setting is too low; improper fit.	Ensure collar is turned on. Charge the battery. Increase sensitivity level. Adjust collar fit to ensure contact points touch skin.
Collar activates without dog barking (false triggers).	Sensitivity setting is too high; external loud noises.	Decrease sensitivity level. Ensure collar is not exposed to excessive external noise.
Battery life is shorter than expected.	Frequent activation; extreme temperatures; aging battery.	Ensure proper sensitivity to avoid unnecessary activations. Avoid leaving collar in extreme temperatures.
Dog continues to bark despite collar activation.	Dog is accustomed to the stimulation; collar not fitted correctly; underlying behavioral issues.	Ensure proper fit and contact. Try a different vibration mode or increase sensitivity. Consult a professional dog trainer for persistent issues.

8. Specifications

Feature	Detail
Model Number	OB3
Item Weight	3.2 ounces
Dimensions (LxWxH)	2.8 x 1 x 0.04 inches
Battery Type	Rechargeable (2 AAA batteries included)
Battery Life	Up to 14 days
Material	Nylon
Waterproof Rating	IP67
Target Audience	Dogs (12-110 lbs)
Correction Method	Beep & Vibration (No Shock)
Sensitivity Levels	5
Vibration Modes	2 (Regular, Strong)
Sound Stages	7 (Progressive)

9. Warranty & Support

For any questions, concerns, or warranty claims regarding your DogRook Dog Bark Collar, please contact DogRook customer support directly. Refer to the contact information provided on the product packaging or the official DogRook website for assistance.
You can also visit the official DogRook Store on Amazon for more information and support:**DogRook Store**

© 2025 DogRook. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072DS462V

More documents and user manuals: **https://manuals.plus/**