

[Manuals.plus](#) /

› [Philips](#) /

› Philips PowerPro FC9352/01 Compact Bagless Vacuum Cleaner User Manual

Philips FC9352/01

Philips PowerPro FC9352/01 Compact Bagless Vacuum Cleaner

User Manual

Model: FC9352/01 | Brand: Philips

1. INTRODUCTION

Thank you for choosing the Philips PowerPro FC9352/01 Compact Bagless Vacuum Cleaner. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.



Image 1: Philips PowerPro FC9352/01 Compact Bagless Vacuum Cleaner with hose and nozzle.

Product Overview Video

Your browser does not support the video tag.

Video 1: An overview of the Philips PowerPro FC9352/01 Vacuum Cleaner, highlighting its features and design.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Do not use the appliance if the cord or plug is damaged.
- Do not use the appliance to pick up water or other liquids, hot ashes, or sharp objects.
- Ensure the dust container and filters are correctly installed before use.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Unplug the appliance before cleaning or performing maintenance.

3. PRODUCT COMPONENTS

Your Philips PowerPro FC9352/01 package includes the following items:

- Vacuum Cleaner Unit
- MultiClean Nozzle
- Integrated Brush Tool
- Telescopic Tube
- Hose
- User Manual
- Warranty Card

Key Features:

- **1900-Watt Durable Motor:** Generates up to 370W of high suction power for thorough cleaning.
- **PowerCyclone 5 Technology:** Accelerates airflow to separate dust from air, maintaining high performance.
- **MultiClean Nozzle:** Designed to seal closely to the floor for thorough cleaning across all floor types.
- **Hygienic Dust Disposal:** Easy-to-empty dust container for minimal dust cloud.
- **Compact and Lightweight Design:** Easy to store and carry.
- **Integrated Brush:** Dusting brush tool built into the handle for convenience.
- **Allergy H13 Filter:** Fully-sealed filtration system captures >99.9% of fine dust particles.
- **ActiveLock Couplings:** Allow attachments to easily fit with a simple snap.
- **Turbo Brush:** Designed for optimal cleaning of pet hair and fluff.

4. SETUP

1. **Attach the Hose:** Insert the hose into the air inlet opening on the main unit until it clicks into place.
2. **Assemble the Telescopic Tube:** Connect the telescopic tube to the hose handle. Adjust the length of the tube by pressing the release button and sliding it to your desired height.
3. **Attach the Nozzle:** Connect the MultiClean Nozzle or other desired attachment to the end of the telescopic tube using the ActiveLock couplings. Ensure it snaps securely into place.
4. **Check Dust Container:** Ensure the 1.5L dust canister is properly inserted and locked into the vacuum cleaner unit.
5. **Power Connection:** Extend the power cord and plug it into a suitable 16A power outlet.



Floor Cleaning



Sofa Surface Cleaning



Carpet Cleaning



Small Corner Cleaning



Wide range of applications

Image 2: Demonstrates the wide range of applications for the vacuum cleaner, including floor, sofa, carpet, and small corner cleaning.

5. OPERATING INSTRUCTIONS

1. **Power On:** Press the power button located on the main unit to start the vacuum cleaner.
2. **Adjust Suction Power:** The vacuum cleaner features powerful suction. Adjust as needed for different surfaces.
3. **Cleaning Surfaces:**
 - For hard floors and carpets, use the MultiClean Nozzle.
 - For furniture, flat surfaces, and upholstery, detach the nozzle and use the integrated brush tool.
 - For pet hair and deep carpet cleaning, attach the Turbo Brush nozzle (if included).
4. **Maneuvering:** The compact and lightweight design, along with large rubber wheels, allows for easy movement around your home. The 6-meter cord provides wide coverage.
5. **Power Off:** Press the power button again to turn off the appliance.

6. **Cord Rewind:** Press the cord rewind button to automatically retract the power cord.



For Powerful consistent suction of
370 air watts (29kPA)

Image 3: A woman demonstrating the use of the Philips PowerPro FC9352/01 on a carpet, highlighting the 1900W durable motor and PowerCyclone 5 technology.

Automatic
cord winder



Wide coverage
with 6m cord length

Image 4: Illustrates the automatic cord winder and wide coverage provided by the 6-meter cord length.

Detailed Product Features Video

Your browser does not support the video tag.

Video 2: A detailed demonstration of the FC9352/01 vacuum cleaner's features, including PowerCyclone 5 technology, H13 filter, and one-hand emptying.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dust Container:

The 1.5-liter dust container is designed for hygienic disposal. When the dust level reaches the MAX indicator, or suction power decreases, it's time to empty it.

1. Switch off and unplug the vacuum cleaner.

2. Press the release button to detach the dust container from the main unit.
3. Hold the container over a dustbin and press the release button on the bottom to open the lid and empty the contents. This can be done with one hand to minimize dust clouds.
4. Close the lid and reattach the dust container to the vacuum cleaner until it clicks into place.



Removable 1.5L dust canister

Image 5: Shows the removable 1.5L dust canister being hygienically emptied with one hand.

Cleaning the Filters:

The Allergy H13 filter system captures over 99.9% of fine dust. Regular cleaning of filters is crucial for maintaining suction power and air quality.

1. Switch off and unplug the vacuum cleaner.
2. Locate the filter compartment (usually at the back or side of the unit).
3. Remove the Allergy H13 filter and the washable foam filter.
4. Tap the H13 filter gently to remove loose dust. Do not wash this filter.
5. Wash the foam filter under lukewarm running water. Do not use soap or detergent.

6. Allow the foam filter to air dry completely for at least 24 hours before reinserting. Ensure it is completely dry to prevent damage to the motor.
7. Reinsert the dry filters and close the filter compartment.



Image 6: Close-up of the Allergy H13 filter system, which captures >99.9% of fine dust.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not switch on.	Not plugged in; power outlet faulty; power button not pressed.	Check power cord connection; try another outlet; press power button firmly.
Low suction power.	Dust container full; filters clogged; hose/tube/nozzle blocked.	Empty dust container; clean/replace filters; remove any blockages.

Problem	Possible Cause	Solution
Unusual noise during operation.	Blockage in hose/nozzle; motor filter not properly installed.	Check for and remove blockages; ensure motor filter is correctly seated.
Dust escaping from the appliance.	Dust container not properly closed; filters not correctly installed or damaged.	Ensure dust container is securely closed; check and correctly install filters; replace damaged filters.

If the problem persists after trying these solutions, please contact Philips customer support.

8. SPECIFICATIONS

- **Model:** FC9352/01
- **Brand:** Philips
- **Wattage:** 1900 Watts (Motor), 370 Watts (Suction)
- **Dust Capacity:** 1.5 Litres
- **Filter Type:** Allergy H13 Filter (Cloth)
- **Special Features:** Wheel, Lightweight, Compact, Bagless
- **Cord Length:** 6 meters
- **Product Dimensions:** 4.1L x 2.81W x 2.47H Meters
- **Item Weight:** 6 kg 980 g
- **Noise Level:** 5 Sones
- **Country of Origin:** China

9. WARRANTY AND SUPPORT

Your Philips PowerPro FC9352/01 Compact Bagless Vacuum Cleaner comes with a **2-year warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, technical support, or service requests, please contact Philips customer service at **1800 102 2929** (India) or refer to the official Philips website for your region.

A 10-day return/replacement policy is available for damaged or defective products, subject to terms and conditions. For further information, including EMI options and delivery details, please refer to the product detail page on Amazon.in.