

[Manuals.plus](#) /

> [Anne Klein](#) /

> Anne Klein Women's Premium Crystal Accented Open Bracelet Watch AK/3121MPTT User Manual

Anne Klein AK/3121MPTT

Anne Klein Women's Premium Crystal Accented Open Bracelet Watch

Model: AK/3121MPTT

INTRODUCTION

Thank you for choosing the Anne Klein Women's Premium Crystal Accented Open Bracelet Watch. This timepiece combines elegant design with reliable Japanese quartz movement. This manual provides essential information for the proper setup, operation, and care of your watch to ensure its longevity and accurate performance.



Front view of the Anne Klein Women's Premium Crystal Accented Open Bracelet Watch, showcasing the two-tone design and crystal accents.

SETUP

Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) outwards to the time-setting position.
2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position. This will start the watch movement.





Side view of the watch, highlighting the crown used for time adjustment.

Bracelet Adjustment

The watch features an open adjustable link bracelet with a jewelry clasp. For optimal comfort and fit, the bracelet may require adjustment by adding or removing links. It is recommended to have this adjustment performed by a professional jeweler to prevent damage to the watch or bracelet.

OPERATING YOUR WATCH

Your Anne Klein watch is powered by a reliable Japanese quartz movement, ensuring accurate timekeeping. Once the time is set and the crown is pushed in, the watch will operate continuously. The watch displays hours, minutes, and seconds.

For daily wear, ensure the watch is securely fastened with the jewelry clasp. Avoid exposing the watch to extreme temperatures or strong magnetic fields, as these can affect its accuracy.

MAINTENANCE AND CARE

Cleaning

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For more thorough cleaning, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and crystal.

Water Resistance

Important: This watch is **Not Water Resistant**. Avoid all contact with water, including showering, swimming, or exposure to rain. Water exposure can cause severe damage to the internal movement and will void the warranty.

Battery Replacement

The watch uses one LR44 battery (included). When the watch stops running, it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and to prevent damage to the movement. Attempting to replace the battery yourself may void the warranty.





Back view of the watch case, showing the manufacturer's markings.

- **Watch not running:**
 - Ensure the crown is fully pushed in.
 - The battery may need replacement. Refer to the "Battery Replacement" section.
- **Time is inaccurate:**
 - Check if the crown is fully pushed in.
 - The battery may be low, affecting accuracy.
 - Avoid strong magnetic fields, which can temporarily affect quartz movement accuracy.
- **Bracelet discomfort or clasp issues:**
 - Ensure the jewelry clasp is properly engaged.
 - If the bracelet is too tight or too loose, consider professional adjustment.

If problems persist, please contact the seller or a qualified watch repair service.

SPECIFICATIONS

Brand	Anne Klein
Model Number	AK/3121MPTT
Product Dimensions	5 x 5 x 0.71 inches
Item Weight	4.8 ounces
Case Diameter	22.5 Millimeters
Case Thickness	8 Millimeters
Band Width	8 Millimeters
Band Material Type	Metal
Band Color	Two Tone
Dial Color	Mother-of-pearl
Crystal	Mineral
Watch Movement Type	Japanese Quartz
Display Type	Analog
Clasp Type	Jewelry Clasp
Water Resistance Level	Not Water Resistant
Batteries	1 LR44 battery (included)

PRODUCT VIDEO DEMONSTRATION

Your browser does not support the video tag.

This video provides a visual overview of the Anne Klein Women's Crystal Accented Two-Tone Open Bracelet Watch, demonstrating its design and features.

WARRANTY AND SUPPORT

For warranty information and support, please refer to the documentation included with your purchase or contact the seller of record directly. The warranty type is generally "Contact seller of record". Keep your proof of purchase for any warranty claims.

For further assistance or inquiries, please visit the official Anne Klein website or contact their customer service department.

Note: Unauthorized repairs or modifications may void your warranty.