

Briloner 7265000

Briloner 7265000 Remote Control User Manual

Model: 7265000

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Briloner 7265000 Remote Control. Please read this manual thoroughly before operating the device and retain it for future reference.

2. PRODUCT OVERVIEW

The Briloner 7265000 is a remote control designed for compatible Briloner lighting products. It features a compact design with clearly labeled buttons for various functions.




Figure 1: Front view of the Briloner 7265000 Remote Control, showing its ergonomic design and button layout.

The remote control typically includes buttons for power on/off, dimming, color temperature adjustment, and potentially pre-set scene selections, depending on the connected lighting fixture.

3. SETUP

3.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or gently pry open the cover.
3. Insert the required batteries (e.g., 2x AAA, not included) according to the polarity indicators (+ and -) inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

3.2. Pairing with a Device

The Briloner 7265000 Remote Control is designed to operate specific Briloner lighting products. The pairing process may vary depending on the lighting fixture. Refer to the instruction manual of your Briloner lighting product for specific pairing instructions. Generally, pairing involves:

- Ensuring the lighting fixture is powered on.
- Pressing a specific button combination on the remote control or a pairing button on the lighting fixture within a short timeframe.
- Confirmation of successful pairing (e.g., light blinking).

4. OPERATING INSTRUCTIONS

Once paired, the remote control allows you to manage your Briloner lighting product. The functions typically include:

- **Power On/Off:** Press the **ON/OFF** button to turn the light on or off.
- **Dimming:** Use the **+** and **-** buttons (or dedicated dimming buttons) to increase or decrease light brightness.
- **Color Temperature Adjustment:** If supported, use the **Warm** and **Cool** buttons (or similar) to adjust the light's color temperature from warm white to cool white.
- **Scene Selection:** Some remotes may have pre-set scene buttons (e.g., "Reading," "Relax," "Night Light") for quick access to specific lighting configurations.

Point the remote control directly towards the Briloner lighting product for optimal signal transmission. Ensure there are no obstructions between the remote and the receiver.

5. MAINTENANCE

5.1. Cleaning

To clean the remote control, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or wet cloths, as these can damage the surface or internal components.

5.2. Battery Replacement

Replace batteries when the remote control's range decreases or it becomes unresponsive. Follow the battery installation steps outlined in Section 3.1. Always dispose of used batteries responsibly according to local regulations.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not responding.	• Dead or incorrectly inserted batteries. • Remote not paired with the device. • Obstruction between remote and device. • Remote out of range.	• Check and replace batteries. Ensure correct polarity. • Re-pair the remote control with the lighting fixture (refer to Section 3.2). • Remove any objects blocking the signal path. • Move closer to the lighting fixture.
Short operating range.	• Weak batteries. • Interference from other electronic devices.	• Replace batteries. • Move the remote or the lighting fixture away from potential sources of interference.

7. SPECIFICATIONS

- **Model:** Briloner 7265000
- **Brand:** Briloner
- **Manufacturer:** Briloner Leuchten
- **ASIN:** B072JC8S6Y
- **Power Source:** Batteries (e.g., 2x AAA, not included)
- **Compatibility:** Designed for compatible Briloner lighting products.

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Briloner 7265000 Remote Control, please refer to the documentation provided with your Briloner lighting product or visit the official Briloner website. You may also contact Briloner customer service directly for assistance.

Note: Specific warranty terms and support contact details may vary by region and product.

© 2023 Briloner. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question