

[Manuals.plus](#) /

› [WALI](#) /

› WALI Tilt TV Wall Mount Bracket (TTM-1) Instruction Manual

WALI TTM-1

WALI Tilt TV Wall Mount Bracket

MODEL: TTM-1

For Most 32-70 inch LED, LCD, OLED Flat Screen TVs

PRODUCT OVERVIEW

The WALI Tilt TV Wall Mount Bracket (TTM-1) provides a secure and space-saving solution for mounting your flat screen television. This mount is designed for TVs ranging from 32 to 70 inches, with a maximum load capacity of 99 lbs (45 kg). It supports various VESA mounting patterns from 100x100mm up to 400x400mm. Its low-profile design keeps your TV close to the wall, while the 8-degree tilting capability allows for optimal viewing angles.



Image: Front view of the WALI Tilt TV Wall Mount Bracket (TTM-1).

KEY FEATURES

- **Compatibility:** Supports most 32-70 inch flat screen TVs with VESA mounting patterns from 100x100mm to 400x400mm. Maximum TV load capacity is 99 lbs (45 kg).
- **Tilting Capability:** Effortless 8-degree tilting for improved viewing flexibility and glare reduction.
- **Space-Saving Design:** Retracts to a low profile of 0.79 inches from the wall.

- **Easy Installation:** Wall plate can be mounted on 16-inch wood studs, brick, or concrete walls.
- **Quick Release:** Features quick-release pull straps for easy TV removal.

COMPATIBILITY DETAILS

Ensure your television meets the following criteria for proper fit and function with the WALI TTM-1 mount:

- **Screen Size:** Compatible with TVs from 32 to 70 inches.
- **Weight Capacity:** Your TV must weigh no more than 99 lbs (45 kg).
- **VESA Pattern:** The mount supports VESA patterns including 100x100mm, 200x100mm, 200x200mm, 300x300mm, 400x200mm, and 400x400mm.



Image: Diagram illustrating display compatibility with maximum weight, VESA size, and screen size.

Minimum Depth From Wall: 0.79"



Image: Visual representation of available VESA mounting patterns supported by the mount.

SETUP & INSTALLATION

Before You Begin

Carefully read all instructions before beginning installation. If you have any doubts about the installation process, consult a qualified professional. Ensure you have all parts and tools listed below. Do not mount on drywall alone.

Package Contents

- 1 x WALI Tilting TV Wall Mount (Black)
- 1 x 6 ft HDMI Cable
- 1 x Bubble Level
- 1 x Mounting Hardware Kit

- 1 x User Manual

Tools Required (Not Included)

- Pencil
- Tape Measure
- Stud Finder (for wood stud installation)
- Drill
- Phillips Head Screwdriver
- Socket Wrench

Mounting the Wall Plate

Important: The wall plate must be mounted on vertical 16-inch wood studs, brick, or concrete walls. **DO NOT mount on drywall alone.**

1. Determine the desired height for your TV.
2. Use a stud finder to locate the center of two adjacent wood studs. Mark the drilling points. For brick or concrete, mark the desired drilling points ensuring they are level.
3. Drill pilot holes at the marked locations. For wood studs, use a 7/32 inch (5.5mm) drill bit. For brick/concrete, use a 3/8 inch (10mm) masonry drill bit and insert concrete anchors.
4. Attach the wall plate to the wall using the provided lag bolts and washers. Tighten securely.

Wood stud installation



Image: Diagram showing proper wood stud installation for the wall mount.



Image: Step-by-step illustration of mounting the wall bracket to the wall using the provided hardware.

Attaching Brackets to TV

1. Carefully place your TV face down on a soft, clean surface.
2. Identify the correct screws (M4, M5, M6, M8) and spacers from the hardware kit that fit your TV's mounting holes.
3. Attach the two vertical TV brackets to the back of your TV using the selected screws and spacers. Ensure the hooks on the brackets are facing upwards and the quick-release straps are at the bottom.



Image: Illustration demonstrating how to attach the mounting brackets to the back of the television.

Mounting TV to Wall Plate

1. With assistance, carefully lift the TV and hook the TV brackets onto the wall plate.
2. Ensure the TV is centered and level.
3. Pull the quick-release straps downwards to unlock the safety mechanism. Push the bottom of the TV towards the wall until the safety locks engage with an audible click.
4. Tuck the quick-release straps behind the TV for a clean look.



Image: A television securely mounted on a wall using the WALI mount, shown in a living room environment.

Installation Video Guide

Your browser does not support the video tag.

Video: An official installation guide for the WALI Tilt TV Wall Mount Bracket (TTM-1), demonstrating the setup process from start to finish.

OPERATING INSTRUCTIONS

Tilt Adjustment

The WALI TTM-1 mount allows for an 8-degree downward tilt to optimize your viewing experience and reduce glare from lights or windows. To adjust the tilt, simply grasp the top or bottom edge of your TV and gently push or pull to achieve the desired angle. The mount will hold its position once adjusted.

Angle Adjustment

Tilt Down 8°



Image: A television mounted on a wall, illustrating the 8-degree downward tilt capability of the mount.

Quick Release Mechanism

To safely remove your TV from the wall mount, locate the quick-release pull straps at the bottom of the TV brackets. Pull both straps downwards simultaneously to disengage the safety locks. With assistance, carefully lift the TV off the wall plate.

MAINTENANCE

To ensure the longevity and safe operation of your WALI TV wall mount, perform the following maintenance:

- **Cleaning:** Dust the mount regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild detergent, then wipe dry. Avoid abrasive cleaners or solvents.
- **Periodic Checks:** Every 6-12 months, check all screws and bolts to ensure they are securely tightened. Verify that the TV remains level and stable on the mount.

- **Inspect for Damage:** Periodically inspect the mount for any signs of wear, corrosion, or damage. If any issues are found, contact customer support.

TROUBLESHOOTING

TV is not level after installation

- Ensure the wall plate was installed perfectly level. Use the included bubble level or a separate level during installation.
- Check that the TV brackets are securely and evenly attached to the back of the TV.

Difficulty attaching TV to wall plate

- Verify that the TV brackets are correctly oriented with the hooks facing upwards.
- Ensure there are no obstructions between the TV brackets and the wall plate.
- Confirm that the quick-release straps are pulled down to unlock the safety mechanism before attempting to hang the TV.

TV feels unstable on the mount

- Double-check that all wall plate lag bolts are securely fastened into the studs or concrete anchors.
- Ensure the TV's weight does not exceed the mount's maximum capacity (99 lbs / 45 kg).
- Confirm that the safety locks on the TV brackets have engaged properly after hanging the TV.

SPECIFICATIONS

Attribute	Value
Brand Name	WALI
Item Model Number	TTM-1
Item Weight	2.25 pounds
Product Dimensions	17.8 x 9 x 1.57 inches
Color	Black
Material	Metal
Mounting Type	Wall Mount
Movement Type	Fixed (with tilt)
Minimum Compatible Size	32 Inches
Maximum Compatible Size	70 Inches

Maximum Tilt Angle	8 Degrees
Compatible Devices	Television

WARRANTY & SUPPORT

WALI provides a 10-year protection for this product. For any questions, concerns, or assistance with installation or troubleshooting, please contact WALI's experienced and friendly US-based customer support team, available to assist 7 days a week.

You can also visit the official WALI store for more information and products:[WALI Store on Amazon](#)

© 2025 WALI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question