Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj MTBX 2016

Bajaj MTBX 2016 20L Grill Microwave Oven User Manual

Model: MTBX 2016

1. Introduction

This manual provides essential instructions for the safe and efficient operation of your Bajaj MTBX 2016 20L Grill Microwave Oven. Please read this manual thoroughly before using the appliance and retain it for future reference.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy when using your appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not use metal utensils or plates inside the microwave oven. Metal can cause arcing and damage the oven.
- Ensure the appliance is properly grounded.
- Do not operate the oven if the door is damaged, or if the seals are broken.
- Do not attempt to service or repair the oven yourself. Contact qualified service personnel.
- Supervise children closely when the appliance is in use.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Clean the oven regularly and remove any food deposits.

3. Product Components and Features

The Bajaj MTBX 2016 is a 20L Grill Microwave Oven designed for various cooking needs. Key features include:

- **20L Capacity:** Suitable for bachelors or small families.
- **Grill Function:** Allows for grilling in addition to reheating, defrosting, and cooking.
- **Jog Dials:** Easy-to-use controls with a long operational life.
- **Combination Cooking:** Combines microwave and grill functions for versatile cooking.
- **30 Minutes Cooking Time Alarm:** Provides an audible alert when the set cooking time is complete.
- **Defrost System:** Efficient defrosting capabilities.



Figure 3.1: Front view of the Bajaj MTBX 2016 Microwave Oven.



Figure 3.2: Summary of key features including Defrost Mode, Microwave & Grilling Functions, 20L Capacity, Cooking Time Alarm, and 1 Year Warranty.

4. Setup and Installation

1. **Unpacking:** Carefully remove the microwave oven and all packing materials from the carton.
2. **Placement:** Place the oven on a flat, stable surface that can support its weight. Ensure there is adequate ventilation space around the oven (at least 10 cm at the back, 15 cm on top, and 5 cm on the sides).
3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the appliance's requirements (230 Volts).
4. **Initial Cleaning:** Wipe the interior and exterior of the oven with a soft, damp cloth before first use.



Figure 4.1: Product dimensions for proper placement: approximately 45.2 cm width, 26.2 cm height, 35 cm depth.

5. Operating Instructions

The Bajaj MTBX 2016 features two jog dials for controlling power level and cooking time.



Figure 5.1: Control panel with Power and Time jog dials.

5.1. Power Level Selection

The upper jog dial controls the power level. Rotate it to select the desired cooking mode:

- **Low:** For softening ice cream, simmering.
- **Med (Medium):** For stewing, slow cooking.
- **Defrost:** For thawing frozen foods.
- **M.High (Medium-High):** For general cooking.
- **High:** For fast cooking, boiling liquids.
- **Grill:** For grilling food items.

- **Combi1, Combi2, Combi3:** Combination cooking modes (Microwave + Grill). Refer to specific recipes for optimal use of each combination.



Figure 5.2: Defrost mode for quick heating and thawing.

5.2. Setting Cooking Time

The lower jog dial sets the cooking time, up to 30 minutes. Rotate the dial clockwise to increase the time. The oven will start operating once the time is set. An alarm will sound when the cooking time is complete.



Figure 5.3: The 30-minute cooking time alarm ensures precise cooking.

5.3. General Operation Steps

1. Place food in a microwave-safe container (non-metallic for microwave modes).
2. Open the oven door, place the container inside, and close the door securely.
3. Rotate the upper jog dial to select the desired power level or cooking mode (Microwave, Grill, or Combination).
4. Rotate the lower jog dial to set the cooking time. The oven will begin operation.
5. When cooking is complete, the oven will sound an alarm. Carefully remove the food.

6. Maintenance and Cleaning

Regular cleaning helps maintain the performance and longevity of your microwave oven.

- **Interior Cleaning:** Wipe the interior cavity, door seals, and turntable with a damp cloth after each use. For stubborn stains, use a mild detergent.

- **Exterior Cleaning:** Clean the exterior surface with a soft, damp cloth. Avoid abrasive cleaners.
- **Turntable:** The glass turntable can be removed for cleaning and is dishwasher safe.
- **Odor Removal:** To remove odors, combine a cup of water with the juice of one lemon in a microwave-safe bowl and microwave on high for 5 minutes.
- **Always unplug the oven before cleaning.**

7. Troubleshooting Guide

If you encounter issues with your microwave oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close the door firmly; Check household fuse/circuit breaker.
Food not heating	Incorrect power level or cooking time set; Door not closed properly; Metal utensils used.	Adjust power level and time; Ensure door is fully closed; Remove any metal objects.
Sparking inside oven	Metal or foil in the oven; Food residue on cavity walls.	Remove all metal objects; Clean the oven interior thoroughly.
Unusual noise during operation	Turntable not correctly positioned; Food container too large.	Ensure turntable is seated properly; Use appropriate size cookware.

If the problem persists after attempting these solutions, please contact customer support.

8. Product Specifications

Feature	Specification
Brand	Bajaj
Model	MTBX 2016
Capacity	20 Litres
Installation Type	Countertop
Oven Cooking Mode	Grill, Microwave
Colour	Black
Voltage	230 Volts
Wattage	800 Watts
Defrost System	Defrost
Material	Powder Coated Iron
Item Weight	11 kg 300 g

Feature	Specification
Item Dimensions (Width x Height x Depth)	Approximately 45.2 cm x 26.2 cm x 35 cm
Included Components	Microwave oven, Warranty Card, User Manual

9. Warranty and Support

Your Bajaj MTBX 2016 Grill Microwave Oven comes with a**1-year warranty on the product** from the date of purchase. For warranty claims, technical support, or service inquiries, please contact Bajaj customer service. Refer to the warranty card included with your product for contact details and terms and conditions.

Manufacturer: Bajaj Electricals Ltd

Importer & Packer: Imported and Marketed by Bajaj Electricals Ltd 45/47, Veer Nariman Road, Mumbai, 400001

© 2025 Bajaj Electricals Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072KZ373J

More documents and user manuals: **https://manuals.plus/**