

Tiny Love TO027

Tiny Love Meadow Days Baby Mobile

Model: TO027

Brand: Tiny Love

INTRODUCTION

The Tiny Love Meadow Days Baby Mobile is designed to provide engaging visual and auditory stimulation for your baby, promoting development both at home and on the go. This versatile mobile features a portable design, allowing it to be easily attached to various baby gear.

KEY FEATURES

- Easy Portability:** Designed to clip easily onto cribs, carriers, strollers, and bassinets.
- Engaging Melodies:** Offers 30 minutes of continuous music with five different melodies to soothe and entertain.
- Visual Stimulation:** Features spinning toys with bright colors that encourage visual tracking and interaction.
- Child Development:** Supports the development of motor skills, communication, and language through interactive play.
- Versatile Attachment:** The mobile arm is designed for convenient attachment to a wide range of baby equipment.

PRODUCT COMPONENTS

The Tiny Love Meadow Days Baby Mobile includes the main mobile unit with a music box, an adjustable attachment arm, and three hanging character toys (fox, hedgehog, and bird).



Image: The Tiny Love Meadow Days Baby Mobile, showcasing its main unit and three hanging characters.

SETUP AND INSTALLATION

1. Battery Installation

1. Locate the battery compartment on the main mobile unit.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 3 AA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

2. Attaching the Mobile

The mobile features a versatile clip-on attachment system suitable for various baby gear.

1. **To Cribs/Bassinets:** Position the mobile's clamp onto the rail of the crib or bassinet. Ensure the clamp is securely fastened and the mobile is stable before use.

Image: Close-up of the mobile's clamp mechanism securely attached to a crib rail.

To Strollers: Attach the mobile's clamp to the stroller's canopy or handle bar, ensuring it is out of the baby's reach but visible.



Image: The mobile attached to a stroller, providing entertainment for a baby.

To Car Seats/Carriers: Secure the mobile to the car seat handle or canopy. Always ensure it does not obstruct the baby's view or interfere with safety harnesses.



Image: The mobile attached to a car seat, positioned for a baby's view.

To Play Yards: Attach the mobile to the top rail of the play yard, ensuring it is firmly secured and the baby cannot pull it down.



Image: The mobile attached to a play yard, providing visual engagement for a baby.

Always ensure the mobile is securely attached and out of the baby's reach when they are able to push up on their hands and knees.

OPERATING INSTRUCTIONS

Powering On/Off and Music Selection

- Locate the power button and music selection switch on the main mobile unit.
- Press the power button to turn the mobile on. The characters will begin to spin, and music will play.
- The mobile features 30 minutes of continuous music with five different melodies. The melodies will cycle automatically.
- To turn off the mobile, press the power button again.




Image: A detailed view of the mobile's main unit, showing the control buttons.

CARE AND MAINTENANCE

- Cleaning:** Wipe the mobile unit and plastic parts with a damp cloth and mild soap. Do not immerse the electronic unit in water.
- Fabric Toys:** The hanging fabric toys can be surface cleaned with a damp cloth. Do not machine wash.
- Storage:** When not in use, store the mobile in a clean, dry place away from direct sunlight.
- Battery Replacement:** Replace batteries when the music becomes distorted or the spinning slows down. Always use new batteries of the same type.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mobile does not turn on or music/spinning is weak.	Low or dead batteries; incorrect battery installation.	Replace with new AA batteries, ensuring correct polarity.
Mobile clamp slips or falls from attachment point.	Clamp not tightened sufficiently; surface too smooth or thin.	Ensure the clamp is fully tightened. If the surface is too smooth, consider adding a non-slip material (e.g., rubber pad) between the clamp and the surface. Ensure the attachment point is within the clamp's recommended thickness.
Low motor sound during operation.	Normal operational sound; internal mechanism friction.	A slight motor sound is normal during operation. If the sound is excessively loud or grinding, ensure no foreign objects are obstructing the spinning mechanism. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	TO027
Dimensions (L x W x H)	4 x 7.5 x 13.38 inches
Item Weight	12 ounces (approx. 340 Grams)
Material Type	Plastic, Polyester
Batteries Required	3 AA batteries
Target Gender	Unisex
Mounting Type	Crib Mount (versatile clip-on)
Music Duration	30 minutes continuous play
Number of Melodies	5

SAFETY INFORMATION

- **WARNING:** Possible entanglement injury. Keep the mobile out of the baby's reach. Remove the mobile from the crib or playpen when the baby begins to push up on hands and knees or is able to sit up unassisted.
- Adult assembly required.
- Do not attach the mobile to a crib or playpen with mesh sides.
- Never leave a child unattended with the mobile.
- Dispose of batteries properly. Do not mix old and new batteries or different types of batteries.
- Inspect the mobile regularly for any signs of damage or wear. Discontinue use if any part is broken or missing.

OFFICIAL PRODUCT VIDEOS

Based on available information, there are no official seller-created product videos for embedding at this time.

WARRANTY AND SUPPORT


For detailed warranty information and customer support, please refer to the official Tiny Love website or the user manual PDF.

- Official User Manual (PDF): [Download Here](#)
- Visit the Tiny Love Store: [Tiny Love Store on Amazon](#)

Related Documents

	<p><u>Tiny Love Tiny Friends Lullaby Mobile User Manual</u></p> <p>User manual for the Tiny Love Tiny Friends Lullaby Mobile (Model TO009), providing instructions for assembly, battery installation, care, safety warnings, and FCC compliance information. Includes detailed steps and descriptions of diagrams.</p>
	<p><u>Tiny Love Tummy Time Mobile Entertainer - Instruction Manual</u></p> <p>Instruction guide for the Tiny Love Tummy Time Mobile Entertainer, covering operation, safety, and care. Includes model numbers and brand information.</p>
	<p><u>Tiny Love Boho Chic Luxe Musical Mobile User Guide</u></p> <p>Comprehensive user guide for the Tiny Love Boho Chic Luxe Musical Mobile, detailing features, operation, safety warnings, and maintenance instructions in multiple languages.</p>
	<p><u>Tiny Love Luxe Musical Mobile - Instruction Guide</u></p> <p>Instruction guide for the Tiny Love Luxe Musical Mobile (Model 130710E001), detailing safety warnings, usage instructions, battery requirements, product features, and care instructions.</p>


Documents - Tiny Love – TO027



[\[pdf\] Instructions Guide Catalog](#)

Take Along MobileTM 321 instructions 3 tinylove media catalog product |||

Take-Along MobileTM Meadow DaysTM 130490E001, **TO027** Tiny Princess TalesTM 130550E001, TO060 Magical TalesTM 130590E001, TO075 Treasure the OceanTM 130700E001, TO1210700 Black White Dcor 130810E001, TO153HBF0400 English Take-Along MobileTM A Instruction Guide Read all instructions before use. K...
lang:en **score:27** filesize: 2.01 M page_count: 2 document date: 2023-08-09



[\[pdf\] Instructions Guide](#)

Untitled Take Along MobileTM Mobile E3055IS658 0F web tinylove 2025 01 |||

Take-Along MobileTM Meadow DaysTM 130490E001, **TO027** Tiny Princess TalesTM 130550E001, TO060 Magical TalesTM 130590E001, TO075 Treasure the OceanTM 130700E001, TO1210700 Black White Dcor 130810E001, TO153HBF0400 English Take-Along MobileTM A Instruction Guide Read all instructions before use. K...
lang:en **score:12** filesize: 1.73 M page_count: 2 document date: 2025-01-25