Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 833-214BN

HOMCOM Shoe Cabinet

Instruction Manual - Model 833-214BN

Overview Safety Information Parts List Setup & Assembly Operating Instructions Maintenance Troubleshooting Specifications Support

1. Product Overview

The HOMCOM Shoe Cabinet Model 833-214BN is designed to provide an organized and efficient storage solution for your footwear and entryway essentials. This contemporary unit features a combination of storage options to suit various needs.

It includes two tilting drawers, each equipped with two internal tiers for shoe storage. Additionally, there is a dedicated cabinet on the left with three individual compartments, a top drawer for smaller items, and two top lattices for display or quick access. The cabinet's design aims to keep your living space tidy and inviting.



Image 1.1: Front view of the HOMCOM Shoe Cabinet with all compartments open, illustrating its storage capabilities for shoes and other items.

2. Safety Information

Please read and understand all safety instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Assembly:** Always assemble the product on a soft, clean surface to prevent scratches. Ensure all parts are present and undamaged before beginning assembly.
- **Tools:** Use appropriate tools for assembly as specified in the included assembly guide. Do not overtighten screws, as this may damage the material.
- **Stability:** Ensure the cabinet is placed on a flat, stable surface. If wall-mounting hardware is provided, it is highly recommended to secure the cabinet to a wall to prevent tipping, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 110 lbs (50 kg) for the entire unit. Distribute weight evenly across shelves and drawers.

- **Children:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the cabinet.
- **Maintenance:** Regularly check all fasteners to ensure they remain tight. Loose fasteners can compromise the stability and safety of the unit.

3. Parts List

Before beginning assembly, please verify that all components listed in the packaging's parts inventory are present and undamaged. Refer to the detailed parts list and hardware pack included with your product for specific item identification. If any parts are missing or damaged, do not proceed with assembly. Contact HOMCOM customer support immediately for assistance.

4. Setup & Assembly

The HOMCOM Shoe Cabinet requires assembly. Follow the step-by-step instructions provided in the separate assembly guide included in your product packaging. It is recommended to have at least two people for assembly to ensure safety and ease of construction.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts on a soft, clean surface to prevent scratches.
2. **Identify Components:** Match each component with the parts list in the assembly guide.
3. **Follow Instructions:** Adhere strictly to the sequence of steps outlined in the assembly guide. Pay close attention to diagrams and hardware usage.
4. **Secure Fasteners:** Ensure all screws, dowels, and other fasteners are securely tightened, but avoid overtightening to prevent material damage.
5. **Stability Check:** Once assembled, gently shake the cabinet to ensure it is stable and all connections are firm. Adjust as necessary.



Image 4.1: The HOMCOM Shoe Cabinet in its fully assembled and closed state, ready for use.

5. Operating Instructions

This shoe cabinet offers multiple storage compartments designed for various items.

- **Tilting Shoe Drawers:** The two main compartments feature tilting doors. Pull the handle to open the door, revealing two tiers for shoe storage. Place shoes with the toes facing inwards for optimal space utilization. Gently push the door back to close.
- **Top Drawer:** The single top drawer is suitable for smaller items such as keys, wallets, or shoe care accessories. Pull the knob to open and push to close.
- **Side Cabinet:** The cabinet on the left side opens with a standard hinged door and contains three fixed compartments. This area is ideal for boots, larger shoes, or other entryway items.
- **Top Lattices:** The two open lattice sections on top of the cabinet can be used for displaying decorative items, storing frequently used items, or as additional open storage.



Image 5.1: Detail of the top drawer and side cabinet, demonstrating access to smaller storage areas.

6. Maintenance

Proper care and maintenance will extend the life and appearance of your HOMCOM Shoe Cabinet.

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the particle board material.
- **Fasteners:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary to maintain structural integrity.
- **Sunlight & Heat:** Avoid placing the cabinet in direct sunlight or near heat sources, as this can cause fading, warping, or cracking of the material.

7. Troubleshooting

If you encounter issues during assembly or use, refer to the following common solutions:

- **Missing or Damaged Parts:** If you find any parts missing or damaged upon unboxing, do not proceed with assembly. Contact HOMCOM customer support for replacement parts.
- **Difficulty Assembling:** Double-check the assembly guide to ensure each step is followed correctly. Sometimes, parts may appear similar but have subtle differences. Ensure you are using the correct hardware for each step.
- **Wobbly Cabinet:** Ensure the cabinet is on a level surface. Check that all screws and fasteners are fully tightened. If applicable, use the provided wall-anchoring hardware to secure the cabinet to a wall.
- **Drawers/Doors Not Closing Properly:** Verify that the internal mechanisms (e.g., tilting hinges, drawer slides) are installed correctly and are not obstructed. Ensure no items inside are preventing closure. Check for any misaligned panels during assembly.
- **Scratches/Dents:** Minor cosmetic damage can sometimes be touched up with furniture repair pens or markers that match the finish. For significant damage, contact customer support.

8. Product Specifications

Brand:	HOMCOM
Model Number:	833-214BN
Material:	Engineered Wood (Particle Board)
Overall Dimensions (W x D x H):	35.5" x 11" x 38.5" (90.17 cm x 27.94 cm x 97.79 cm)
Weight Capacity:	110 lbs (50 kg)
Mounting Type:	Floor Mount
Room Type:	Bedroom, Entryway, Living Room
Assembly Required:	Yes



Image 8.1: Dimensional drawing of the shoe cabinet, indicating overall width, depth, and height.

9. Warranty & Customer Support

For warranty information, replacement parts, or any questions regarding your HOMCOM Shoe Cabinet, please contact HOMCOM customer support directly. Refer to the contact information provided in your product packaging or visit the official HOMCOM website.

When contacting support, please have your model number (833-214BN) and proof of purchase readily available to expedite assistance.

Online Support: Visit the HOMCOM Store on Amazon

© 2026 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072LVV3W9

More documents and user manuals: **https://manuals.plus/**