

[Manuals.plus](#) /

> [labebe](#) /

> labebe Pink Unicorn Rocking Horse User Manual (Model HY1720004-BLW)

labebe HY1720004-BLW

labebe Pink Unicorn Rocking Horse User Manual

Model: HY1720004-BLW

For ages 6 months to 3 years

1. INTRODUCTION

Thank you for choosing the labebe Pink Unicorn Rocking Horse. This product is designed to provide a safe and enjoyable experience for your child, promoting balance and motor skill development. Please read this manual thoroughly before assembly and use to ensure proper operation and safety.



Image: The labebe Pink Unicorn Rocking Horse, featuring a soft plush unicorn with a pink mane, golden horn, and a secure seat with a safety belt, mounted on a wooden rocking base.

2. SAFETY INFORMATION

Your child's safety is our top priority. Please adhere to the following safety guidelines:

- Always supervise children while they are using the rocking horse.
- Ensure the safety belt is securely fastened around your child before use.
- Place the rocking horse on a flat, stable surface away from stairs, windows, and other hazards.
- Do not exceed the maximum weight capacity of 150 lbs (68.04 kg).
- Regularly inspect the product for any loose parts, damage, or wear. Discontinue use if any issues are found.

- Keep small parts away from children under 3 years of age to prevent choking hazards.

Perfect Gift for Toddler



Let your kid experience the fun of their own pony friend to play with



Gift



Birthday



Christmas

Image: A close-up view highlighting the secure three-sided seat and the adjustable safety belt, designed to keep the child safely in place during use.

3. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow these steps carefully:

1. Unpack all components and verify against the parts list.
2. The plush unicorn body comes pre-assembled.
3. Attach the two wooden rocking boards to the base of the unicorn using the provided screws and wooden blocks. Ensure the counter-sunk holes on the wooden boards face outwards for a smooth finish.
4. Insert the round bar (handle) into the designated holes on the unicorn's head.
5. Tighten all screws firmly, but do not overtighten.
6. Ensure all connections are secure before allowing a child to use the product.

Quick device tips:

Need to press and hold the control lever firmly and push it forward to align with the device. This design can make the rocking horse more stable.



Image: An illustration showing the components of the rocking horse and a step-by-step diagram for attaching the wooden rocking base to the plush unicorn body.

Enjoy a happy childhood in labebe

The best gift for kids, Soft, cozy and cute

About us

Our vision

The most influential children's products company in the world.

Our mission "More Effort More Love"

Deep down, we believe that for children all over the world, play is the most indispensable.



UNICORN ROCKING

The pink unicorn plush rocking horse is a symbol of beauty, nobility and purity, it will inspire children to explore the world!



Image: A visual guide detailing the wooden base, handles, and the process of securing the base to the unicorn, emphasizing the importance of proper alignment for stability.

4. OPERATING INSTRUCTIONS

The labebe Pink Unicorn Rocking Horse is designed for simple and intuitive use:

- Help your child sit comfortably in the plush seat.
- Fasten the 3-point safety buckle securely.
- Encourage your child to hold onto the wooden handles for stability.
- The rocking motion is achieved by shifting weight or gently pushing off the ground with feet. The design incorporates a 20° restricted angle to prevent tipping.

Labebe have many fans in the world!



Image: A child happily riding the labebe Pink Unicorn Rocking Horse, demonstrating the comfortable and secure seating position.

5. MAINTENANCE

To ensure the longevity and cleanliness of your rocking horse:

- **Cleaning the Plush Fabric:** For stains, use a damp cloth with mild soap or baking soda. Gently rub the affected area and then wipe clean with a fresh damp cloth. Allow to air dry completely.
- **Cleaning the Wooden Base:** Wipe the wooden parts with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the rocking horse in a dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rocking horse feels unstable.	Loose screws or uneven surface.	Check and tighten all assembly screws. Ensure the product is on a flat, level surface.

Problem	Possible Cause	Solution
Child slips out of the seat.	Safety belt not fastened or adjusted correctly.	Always ensure the 3-point safety buckle is securely fastened and adjusted snugly to your child's size.
Difficulty with rocking motion.	Child is too young or not yet developed sufficient core strength.	Supervise and assist the child. The product is suitable for children aged 6 months to 3 years, with varying levels of assistance needed.

7. SPECIFICATIONS

- **Brand:** labebe
- **Model:** HY1720004-BLW
- **Recommended Age:** 6 months to 3 years
- **Maximum Weight Capacity:** 150 lbs (68.04 kg)
- **Materials:** Cotton, Engineered Wood, Wood
- **Item Dimensions (L x W x H):** 25" x 14" x 27" (64 cm x 37 cm x 68 cm)
- **Item Weight:** 11.02 lbs
- **Assembly Required:** Yes



Image: A diagram illustrating the key dimensions of the rocking horse, including length, width, and height, for reference.

8. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your labebe Pink Unicorn Rocking Horse, please contact our customer support team. We are committed to ensuring your satisfaction and your child's enjoyment.

Please refer to your purchase documentation for specific warranty details. If you encounter any issues during assembly or use, do not hesitate to reach out to us for prompt support.

Contact Information: [Visit the labebe Store on Amazon](#)