

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Techni Mobili](#) /
- › [Techni Mobili Kid's Gaming and Student Racer Chair Instruction Manual](#)

## Techni Mobili RTA-KS40

# Techni Mobili Kid's Gaming and Student Racer Chair Instruction Manual

Model: RTA-KS40

## 1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Techni Mobili Kid's Gaming and Student Racer Chair. Designed with a racer-style aesthetic, this chair offers comfort and functionality for gaming or study. It features durable TechniFlex upholstery, a pneumatic height-adjustable seat, and a stable 5-star nylon base with non-marking casters.



Image 1.1: Techni Mobili Kid's Gaming and Student Racer Chair (Blue)

## 2. SAFETY INFORMATION

Please read and understand all safety warnings before assembling or using the chair.

- This product has a maximum weight capacity of **140 lbs**. Do not exceed this limit to prevent damage or injury.
- Improper use of the pneumatic adjustable seat height may pose a risk. Always adjust the height carefully and ensure the user is seated properly.
- For child safety, adult supervision is recommended during assembly and initial use.
- Keep small parts away from children during assembly to avoid choking hazards.

### 3. COMPONENTS AND PARTS LIST

Before beginning assembly, ensure all components are present and undamaged. Refer to the diagram below for identification.



Image 3.1: Key Features and Components

Typical components include:

- Seat Cushion Assembly
- Backrest Assembly
- 5-Star Nylon Base
- Casters (Wheels)
- Gas Lift Cylinder
- Gas Lift Cover
- Armrests (pre-attached or separate)
- Hardware (screws, washers, Allen wrench)

### 4. SETUP AND ASSEMBLY

Assembly is straightforward and typically requires one person. An Allen wrench is usually included with the hardware.

1. **Attach Casters to Base:** Insert each caster into the holes at the end of each leg of the 5-star nylon base until it clicks securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the 5-star nylon base. Cover the gas lift with the telescopic cover.
3. **Attach Seat to Gas Lift:** Carefully place the seat cushion assembly onto the gas lift cylinder, ensuring the center mechanism aligns with the top of the gas lift. Press down firmly to secure.
4. **Attach Backrest to Seat:** Align the backrest with the mounting points on the seat cushion. Secure with the provided screws and tighten using the Allen wrench. Do not overtighten.
5. **Final Check:** Ensure all screws are tightened and the chair is stable before use.



Image 4.1: Chair Dimensions for Reference

## 5. OPERATING INSTRUCTIONS

Your Techni Mobili Kid's Gaming and Student Racer Chair is designed for ease of use and comfort.

- **Height Adjustment:** To raise the seat, lift the lever located under the right side of the seat while standing. To lower the seat, lift the lever while seated. Release the lever at the desired height.
- **Swivel Function:** The chair features a 360-degree swivel for easy movement and access to your workspace.
- **Mobility:** The dual non-marking casters allow for smooth movement across various floor surfaces without leaving marks.



Image 5.1: Chair in a typical use environment

## 6. MAINTENANCE

Proper care will extend the life and appearance of your chair.

- **Cleaning:** For general cleaning, wipe the chair with a soft, damp cloth. For spot cleaning, use a mild soap solution and a clean cloth, then wipe dry. Avoid harsh chemicals or abrasive cleaners.
- **Caster Maintenance:** Periodically check casters for hair or debris that may impede smooth rolling. Clean as necessary.
- **Hardware Check:** Every few months, check all screws and bolts to ensure they are tight. Retighten if necessary.

to maintain stability.

## 7. TROUBLESHOOTING

If you encounter issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift malfunction or lever not engaged.	Ensure the lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact customer support.
Chair wobbles or feels unstable	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the base is on a flat surface.
Casters do not roll smoothly	Debris caught in casters or damaged casters.	Remove any hair or debris from the caster wheels. If damaged, casters may need replacement.

## 8. SPECIFICATIONS

<b>Brand</b>	Techni Mobili
<b>Model Name</b>	Gaming Chair for Kids, Racing Style Kids Desk Chair with Wheels, Blue
<b>Product Dimensions</b>	22"D x 21.25"W x 35.25"H
<b>Size</b>	22"D x 21.25"W x 35.25"-38"H
<b>Color</b>	Blue
<b>Maximum Weight Recommendation</b>	140 Pounds
<b>Material</b>	TechniFlex upholstery, Nylon base
<b>Special Feature</b>	Adjustable Height, Non-marking casters, Swivel
<b>Item Weight</b>	20 pounds
<b>Manufacturer</b>	RTA Products

## 9. WARRANTY AND SUPPORT

Your Techni Mobili Kid's Gaming and Student Racer Chair comes with a **1 Year Limited Warranty**. This warranty covers manufacturing defects and material flaws under normal use.

For warranty claims, replacement parts, or further assistance, please contact Techni Mobili customer service. Techni Mobili is an American company with US-based customer service.

You can also refer to the official Installation Manual for detailed assembly diagrams [Installation Manual \(PDF\)](#)

*Note: No official product videos from the seller were available for embedding in this manual.*

