

CUCKOO CRP-EHSS0309F

CUCKOO High Pressure Rice Cooker

MODEL: CRP-EHSS0309F

User Manual

Introduction

This manual provides instructions for the CUCKOO CRP-EHSS0309F 3-Cup IH Pressure Rice Cooker. This appliance is designed to cook various types of rice and other dishes using induction heating technology. It features a stainless steel interior and a ventilation pipe system for durability and consistent performance.



Image: The CUCKOO CRP-EHSS0309F High Pressure Rice Cooker, showcasing its gold and black exterior with an LED display.

Setup

1. Unboxing and Component Identification

Carefully remove all components from the packaging. Ensure the following items are present:

- CUCKOO CRP-EHSS0309F Rice Cooker
- Nonstick Inner Pot (Xwall Stainless)
- Rice Spatula

- Rice Measuring Cup
- Instruction & Cooking Guide (this manual)

Essentials Included



XWALL STAINLESS
INNER POT



MEASURING
CUP



RICE SCOOPER



STEAM PLATE



INSTRUCTION &
COOKING GUIDE



Dual Motion Packing

Detachable Inner Lid

Xwall Stainless Inner Pot

Stainless Finish

Product Size: W 9.1" X D 12.6" X H 8.3"

Image: A visual representation of the included accessories: Xwall stainless inner pot, measuring cup, rice scooper, steam plate, and instruction manual.

2. Initial Cleaning

Before first use, wash the inner pot, rice spatula, and measuring cup with warm, soapy water. Wipe the exterior of the rice cooker with a damp cloth. Ensure all parts are dry before assembly.

3. Language Setup (Voice Guide)

The rice cooker features a 3-language voice guide (English, Chinese, Korean). To set your preferred language:

1. Press the "SET" button to initiate setup.
2. Select your preferred language using the navigation buttons.
3. Confirm your selection by pressing "SET" again.

Voice-Guided Cooking



Image: A diagram illustrating the steps to set the voice guide language, showing options for Korean, English, and Chinese.

Operating Instructions

The CUCKOO CRP-EHSS0309F offers 16 customizable menu options and utilizes induction heating for efficient cooking.

1. Basic Rice Cooking

1. Measure the desired amount of rice using the provided measuring cup.
2. Rinse the rice thoroughly until the water runs clear.
3. Place the rinsed rice into the nonstick inner pot.
4. Add water according to the markings inside the inner pot or your preferred ratio.
5. Close the lid securely.
6. Select the desired cooking mode using the LED touch controls. Common options include Glutinous/White Rice, Brown Rice, Mixed Rice, and GABA Rice.
7. Press the "COOK" button to start. The smart algorithm will detect the grain type and internal temperature to optimize cooking.

Induction Stainless Pot

Xwall
BLACK SHINE
FOR EXTREME CONDITION

Xwall
STAINLESS
Clean & Safe

Xwall
THE BLACK
COATING Black

Xwall
DIAMOND



Stainless Steel Casing
Ensures perfect heat control
for unmatched rice flavor.



Induction Heating
Induction heat surrounds pot
for fast, flawless rice cooking.



Enhanced Durability
Resists extreme heat, pressure, salt,
and detergents.



Curved Design
60-degree angled design
for enhanced heat circulation.

CUCKOO



Image: A diagram highlighting the stainless steel casing, induction heating, enhanced durability, and curved design of the inner pot for optimal heat circulation.

2. Menu Options and Special Functions

The rice cooker includes 16 menu options for diverse meal preparation:

- **Rice Types:** GABA rice, brown rice, glutinous/white rice, mixed rice.
- **Specialty Dishes:** Nu Rung Ji, pressure cook, multi-cook.
- **Convenience Functions:** Reheat option for leftovers, keep-warm function to maintain food temperature.

The **My Mode Function** allows for customized temperature control to achieve specific rice flavor and texture preferences.

Unlimited Cooking Magic



Turbo Rice Mode
17-22 Minutes



Regular White Rice
30-39 Minutes



GABA Rice
71-98 Minutes



Porridge
71-98 Minutes



Steamed Vegetable
15-35 Minutes



Butter Cake
40-45 Minutes

CUCKOO

Image: Examples of various dishes that can be prepared, including Turbo Rice, Regular White Rice, GABA Rice, Porridge, Steamed Vegetable, and Butter Cake, along with their approximate cooking times.

Master Every Grain



Smart Algorithm

Fuzzy-logic for tailored cooking
Detects grains and fine tunes-water, heat, and duration



Image: A diagram titled 'Master Every Grain' showing the five stages of the Smart Algorithm: Water Absorption, Heating, Steaming, Cool Down, and Keep Warm, with Fuzzy Logic detecting grains and fine-tuning water, heat, and duration.



Image: A visual showing 'Food Made Simple', with examples of Regular White Rice, Braised Short Ribs, Porridge, and Steamed Dish, demonstrating the cooker's versatility beyond just rice.

Maintenance

Regular cleaning and maintenance ensure the longevity and optimal performance of your rice cooker.

1. Auto-Clean Function

After cooking, initiate the Auto-Clean function to steam the interior of the rice cooker for a deep clean. This helps remove food residue and maintain hygiene.




Image: A diagram illustrating the 'Easy to Clean' features, including dishwasher-safe components, general easy cleaning, and the Auto Clean function.

2. Detachable Inner Lid

The inner lid is detachable for thorough cleaning. Refer to the detailed instructions in the full manual for proper removal and reattachment to prevent damage.

3. General Cleaning

- The nonstick inner pot should be hand washed.
- Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners.
- Ensure the ventilation pipe system is clear of any blockages.

Clean Cooking, Richer Flavor




Auto Sterilization
Cleaning



Anti-Stagnant
Water Drainage



Dual Soft
Steam Cap



Non-Stop
Steam Venting



CUCKOO

Image: A diagram titled 'Clean Cooking, Richer Flavor' illustrating features like Auto Sterilization Cleaning, Anti-Stagnant Water Drainage, Dual Soft Steam Cap, and Non-Stop Steam Venting.

Troubleshooting

If you encounter issues with your CUCKOO rice cooker, consider the following common solutions:

- **Rice not cooking properly:** Ensure the correct water-to-rice ratio is used for the selected grain type. Verify the inner pot is seated correctly and the lid is fully closed.
- **Lid difficult to open/close:** Check for any obstructions around the lid or sealing gasket. Ensure the pressure release valve is in the correct position.
- **Voice guide issues:** Confirm the language setting is correct as per the 'Language Setup' section.
- **Unusual odors or sounds:** Discontinue use and consult the manufacturer's support if persistent.

For more detailed troubleshooting, refer to the comprehensive guide provided with your product or contact CUCKOO customer support.







Specifications

Feature	Detail
Brand	CUCKOO
Model Number	CRP-EHSS0309F
Capacity	3-Cup Uncooked / 6-Cup Cooked (1.5 Quarts)
Product Dimensions	9.1"D x 12.6"W x 8.6"H
Power Source	Corded Electric
Product Care Instructions	Hand Wash (inner pot)
Color	Gold
Special Feature	Advanced Fuzzy Logic, Induction Heating
Material	Metallic (exterior), Stainless Steel (inner pot, lid)
Item Weight	11 Pounds
Wattage	850 watts
Voltage	120 Volts
Included Components	Rice cooker, nonstick inner pot, rice spatula, rice measuring cup

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official CUCKOO website. The warranty typically covers manufacturing defects for a specified period from the date of purchase.

For technical support, service, or to purchase replacement parts, please contact CUCKOO customer service through their official website or the contact information provided in your product packaging.

	<p>CUCKOO CRP-G10 Fuzzy Series Electric Rice Cooker/Warmer: Operating Instructions and Limited Warranty</p> <p>Explore the CUCKOO CRP-G10 Fuzzy Series Electric Pressure Rice Cooker/Warmer with this comprehensive guide. It details operating instructions, safety warnings, maintenance tips, and the limited warranty provided by CUCKOO ELECTRONICS CO.,LTD.</p>
	<p>CUCKOO CRP-HR08 Fuzzy Series IH Pressure Jar Cooker Operating Instructions</p> <p>This document provides comprehensive operating instructions for the CUCKOO CRP-HR08 Fuzzy Series IH Pressure Jar Cooker, covering safety precautions, usage guides, cleaning procedures, and troubleshooting tips.</p>
	<p>Cuckoo CR-0675FW Multifunctional Rice Cooker User Manual</p> <p>Comprehensive user manual for the Cuckoo CR-0675FW 6-cup multifunctional micom rice cooker, detailing operation, features, and maintenance for optimal cooking.</p>
	<p>CUCKOO IH Pressure Rice Cooker CRP-JH10 FUZZY Series Operating Instructions</p> <p>This document provides comprehensive operating instructions and cooking guidance for the CUCKOO IH Pressure Rice Cooker, model CRP-JH10 FUZZY Series. It covers safety precautions, product specifications, cooking methods, and troubleshooting tips to ensure optimal use of the appliance.</p>
	<p>CUCKOO CRP-P1009S Series Electric Pressure Rice Cooker/Warmer User Manual</p> <p>Comprehensive operating instructions and user manual for the CUCKOO CRP-P1009S Series electric pressure rice cooker/warmer. Includes safety precautions, operating guide, cooking methods, cleaning instructions, and troubleshooting.</p>
	<p>CUCKOO CRP-DH06 Fuzzy Series IH Pressure Jar Cooker Operating Instructions</p> <p>Comprehensive operating instructions and safety guidelines for the CUCKOO CRP-DH06 Fuzzy Series IH Pressure Jar Cooker. This manual covers setup, usage, cleaning, maintenance, troubleshooting, and warranty information.</p>

