

[Manuals.plus](#) /

› [GE](#) /

› GE Lighting Reveal HD LED 3-Way Light Bulb User Manual

GE 96678

GE Lighting Reveal HD LED 3-Way Light Bulb User Manual

Model: 96678

INTRODUCTION

This manual provides essential information for the safe and effective use of your GE Lighting Reveal HD LED 3-Way Light Bulb. This advanced LED bulb is designed to deliver exceptional color contrast and radiant whites, enhancing the appearance of colors in your home. It features a 3-way functionality, offering multiple brightness levels from a single bulb.



Image: Packaging of the GE Reveal HD LED 3-Way Light Bulb, highlighting its 3-way functionality and brightness levels.

SAFETY INFORMATION

Please read and understand all safety instructions before installing or using this light bulb. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Risk of Electric Shock:** Always turn off power to the fixture before installing, removing, or inspecting the bulb.
- **Risk of Fire:** Do not exceed the wattage rating of the fixture. This bulb is a 16-watt LED, equivalent to a 100-watt incandescent bulb.
- **Not for Enclosed Fixtures:** This bulb is not recommended for use in fully enclosed fixtures as it may shorten its lifespan.
- **Not for Dimmers:** This is a 3-way bulb designed for 3-way sockets. It is not intended for use with standard dimmer switches. Using it with a dimmer may cause damage or improper operation.
- **Indoor Use Only:** Suitable for dry locations.
- **Handle with Care:** Allow the bulb to cool before handling if it has been in use.

SETUP AND INSTALLATION

Installing your GE Reveal HD LED 3-Way Light Bulb is a simple process. Ensure you have a compatible 3-way lamp or fixture with an E26 medium base socket.

1. **Turn Off Power:** Before installation, ensure the power to the lamp or fixture is completely turned off at the switch and, if possible, at the circuit breaker.
2. **Remove Old Bulb:** Carefully unscrew the old light bulb from the socket.
3. **Insert New Bulb:** Screw the GE Reveal HD LED 3-Way Light Bulb into the E26 medium base socket. Turn clockwise until it is finger-tight. Do not overtighten.
4. **Restore Power:** Turn the power back on to the fixture.



Image: Close-up of the GE Reveal HD LED 3-Way Light Bulb, showing its standard E26 medium screw base.

OPERATING INSTRUCTIONS

This 3-way light bulb provides three distinct brightness levels. The functionality is controlled by the 3-way switch on your lamp or fixture.

- **First Click:** Activates the lowest brightness setting (equivalent to 30W incandescent, 300 lumens).
- **Second Click:** Activates the medium brightness setting (equivalent to 70W incandescent, 850 lumens).
- **Third Click:** Activates the highest brightness setting (equivalent to 100W incandescent, 1140 lumens).
- **Fourth Click:** Turns the bulb off.

The GE Reveal HD LED technology filters out dulling yellow light, providing exceptional color contrast and whiter whites, making colors appear more vivid and vibrant. This makes it ideal for kitchens, bathrooms, and craft or hobby spaces where clarity is important.

See just how vivid color can be with GE's high definition light.

GE HD bulbs are an improved, energy-saving LED that enhance the appearance of colors. Experience the difference with bolder colors and enhanced contrast vs. standard GE LED bulbs.

reveal®

REVEAL® is GE's best light. REVEAL® bulbs filter out dulling yellow light to give you incredible color contrast PLUS whiter whites for exceptional clarity. REVEAL® bulb's clean, beautiful light® is perfect for detailed tasks and beautiful spaces. Use REVEAL® light in kitchens, bathrooms as well as craft & hobby spaces where clarity matters most.



Reveal® and clean, beautiful light® are registered trademarks of GE.

HD+ LIGHT

Exceptional
color contrast
& boldness
PLUS
radiant whites



Greater color
contrast vs.
standard LED

+

More vivid colors

+

Whites
appear whiter

Image: A kitchen counter with fruits and appliances, demonstrating the enhanced color vibrancy provided by GE Reveal HD LED lighting.

MAINTENANCE

The GE Reveal HD LED 3-Way Light Bulb requires minimal maintenance.

- **Cleaning:** Ensure the power is off and the bulb is cool before cleaning. Wipe the bulb with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Replacement:** This LED bulb has a long lifespan. Replace the bulb when it no longer illuminates or if its performance significantly degrades. Follow the "Setup and Installation" steps for replacement.

TROUBLESHOOTING

If you encounter issues with your GE Reveal HD LED 3-Way Light Bulb, try the following solutions:

- **Bulb Does Not Light Up:**
 - Ensure the power to the fixture is on.
 - Check if the bulb is screwed in securely.
 - Test the bulb in another working 3-way fixture to confirm it is not faulty.

- Verify the fixture itself is working by testing with another known good bulb.

- **Incorrect Brightness Sequence (e.g., 70W-100W-30W):**

- The intended sequence for this 3-way bulb is typically increasing brightness (30W → 70W → 100W).
- Some older or non-standard 3-way lamp sockets may cycle through brightness levels in a different order. This is often due to the wiring or design of the fixture's switch, not a defect in the bulb.
- If the sequence is consistently different from expected, it is likely a characteristic of your specific lamp or fixture.

- **Flickering or Dimming:**

- Ensure the bulb is not used with a standard dimmer switch, as this bulb is not designed for dimming and may flicker.
- Check for loose connections in the fixture or wall switch.

SPECIFICATIONS

Feature	Detail
Brand	GE
Model Number	96678
Light Type	LED
Special Feature	3-Way
Wattage	16 watts
Incandescent Equivalent	100 Watts (max)
Brightness (Lumens)	300 / 850 / 1140 Lumens (3-Way)
Bulb Shape Size	A21
Bulb Base	E26 (Medium Base)
Voltage	120 Volts
Color Rendering Index (CRI)	80
Material	Copper (base)
Product Dimensions	4.93 x 2.37 x 2.37 inches
Item Weight	7.2 ounces
GTIN/UPC	043168684170

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official GE Lighting website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Online Resources: www.gelighting.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B072NS1FBD>

More documents and user manuals: <https://manuals.plus/>