

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tiny Love](#) /

› **Tiny Love Meadow Days Soothe 'n Groove Baby Mobile Instruction Manual**

Tiny Love TO025

Tiny Love Meadow Days Soothe 'n Groove Baby Mobile Instruction Manual

Model: TO025

Brand: Tiny Love

PRODUCT OVERVIEW

The Tiny Love Meadow Days Soothe 'n Groove Baby Mobile is a versatile musical mobile designed to entertain and soothe your child from infancy through toddlerhood. It transitions from a crib mobile to a stand-alone music box, offering a variety of musical options and engaging features.

IMPORTANT SAFETY INFORMATION

- Always ensure the mobile is securely attached to the crib according to the instructions.
- Remove the mobile from the crib when the baby begins to push up on hands and knees or reaches 5 months of age, whichever comes first.
- Do not add additional strings or straps to the mobile.
- Keep small parts away from children.
- Adult assembly required.

PACKAGE CONTENTS

Please check that all parts are included before assembly:

- Mobile Arm and Attachment Mechanism
- Music Box Unit
- Mobile Arch with Hanging Toys (Fox, Hedgehog, Rabbit, Bird)
- User Manual (this document)

SETUP AND ASSEMBLY

Attaching to the Crib

1. Identify the mobile arm and the music box unit.
2. Securely attach the mobile arm to the crib rail. Ensure it is firmly clamped and stable.
3. Slide the music box unit onto the designated slot on the mobile arm until it clicks into place.
4. Attach the mobile arch with the hanging toys to the top of the mobile arm. Ensure all toys are securely fastened.



Image: The Tiny Love Meadow Days Soothe 'n Groove Mobile securely attached to a crib, demonstrating proper installation.

Converting to Stand-Alone Music Box

1. Detach the mobile arm and arch from the music box unit.
2. The music box unit can now be used independently as a portable music player for toddlers.



Image: A toddler happily holding the music box unit, illustrating its use as a portable, stand-alone music player.

OPERATING INSTRUCTIONS

Power On/Off and Volume Control

Locate the power switch and volume control on the side of the music box unit.

- **Power On/Off:** Slide the switch to "On" to activate the mobile or "Off" to power down.
- **Volume Control:** Adjust the volume using the dedicated slider or buttons.

Musical Categories and Tunes

The mobile offers 6 different musical categories with a total of 18 engaging melodies, providing up to 40 minutes of continuous, non-repeating music.

- **Jazz:** Upbeat tunes for active play.
- **World:** Diverse melodies for exploration.
- **Nature:** Calming sounds inspired by the outdoors.
- **Classic:** Timeless compositions for cognitive development.
- **Lullaby:** Soothing melodies for naptime or bedtime.

- **White Sound:** Gentle background noise for relaxation.

Press the corresponding button on the music box to select a musical category. Each category typically cycles through three different tunes.

Features 6 different musical categories with 18 different tunes



Image: The music box unit highlighting the buttons for selecting different musical categories.

Up to 40 minutes of continuous non-repeating music



Image: A baby reaching for the music box, illustrating the interactive nature of the product and its continuous music feature.

Mobile Motion and Light

The mobile features a special soothing motion that engages the baby. A soft night light function is also available.

- **Motion:** The mobile arm rotates gently, moving the hanging toys.
- **Light:** Activate the night light for a calming glow.

Special soothing motion engages baby



Image: The mobile in action, with hanging toys rotating above a baby, demonstrating the soothing motion feature.

Becomes a stand-alone portable music box for toddlers



Image: A close-up of the music box unit, showing the various buttons for music selection, volume, and light.

Product Videos

Video: An official overview of the Tiny Love Meadow Days Soothe 'n Groove Mobile, showcasing its features and functionality.

Video: A complete sampler of the track listing available on the Tiny Love Meadow Days Soothe 'n Groove Mobile, demonstrating the various musical categories.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the mobile unit and plastic parts with a damp cloth and mild soap. Do not immerse in water.
- **Toy Care:** The plush toys can be hand-washed with mild detergent and air-dried.
- **Storage:** Store in a cool, dry place when not in use.

TROUBLESHOOTING

| Problem | Solution |
|---------|----------|
| | |

| Problem | Solution |
|---------------------------------|---|
| Mobile not turning on | Ensure the power switch is in the "On" position. |
| Music is distorted or too quiet | Adjust the volume control. Ensure speakers are not obstructed. |
| Mobile not rotating | Check for any obstructions preventing rotation. Ensure the mobile arm is correctly assembled. |

PRODUCT SPECIFICATIONS

- **Model Number:** TO025
- **Brand:** Tiny Love
- **Dimensions (L x W x H):** 4.75 x 16 x 13.5 inches
- **Item Weight:** 1.98 pounds (0.9 Kilograms)
- **Material:** Metal, Plastic
- **Special Features:** Adjustable, Light Up, Musical
- **Musical Options:** 6 categories, 18 tunes, up to 40 minutes continuous play
- **Mounting Type:** Crib Mount
- **UPC:** 855075007054

WARRANTY AND CUSTOMER SUPPORT

For warranty information, product registration, or customer support, please visit the official Tiny Love website or contact their customer service department. Keep your purchase receipt for proof of purchase.