



Manuals.plus /

› Accessory USA /

› Accessory USA AC DC Adapter for Eton MICROLINK FR170 AM/FM Weather Radio User Manual

## Accessory USA FR170

# Accessory USA AC DC Adapter for Eton MICROLINK FR170 AM/FM Weather Radio User Manual

## 1. INTRODUCTION

---

This manual provides essential instructions for the safe and effective use of your Accessory USA AC DC Adapter, designed specifically for the Eton MICROLINK FR170 AM/FM Weather Radio. Please read this manual thoroughly before using the product.

## 2. SAFETY INFORMATION

---

Your Accessory USA AC DC Adapter is CE / FCC / RoHS certified and has been tested by the manufacturer to meet or exceed OEM specifications. It incorporates OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) to ensure safe operation.

- Do not expose the adapter to liquids, extreme temperatures, or humidity.
- Ensure the adapter is used in a well-ventilated area.
- Do not disassemble or attempt to repair the adapter.
- Always unplug the adapter from the power outlet when not in use or during electrical storms.

## 3. COMPATIBILITY

---

This AC DC Adapter is compatible with the ETON MICROLINK FR170 AM/FM WEATHER RADIO. Before purchasing or using, please ensure that your device model matches the specified compatibility to prevent damage.



Image showing the Accessory USA AC DC Adapter, designed for use with the Eton MICROLINK FR170 AM/FM Weather Radio. It features a standard AC plug on one end and a barrel connector on the other.

## 4. SETUP INSTRUCTIONS

---

1. **Inspect the Adapter:** Before connecting, visually inspect the adapter and its cables for any signs of damage.
2. **Connect to Device:** Insert the barrel connector end of the adapter firmly into the power input port of your Eton MICROLINK FR170 AM/FM Weather Radio.
3. **Connect to Power Outlet:** Plug the AC plug end of the adapter into a standard wall power outlet. Ensure the outlet is easily accessible.
4. **Verify Connection:** Confirm that both connections are secure. The radio should now receive power from the adapter.

## 5. OPERATING INSTRUCTIONS

---

Once the adapter is properly connected to both the Eton MICROLINK FR170 radio and a power outlet, the radio will draw power directly from the electrical supply. This allows for continuous operation without relying on the radio's internal battery, or it can charge the radio's internal battery if the radio supports this function via its power input.

- Turn on your Eton MICROLINK FR170 radio as per its own user manual.
- The adapter provides a stable power supply for the radio's functions.
- To disconnect, first turn off the radio, then unplug the adapter from the wall outlet, and finally disconnect it from the radio.

## 6. MAINTENANCE

---

To ensure the longevity and optimal performance of your AC DC Adapter, follow these simple maintenance guidelines:

- **Cleaning:** Use a dry, soft cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Do not bend or crimp the cable excessively. Avoid placing heavy objects on the cable.

## 7. TROUBLESHOOTING

---

- **No Power to Radio:**
  - Ensure the adapter is securely plugged into both the radio and the wall outlet.
  - Check if the wall outlet is functional by plugging in another device.
  - Inspect the adapter cable for any visible damage. If damaged, discontinue use.
- **Radio Functioning Intermittently:**
  - Verify all connections are tight.
  - Ensure the adapter is not overheating. Disconnect and allow it to cool if it feels unusually hot.

## 8. SPECIFICATIONS

---

Specification	Value
Brand	Accessory USA
Connector Type	barrel connector
Input Voltage	240 Volts
Output Current	170 Amps
Specification Met	CE, FCC, RoHS
UPC	769043463073
ASIN	B072PZDS23

## 9. WARRANTY AND SUPPORT

---

This product comes with a 30 Days Money Back Guarantee, 60 Days Free Exchange with Paid Return Label, and a 365 Days Anytime Worry-Free Warranty. For support or warranty claims, please contact Accessory USA customer service through your purchase platform or the official Accessory USA website.