

[manuals.plus](#) /

- › [Timex](#) /
- › [Timex Women's Metropolitan 34mm Dress Watch Instruction Manual](#)

**Timex TW2R364009J**

# Timex Women's Metropolitan 34mm Dress Watch Instruction Manual

Model: TW2R364009J

## INTRODUCTION

Thank you for choosing the Timex Women's Metropolitan 34mm Dress Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

## PRODUCT OVERVIEW

Familiarize yourself with the key components of your Timex Metropolitan watch.



**Figure 1: Front View of the Timex Metropolitan Watch.** This image displays the watch face with its black dial, gold-tone hour markers, and hands, encased in a gold-tone bezel, attached to a black leather strap.



**Figure 2: Side View of the Timex Metropolitan Watch.** This image shows the slim profile of the watch case and the crown on the right side, used for setting the time.



**Figure 3: Watch Strap and Buckle.** This image details the black genuine leather strap and the gold-tone buckle with the Timex logo, used to secure the watch on the wrist.

## SETUP: SETTING THE TIME

---

1. **Locate the Crown:** The crown is the small knob located on the right side of the watch case (refer to Figure 2).
2. **Pull Out the Crown:** Gently pull the crown outwards until you feel a click. This will stop the watch movement.
3. **Set the Time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
4. **Push In the Crown:** Once the time is set, push the crown back into its original position. The watch will resume operation.

# OPERATING INSTRUCTIONS

## Water Resistance

Your Timex Metropolitan watch is water resistant to 30 meters (100 feet). This means it is suitable for everyday use and can withstand splashes or brief immersion in water. However, it is **not recommended** for swimming, bathing, or diving. Always ensure the crown is fully pushed in to maintain water resistance.

## General Care

- Avoid exposing the watch to extreme temperatures (hot or cold).
- Keep the watch away from strong magnetic fields.
- Avoid direct contact with solvents, detergents, perfumes, and cosmetic products, as they may damage the strap or case.

## MAINTENANCE

### Battery Replacement

Your watch is powered by an analog-quartz movement and requires one CR2 battery (included). When the watch stops or the time becomes inaccurate, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

### Cleaning Your Watch

- **Case and Crystal:** Wipe with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth.
- **Leather Strap:** Avoid prolonged exposure to water. If the strap gets wet, dry it thoroughly with a soft cloth. Leather straps can be cleaned with a specialized leather cleaner or a very slightly damp cloth. Allow to air dry completely.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Dead battery	Replace battery (recommended by professional).
Incorrect time display	Crown not fully pushed in; time needs adjustment.	Push crown in completely. Reset time as per "Setting the Time" section.
Condensation under crystal	Exposure to extreme temperature changes or water ingress.	Seek professional service immediately to prevent damage.

## SPECIFICATIONS

- **Model Number:** TW2R364009J
- **Movement:** Analog-quartz
- **Case Diameter:** 34mm
- **Case Material:** Brass
- **Strap Material:** Genuine Leather
- **Water Resistance:** 30m (100ft) - withstands splashes or brief immersion in water, not suitable for swimming or bathing.
- **Battery:** 1 CR2 battery (included)
- **Manufacturer:** Timex Corporation

# WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Timex website. Keep your proof of purchase for warranty claims.

Timex Official Website: [www.timex.com](http://www.timex.com)



© 2023 Timex Corporation. All rights reserved.

## Related Documents - TW2R364009J

	<p><a href="#">Timex Metropolitan S Smartwatch Quick Start Guide</a></p> <p>A concise guide to setting up and using your Timex Metropolitan S smartwatch, including charging, app connection, and basic navigation.</p>
	<p><a href="#">Timex Diamond Collection Watch User Manual and Instructions</a></p> <p>Official user manual and guide for the Timex Diamond Collection watch, providing instructions on operation, water resistance, time setting, bracelet adjustment, and warranty information.</p>
	<p><a href="#">TIMEX Metropolitan Smart: Round Dial User Guide</a></p> <p>User guide for the TIMEX Metropolitan Smart: Round Dial smartwatch, detailing features, setup, app integration, and usage instructions for optimal performance.</p>
	<p><a href="#">Руководство по эксплуатации часов Timex</a></p> <p>Подробное руководство по эксплуатации часов Timex, охватывающее настройку времени, использование хронографа, водонепроницаемость, регулировку браслета и функции подсветки INDIGLO® для различных механизмов Timex.</p>
	<p><a href="#">Timex Analog Watch User Manual - Features, Settings, and Care</a></p> <p>Comprehensive user guide for Timex Analog watches, covering setup, features like INDIGLO® Night-Light, water resistance, alarms, perpetual calendar, and maintenance. Available in multiple languages.</p>
	<p><a href="#">TIMEX Metropolitan Smart: Round Dial User Guide</a></p> <p>Comprehensive user guide for the TIMEX Metropolitan Smart: Round Dial smartwatch, covering setup, features, operations, fitness tracking, and app connectivity.</p>

