

Intempo EE1771BLKSTK

Intempo EE1771BLKSTK Bluetooth Capsule Speaker User Manual

Model: EE1771BLKSTK

Brand: Intempo

1. INTRODUCTION

Thank you for purchasing the Intempo EE1771BLKSTK Bluetooth Capsule Speaker. This portable speaker is designed to provide wireless audio playback and hands-free calling, enhanced with integrated color-changing LED lights. This manual provides essential information for setting up, operating, and maintaining your speaker.



This image shows the Intempo EE1771BLKSTK Bluetooth Capsule Speaker in black, positioned horizontally, with a black smartphone lying beside it. The speaker has a cylindrical shape with textured grilles and chrome accents.

2. SAFETY INFORMATION

- Do not expose the speaker to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the speaker to strong impacts.

- Do not attempt to disassemble or repair the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from heat sources, direct sunlight, and flammable materials.
- Dispose of the product and its battery responsibly according to local regulations.

3. PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x Intempo Bluetooth Capsule Speaker with LED Lights
- 1 x USB Charging Cable

4. PRODUCT OVERVIEW

Control Panel



A close-up top view of the Intempo EE1771BLKSTK speaker, highlighting the central control panel. Buttons for power, mode, play/pause, and track navigation are visible, along with an 'intempo+' logo on the right side.

- **Power Button:** Press and hold to turn the speaker ON/OFF.
- **Mode Button (M):** Press to switch between Bluetooth and SD card modes.
- **Play/Pause Button:** Press to play or pause audio. Press to answer/end calls. Press and hold to reject a call.
- **Previous Track / Volume Down Button:** Press to go to the previous track. Press and hold to decrease volume.
- **Next Track / Volume Up Button:** Press to go to the next track. Press and hold to increase volume.

Ports

- **USB Charging Port:** For connecting the USB charging cable.
- **SD Card Slot:** For playing audio directly from an SD card.

5. SETUP

5.1 Charging the Speaker

1. Connect the small end of the included USB charging cable to the USB charging port on the speaker.
2. Connect the larger end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate during charging and turn off when fully charged.
4. A full charge provides approximately 4 hours of playback time.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the LED indicator lights up and an audible tone is heard.

- **To Power Off:** Press and hold the Power button until the LED indicator turns off and an audible tone is heard.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

The speaker is compatible with Bluetooth-enabled smartphones and tablets.

1. Ensure the speaker is powered on and in Bluetooth mode. The LED indicator will flash, indicating it is ready for pairing.
2. Enable Bluetooth on your mobile device (smartphone or tablet).
3. Search for available Bluetooth devices. Select "EE1771BLKSTK" (or similar name) from the list.
4. Once successfully paired, the speaker will emit a confirmation tone, and the LED indicator will stop flashing.

6.2 Playing Audio

- **Via Bluetooth:** After successful pairing, play music from your connected device. Use the speaker's Play/Pause, Previous/Next Track buttons, or your device's controls.
- **Via SD Card:** Insert a compatible SD card into the SD card slot. The speaker will automatically switch to SD card mode and begin playing audio files. Use the speaker's controls for playback.

6.3 Hands-Free Calling


When connected via Bluetooth, the speaker's built-in microphone allows for hands-free calls.

- **Answer Call:** Press the Play/Pause button once.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button when a call is incoming.

6.4 Adjusting Volume

- Press and hold the **Volume Up** button to increase the volume.
- Press and hold the **Volume Down** button to decrease the volume.
- Volume can also be adjusted directly from your connected device.

6.5 LED Light Function



This image captures the Intempo EE1771BLKSTK speaker in a dark setting, showcasing its vibrant red and blue LED lights glowing through the speaker grille, creating an atmospheric effect.

The speaker features integrated color-changing LED lights that activate automatically when the speaker is powered on, enhancing the audio experience with visual effects. The lights cycle through various colors.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid prolonged exposure to direct sunlight or extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not used frequently. Avoid fully discharging the battery for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on	Battery is discharged	Charge the speaker using the provided USB cable.
No sound	Volume is too low or muted; Speaker not connected	Increase volume on speaker and connected device; Ensure Bluetooth connection is established.
Cannot pair via Bluetooth	Speaker not in pairing mode; Device Bluetooth off; Speaker connected to another device	Ensure speaker is powered on and flashing LED; Enable Bluetooth on your device; Disconnect from other devices.
Poor sound quality	Too far from connected device; Interference	Move the speaker closer to the connected device; Avoid obstacles between devices.

9. SPECIFICATIONS

Feature	Specification
Model	EE1771BLKSTK
Brand	Intempo
Connectivity	Bluetooth
Compatible Devices	Smartphone, Tablet
Audio Output Mode	Stereo
Speaker Configuration	2.0
Max Speaker Power	3 Watt (per speaker)
Total Output Wattage	6 Watt
Power Source	Battery powered
Average Battery Life	4 Hours
Special Features	Wireless, Color-changing LED Lights, SD Card Input, Built-in Microphone
Included Components	1 x Speaker, 1 x USB Charging Cable
Product Dimensions	35 x 6.9 x 11 cm
Product Weight	100 g

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Intempo customer service directly. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question