

MUSE M-630

Muse M-630 DWT Bluetooth Speaker Instruction Manual

Model: M-630 DWT

1. PRODUCT OVERVIEW

The Muse M-630 DWT is a versatile Bluetooth speaker designed to deliver high-quality audio with multiple connectivity options. It features an integrated FM radio, USB playback and charging capabilities, NFC for easy pairing, and an AUX-In port. The unit includes a remote control for convenient operation and a dimmable LED display for enhanced usability.

Package Contents:

- Muse M-630 DWT Bluetooth Speaker
- Remote Control
- Auxiliary Cable
- Power Cable
- Instruction Manual

2. IMPORTANT SAFETY INSTRUCTIONS

Please read and follow these safety instructions carefully before operating the device. Keep this manual for future reference.

- Do not expose this appliance to dripping or splashing water.
- Do not place objects filled with liquids, such as vases, on the appliance.
- Ensure proper ventilation around the unit. Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the appliance.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this appliance during lightning storms or when unused for long periods of time.

- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

3. PRODUCT FEATURES

- Bluetooth connectivity for wireless audio streaming.
- FM Radio with 20 preset stations.
- USB port for MP3 playback.
- USB port for device charging (5V 1A).
- NFC (Near Field Communication) for automatic Bluetooth pairing.
- AUX-In jack for wired audio connection.
- Multifunction white LED display with dimmer (High, Low, Off).
- Integrated clock, alarm, and sleep functions.
- 40 Watts output power with passive bass.
- Wooden casing for enhanced acoustics.
- Full-function remote control included.

4. CONTROLS AND CONNECTIONS

The front panel of the Muse M-630 DWT features an LED display and various control buttons and ports for easy access to its functions.



Image: Front view of the Muse M-630 DWT Bluetooth Speaker. The speaker features a dark wooden casing with a black speaker grille covering the front. In the center, a black panel houses a white LED display showing '12:00', along with various control buttons and input ports. These include 'NFC' indicator, 'SOURCE' button, play/pause, skip track buttons, 'USB MP3' port, 'USB CHARGING' port (5V 1A), and 'AUX IN' jack. The 'MUSE' logo is visible on the bottom right of the grille. The unit stands on four conical feet.

Front Panel Controls:

- **NFC Area:** For quick Bluetooth pairing with NFC-enabled devices.
- **/SOURCE Button:** Powers the unit on/off and switches between input sources (Bluetooth, FM, USB, AUX).
- **Play/Pause Button:** Controls playback in Bluetooth and USB modes.
- **Skip/Tune Buttons (◀◀ / ▶▶):** Skips tracks in Bluetooth/USB mode or tunes FM radio stations.
- **Volume Buttons (- / +):** Adjusts the speaker volume.
- **USB MP3 Port:** Connect a USB flash drive for MP3 audio playback.
- **USB CHARGING Port (5V 1A):** Connect a USB cable to charge external devices.
- **AUX IN Jack:** Connect external audio devices using the supplied auxiliary cable.

5. SETUP

5.1 Power Connection

1. Connect the supplied power cable to the AC IN port on the back of the speaker.
2. Plug the other end of the power cable into a standard AC wall outlet.
3. The unit will enter standby mode, and the clock display may illuminate.

5.2 Initial Setup

Upon first power-on or after a power outage, you may need to set the clock. Refer to the 'Clock, Alarm, and Sleep Functions' section for detailed instructions.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off and Source Selection

- Press the **/SOURCE** button on the front panel or remote control to turn the unit on or off.
- Repeatedly press the **/SOURCE** button to cycle through available input sources: Bluetooth, FM Radio, USB, AUX-In.

6.2 Bluetooth Operation

1. Switch the speaker to Bluetooth mode. The display will show 'BT' and an icon, indicating it's ready for pairing.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select 'M-630 DWT' from the list of found devices.
4. Once paired, the speaker will emit a confirmation sound, and the Bluetooth icon on the display will stop flashing.
5. You can now play audio from your device through the speaker. Use the Play/Pause and Skip buttons on the speaker or remote, or control playback directly from your device.

NFC Pairing:

If your device supports NFC, simply tap your device against the NFC area on the speaker's front panel to initiate Bluetooth pairing automatically.

6.3 FM Radio Operation

1. Switch the speaker to FM Radio mode. The display will show the current frequency.
2. **Automatic Scan:** Press and hold the Play/Pause button for a few seconds. The radio will scan for and save available FM stations automatically (up to 20 presets).
3. **Manual Tuning:** Briefly press the Skip/Tune buttons (◀◀ / ▶▶) to fine-tune the frequency step-by-step.
4. **Preset Selection:** Use the P- / P+ buttons on the remote control to navigate through saved preset stations.

6.4 USB Playback

1. Insert a USB flash drive containing MP3 audio files into the 'USB MP3' port.
2. Switch the speaker to USB mode. The display will show 'USB' and begin playing the first track.
3. Use the Play/Pause and Skip buttons to control playback.

6.5 AUX-In Operation

1. Connect one end of the supplied auxiliary cable to the 'AUX IN' jack on the speaker.
2. Connect the other end of the auxiliary cable to the headphone jack or audio output of your external audio device.
3. Switch the speaker to AUX-In mode. The display will show 'AUX'.
4. Play audio from your external device. Volume can be controlled via the speaker or the external device.

6.6 Clock, Alarm, and Sleep Functions

Detailed instructions for setting the clock, configuring alarms, and activating the sleep timer are typically found in the full printed manual. These functions are usually accessed via dedicated buttons on the remote control or by pressing and holding specific buttons on the unit's front panel.

6.7 Display Dimmer

The LED display has three brightness levels: High, Low, and Off. This function is usually controlled by a dedicated 'DIMMER' button on the remote control or a combination of buttons on the unit. Press the button repeatedly to cycle through the brightness options.

7. MAINTENANCE

Cleaning the Unit:

- Always unplug the unit from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- Keep the ventilation openings free of dust.

8. TROUBLESHOOTING GUIDE

If you experience issues with your Muse M-630 DWT speaker, consult the table below for common problems and solutions.

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active.	Ensure the power cable is securely connected to the unit and a working wall outlet.
No sound	Volume too low; Incorrect source selected; Device not paired (Bluetooth); AUX cable not connected properly.	Increase volume; Select correct input source; Re-pair Bluetooth device; Check AUX cable connection.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in Bluetooth mode and visible; Move device closer; Avoid other wireless devices.
FM radio reception poor	Weak signal; Antenna not extended.	Adjust the position of the unit; Extend the FM antenna (if applicable).
USB playback not working	USB drive not formatted correctly; Incompatible file format; USB drive damaged.	Ensure USB drive is FAT32 formatted; Only MP3 files are supported; Try a different USB drive.
Remote control not working	Battery depleted; Obstruction between remote and unit.	Replace remote control battery; Ensure clear line of sight to the unit's sensor.

9. TECHNICAL SPECIFICATIONS

- **Brand:** MUSE
- **Model:** M-630 DWT
- **Output Power:** 40 Watts
- **Connectivity:** Bluetooth, USB, Wired (AUX-In)
- **Wireless Technology:** Bluetooth, NFC
- **Power Source:** AC
- **Audio Output Mode:** Stereo
- **Speaker Type:** Component
- **Control Method:** Remote Control
- **Special Features:** FM Radio, Clock, Alarm, Sleep Function, Dimmable LED Display, USB Charging (5V 1A)






- **Dimensions (L x W x H):** 14.7 x 32 x 17.5 cm (5.79 x 12.6 x 6.89 inches)
- **Weight:** 2.6 kg (5.73 lbs)
- **Compatible Devices:** Smartphone, other Bluetooth-enabled devices, devices with 3.5mm audio output

10. WARRANTY AND CUSTOMER SUPPORT

This product is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details. For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact your retailer or the official Muse customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

© 2023 MUSE. All rights reserved.

Related Documents - M-630

	<p>Muse M-056 AG/SC/VB Portable Radio User Manual</p> <p>User manual for the Muse M-056 AG, M-056 SC, and M-056 VB portable radio. Provides instructions on operation, controls, power supply, radio tuning, auxiliary input, technical specifications, and safety guidelines.</p>
	<p>MUSE M-238 BC Bone Conduction Earphones with MP3 Player - User Manual</p> <p>User manual for the MUSE M-238 BC bone conduction earphones with built-in MP3 player. Learn about setup, operation, Bluetooth pairing, charging, specifications, and safety warnings.</p>
	<p>Manuel d'utilisation de l'enceinte Bluetooth MUSE M-1930 DJ</p> <p>Ce manuel fournit des instructions détaillées pour l'enceinte Bluetooth MUSE M-1930 DJ, couvrant la configuration, l'utilisation des fonctions Bluetooth, USB, AUX, FM, le karaoké, le couplage stéréo et le dépannage.</p>
	<p>Muse M-1380 DBT Bluetooth Speaker User Manual</p> <p>Comprehensive user manual for the Muse M-1380 DBT Bluetooth speaker, covering setup, operation, features like DAB+/FM radio, CD playback, USB, Bluetooth, NFC, and troubleshooting.</p>
	<p>MUSE M-199 DAB Autoradio User Manual - DAB+/FM, Bluetooth, USB/SD</p> <p>This user manual provides comprehensive instructions for the MUSE M-199 DAB car radio. Discover how to install, operate, and utilize its advanced features, including DAB+/FM radio reception, Bluetooth connectivity, USB/SD media playback, and essential safety guidelines.</p>



[Muse M-05R Portable 4-Band Radio User Manual](#)

User manual for the Muse M-05R portable 4-band radio, covering safety, operation, power supply, and technical specifications.