

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [REVLON](#) /

› [Revlon Pro Collection 2-in-1 Hair Dryer and Volumizer RVDR5212 Instruction Manual](#)

REVLON RVDR5212

Revlon Pro Collection 2-in-1 Hair Dryer and Volumizer

Model: RVDR5212

INTRODUCTION

This manual provides instructions for the safe and effective use of your Revlon Pro Collection 2-in-1 Hair Dryer and Volumizer. This appliance is intended for household use only. Please read all instructions before use and retain for future reference.



Image: The Revlon Pro Collection 2-in-1 Hair Dryer and Volumizer, featuring a black handle and a paddle brush head with pink bristles.

PRODUCT FEATURES

The Revlon Pro Collection 2-in-1 Hair Dryer and Volumizer combines the power of a hairdryer with the precision of a styling brush. Key features include:

- **Ionic Technology:** Negative ions saturate the airflow to reduce the size of water droplets for faster drying. This helps condition, smooth, and make hair shinier, while reducing frizz and static.
- **Large Paddle Design:** Dries and smooths hair quickly.
- **Detangling Bristles:** Designed to glide through hair, detangling, drying, and smoothing in one step.
- **Multiple Heat Settings:** Two heat settings (HIGH and LOW) and one cool shot setting for complete styling flexibility.
- **Lightweight, Ergonomic Design:** For comfortable use and easy styling, especially for the back of the head.
- **Professional Swivel Cord:** Prevents tangling and facilitates styling.



Image: A detailed diagram illustrating the components of the Revlon 2-in-1 Hair Dryer and Volumizer, including air outlets, bristles, brush area, handle, 4-position switch, and air inlets.

SETUP

1. Unpack the appliance and ensure all components are present and undamaged.
2. Familiarize yourself with the appliance's features, including the 4-position switch for heat and cool settings.
3. Ensure your electrical outlet matches the voltage requirements of the appliance.

OPERATING INSTRUCTIONS

For best results, follow these steps:

1. **Prepare Hair:** Always towel-dry hair to remove excess water. Smooth hair with a comb or brush to untangle. Styling hair will be faster if it is slightly damp, not wet.
2. **Plug In:** Plug the appliance into an electrical outlet.

3. **Select Setting:** Adjust the 4-position switch to the desired setting.

- Use the **HIGH (III)** setting for thick or coarse hair.
- Use the **LOW (II)** setting for fine or thin hair.
- The **COOL (I)** setting can be used to set your style.

4. **Section Hair:** For optimal results, separate hair into manageable sections.

5. **Style Hair:** Starting with the bottom section of hair, place the brush over the hair close to the roots. Run the brush towards the ends. To prevent over-drying, do not concentrate the airflow on any one area for an extended period.

6. **Repeat:** Continue this process for the remaining sections until the desired look is achieved.

7. **Finish:** Turn the appliance off when styling is complete. Allow the unit to cool completely before storing.



Image: A woman demonstrating the use of the Revlon 2-in-1 Hair Dryer and Volumizer to dry and style her hair.

OVERHEATING PROTECTION

This appliance is equipped with a thermostat that will cycle OFF (0) should the heat of the dryer exceed the optimum drying level, due to partially blocked air inlet or outlet openings. In the event that the appliance stops, turn the appliance OFF (0) and allow it to cool down. Once the appliance cools, the thermostat will automatically reset and usage may resume.

MAINTENANCE AND CARE

Cleaning

- Always unplug the appliance from the mains after use and allow it to cool before cleaning.
- Wipe the outer surface of the dryer with a slightly moist cloth, then wipe dry.
- Do not use abrasive cleaners or solvents.

Storage

- Always unplug the appliance when not in use.
- Allow the appliance to cool completely before storing.
- Store the appliance in a dry location.
- Do not pull or twist the cord. Do not wrap the cord around the appliance, as this may cause the cord to wear prematurely and break.
- Regularly check the power cord for wear and damage, particularly where it enters the appliance and the plug.

TROUBLESHOOTING

If your appliance is not functioning as expected, consider the following:

- **No Power:** Ensure the appliance is properly plugged into a working electrical outlet. Check your household fuse or circuit breaker.
- **Overheating:** If the appliance stops working due to overheating, refer to the "Overheating Protection" section. Unplug and allow it to cool before resuming use.
- **Reduced Airflow:** Check for any lint or hair buildup in the air inlets or outlets. Clean as per the "Maintenance and Care" section.
- **Unusual Noise/Smell:** Discontinue use immediately and unplug the appliance. Contact customer support if the issue persists.

SPECIFICATIONS

Brand	REVLON
Model Number	RVDR5212
Power	1100 Watts
Power Source	Corded Electric
Special Feature	Cool Shot, Ionic Technology
Recommended Uses	Detangling, Smoothing, Drying
Material	Plastic

Color	Black
Dimensions (L x W x H)	22.5 x 16.5 x 21.5 cm
Weight	648 grams
Country of Origin	China

IMPORTANT SAFETY WARNINGS

- **Water Hazard:** Keep away from water. Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- **Flammable Materials:** Do not use near flammable materials.
- **Children:** Do not allow children to use this appliance unsupervised.
- **Power Cord:** Do not operate the appliance with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- **Ventilation:** Ensure air inlets and outlets are not blocked during use to prevent overheating.
- **Storage:** Always unplug and allow to cool before storing. Store in a dry place.

WARRANTY AND CUSTOMER SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official Revlon website. Keep your proof of purchase for any warranty claims.

For further assistance, please contact Revlon customer service.