

T'nB KBSCGR

T'nB KBSCGR Wireless Keyboard and Mouse Combo Instruction Manual

Model: KBSCGR (AZERTY, Grey)

1. INTRODUCTION

Thank you for choosing the T'nB KBSCGR Wireless Keyboard and Mouse Combo. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new device. Please read these instructions carefully before use to ensure optimal performance and longevity of your product.



Image 1.1: T'nB KBSCGR Wireless Keyboard and Mouse Combo (AZERTY, Grey).

2. PACKAGE CONTENTS

Ensure all items are present in your package:

- 1 x T'nB Wireless AZERTY Keyboard
- 1 x T'nB Wireless Mouse
- 1 x USB Radiofrequency Receiver (Dongle)
- AAA Batteries (for both keyboard and mouse)

- 1 x Instruction Manual (this document)

3. SETUP GUIDE

3.1. Installing Batteries

1. **For the Mouse:** Locate the battery compartment on the underside of the mouse. Open the cover, insert the provided AAA battery, ensuring correct polarity (+/-). Close the cover.
2. **For the Keyboard:** Locate the battery compartment on the underside of the keyboard. Open the cover, insert the provided AAA batteries, ensuring correct polarity (+/-). Close the cover.



Image 3.1: Underside of the T'nB Wireless Mouse, illustrating the battery compartment.

3.2. Connecting the USB Receiver

1. Locate the small USB radiofrequency receiver (dongle). This dongle is typically stored within the mouse's battery compartment or a dedicated slot for transport.
2. Plug the USB receiver into an available USB port on your computer (desktop or laptop).
3. The keyboard and mouse will automatically connect to your computer. No additional driver installation is required.

usually required for Windows or macOS operating systems.



Image 3.2: The USB receiver connected to a laptop, enabling wireless communication with the keyboard and mouse.

4. OPERATING INSTRUCTIONS

4.1. General Use

- The keyboard features a compact design with comfortable, silent keys for a pleasant typing experience.
- The wireless mouse is designed for comfort and ergonomics, suitable for both left and right-handed users.

Longue autonomie de plusieurs mois

Piles incluses



Image 4.1: The T'nB wireless keyboard and mouse in an office environment, highlighting their silent operation.

Souris confortable

Convient aussi bien aux gauchers qu'aux droitiers



Image 4.2: The ergonomic design of the T'nB wireless mouse, comfortably fitting in a user's hand.

4.2. Multimedia Shortcuts

The keyboard is equipped with 13 multimedia shortcut keys, accessible by pressing the **Fn** key in combination with the corresponding function key (F1-F12). These shortcuts allow quick access to:

- Media playback controls (play/pause, stop, previous/next track)
- Volume control (mute, volume up/down)
- Web browser, email client, and other common applications



13 Raccourcis multimédia

En appuyant sur FN+F1, F2...

**Vous pouvez rapidement passer
d'un raccourci multimédia à l'autre**

Image 4.3: Illustration of the multimedia shortcut keys on the T'nB keyboard.

5. MAINTENANCE

5.1. Cleaning

- To clean the keyboard and mouse, use a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaning solution. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaners, as these can damage the surface.

5.2. Battery Replacement

The keyboard and mouse are designed for long battery autonomy. When performance degrades (e.g., delayed response, intermittent connection), it is time to replace the batteries.

- Replace all batteries in the device simultaneously with new AAA alkaline batteries.
- Ensure correct polarity (+/-) when inserting new batteries.
- Dispose of used batteries responsibly according to local regulations.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low or dead batteries	Replace batteries in both devices with fresh AAA alkaline batteries.
Intermittent connection or lag	USB receiver not properly connected or too far from devices; Interference from other wireless devices.	Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port. Move the receiver closer to the keyboard and mouse. Minimize obstructions between devices and receiver.
Keys sticking or unresponsive	Debris under keys; Key mechanism issue.	Gently clean around and under the affected keys. If the issue persists, contact customer support.
Mouse cursor erratic or unresponsive	Dirty optical sensor; Mouse used on unsuitable surface.	Clean the optical sensor on the underside of the mouse. Use the mouse on a clean, opaque, non-reflective surface or a mouse pad.

7. SPECIFICATIONS

Feature	Detail
Brand	T'nB
Model Number	KBSCGR
Color	Grey
Connectivity Technology	Wireless (Radiofrequency) with USB Receiver
Keyboard Layout	AZERTY (French)
Special Features	Silent Keys, 13 Multimedia Shortcuts, Ergonomic Mouse
Compatible Operating Systems	Windows, macOS
Compatible Devices	Desktop computers, Laptops
Battery Type	AAA Alkaline (included)
Mouse Movement Detection	Optical
Recommended Product Usage	General computing, Multimedia usage

8. WARRANTY INFORMATION

This T'nB product is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or external causes.

Please retain your proof of purchase for warranty claims.


9. CUSTOMER SUPPORT


If you encounter any issues not resolved by the troubleshooting section, or if you require further assistance, please contact T'nB customer support. Refer to the contact information provided on the product packaging or the official T'nB website.

For more information, you may visit the [T'nB Brand Store](#).

© 2025 T'nB. All rights reserved.

Related Documents - KBSCGR

	<p>T'nB Rechargeable Wireless Mouse Bluetooth + USB 2.4GHz User Manual User guide for the T'nB MWGRADIENT rechargeable wireless mouse, detailing setup via USB 2.4GHz and Bluetooth for Windows and Mac, along with essential safety information.</p>
	<p>T'nB USB Wired Products User Manual and Safety Guide Comprehensive guide for T'nB USB wired products, including safety instructions, connection steps, and support information. Learn how to safely connect and use your T'nB keyboard and mouse.</p>
	<p>T'nB Bluetooth Mouse and Keyboard Combo User Manual User manual for the T'nB Bluetooth Mouse and Keyboard Combo, providing setup instructions, safety guidelines, and troubleshooting tips.</p>
	<p>T'nB iClick Bluetooth Keyboard and Mouse User Manual User manual for the T'nB iClick Bluetooth Keyboard and Mouse, providing setup and usage instructions.</p>
	<p>TNB CFSPEAKERBT Bluetooth Speaker User Manual Features, Setup, Safety Comprehensive user manual for the TNB CFSPEAKERBT Bluetooth speaker. Learn about its features, USB and Bluetooth connection methods, important safety instructions, and support contact information.</p>



[T'nB LASERREMOTE Presentation Laser User Manual](#)

User manual for the T'nB LASERREMOTE presentation laser pointer. Learn about its features, operation, and safety guidelines for effective presentations.