Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Yaheetech /
- Yaheetech Professional 4-in-1 Rolling Makeup Train Case (Model YTu6rr0001001) Instruction Manual

Yaheetech YTu6rr0001001

Yaheetech Professional 4-in-1 Rolling Makeup Train Case (Model YTu6rr0001001) Instruction Manual

Comprehensive guide for the assembly, operation, and maintenance of your Yaheetech Professional Makeup Train Case.

Introduction

Thank you for choosing the Yaheetech Professional 4-in-1 Rolling Makeup Train Case. This versatile and durable cosmetic organizer is designed to meet the needs of professional makeup artists, manicurists, hair stylists, beauticians, and enthusiasts alike. Its modular design allows for flexible storage and easy portability, ensuring your tools and products are always organized and accessible.

Key Features:

- **4-in-1 Transformable Design:** Features four detachable compartments for customizable storage configurations (4-in-1, 3-in-1, or 2-in-1).
- Extra-large 4-tiered Case: Includes a top case with accordion-style trays and a roomy compartment, plus a second tier with a detachable foam-lined tray with 6 dividers, ideal for most-used items and delicate products.
- **Sturdy Construction:** Made from CARB P2-compliant engineered wood and a waterproof plastic finish, reinforced with aluminum trimming and steel corners. Supports up to 66 lb.
- Secured With Lockable Latches: Equipped with 8 robust suitcase latches and 2 keys for enhanced security of your contents.
- Versatile Use: Ideal for organizing a wide range of beauty products, tools, and accessories.

SETUP AND ASSEMBLY

Your Yaheetech Professional Makeup Train Case comes largely pre-assembled. The primary setup involves attaching the removable wheels and configuring the modular compartments to suit your needs.

1. Attaching the Wheels

The case includes four detachable 360-degree swivel wheels for easy mobility.



Figure 1: Overview of the Yaheetech 4-in-1 Makeup Train Case, highlighting its dimensions and the 360-degree rotating wheels. The wheels are designed for smooth movement and can be easily attached or detached.

- 1. Locate the four wheel attachment points on the bottom corners of the base unit.
- 2. Align each wheel with an attachment point.
- 3. Push firmly until you hear a click, indicating the wheel is securely in place. Ensure all wheels are properly attached before use.
- 4. To remove, press the red button on the wheel stem and pull the wheel downwards.

2. Configuring the 4-in-1 Modular Design

The case consists of a top unit, two middle units, and a bottom unit. These can be used together or separately.

Your browser does not support the video tag.

Video 1: Demonstration of the 4-in-1 modular design, showing how the different sections of the rolling makeup organizer can be detached and reconfigured. (Source: Vitacomoda)

- 1. To separate a unit, unlatch the metal clasps on both sides of the desired section.
- 2. Lift the upper section straight up to detach it from the lower section.
- 3. To reattach, align the upper section precisely over the lower section and press down until the latches

engage securely.

4. The top unit can be used independently as a smaller carrying case. The middle units can be removed to create a 3-in-1 or 2-in-1 configuration.



Figure 2: The Yaheetech Professional 4-in-1 Rolling Makeup Train Case fully assembled, showcasing its sleek black design and robust construction.

OPERATING INSTRUCTIONS

1. Accessing Compartments

Each section of the makeup train case is designed for easy access and organization.



Figure 3: A woman utilizing the Yaheetech makeup train case, demonstrating the accessibility of the top compartments with their pull-out trays.

- **Top Unit:** Unlatch the two top clasps and lift the lid. The top unit features four accordion-style trays that slide outwards, revealing a spacious main compartment underneath. These trays are ideal for smaller items like brushes, palettes, and lipsticks.
- **Middle Units:** Each middle unit can be accessed by detaching the upper unit as described in the Setup section. The second tier includes a detachable foam-lined tray with 6 dividers, perfect for delicate items or nail polish bottles. The third tier is a deep, open compartment for larger items.
- **Bottom Unit:** The largest and deepest compartment, suitable for bulkier items such as hair dryers, curling irons, or larger product bottles.

2. Securing the Case

The case is equipped with lockable latches to keep your contents secure.



Figure 4: Detailed view of the robust lockable latches, ensuring the security of your valuable items within the case.

- Ensure all units are properly stacked and the side latches are engaged.
- Use the provided keys to lock the top latches for added security. Keep spare keys in a safe place.

3. Using the Telescopic Handle

For easy transport, extend the telescopic handle.



Figure 5: The telescopic handle extended, allowing for comfortable and effortless transportation of the rolling case.

- Press the button on the top of the handle and pull upwards to extend it.
- Adjust the handle to a comfortable height for rolling.
- To retract, press the button again and push the handle downwards until it locks into its compact position.

Your browser does not support the video tag.

Video 2: A quick demonstration of the rolling functionality and modularity of the Yaheetech 4-in-1 Makeup Train Case. (Source: Yaheetech)

Maintenance and Care

- **Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. For stubborn stains, a mild soap solution can be used. Avoid abrasive cleaners or solvents.
- Interior: The interior lining can be gently wiped with a damp cloth. For the foam-lined trays, remove and shake out any debris.
- **Hardware:** Periodically check all latches, hinges, and the telescopic handle for proper function. Lubricate moving parts if necessary.
- Storage: Store the case in a dry, cool place away from direct sunlight to prevent material

degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Units do not stack securely.	Misalignment of units or latches.	Ensure units are perfectly aligned before engaging latches. Check for any obstructions.
Wheels are difficult to attach/detach.	Improper alignment or debris in the socket.	Ensure the wheel stem is aligned correctly. Clear any debris from the socket. Apply slight pressure while twisting gently.
Telescopic handle is stiff.	Dust/debris in the mechanism or lack of lubrication.	Clean the handle mechanism. Apply a small amount of silicone lubricant if necessary.
Latches are difficult to lock/unlock.	Key misalignment or mechanism stiffness.	Ensure the key is fully inserted and turned correctly. Lubricate the lock mechanism if stiff.

SPECIFICATIONS

Feature	Detail
Product Dimensions	13.4 x 10 x 31.6 inches (L x W x H)
Item Weight	15.87 Pounds
Material	CARB P2-compliant engineered wood, waterproof plastic finish, reinforced aluminum trimming, steel corners
Color	Black
Model Number	YTu6rr0001001
Max Load Capacity	66 lb
Wheels	4 detachable 360° swivel wheels

WARRANTY AND SUPPORT

For specific warranty details and support inquiries, please refer to the product's packaging or contact Yaheetech customer service directly. General return policies may apply as per the retailer's terms. For further assistance, please visit the official Yaheetech website or contact their customer support.

