



[Manuals.plus](#) /

> [Accessory USA](#) /

> Accessory USA Replacement AC Power Cord Instruction Manual for Sharp Aquos LC-48LE551U, LC-39LE551U, LC46SE941U

## Accessory USA LC-48LE551U, LC-39LE551U, LC46SE941U, QACCZA076WJPZ, QACCCA039WJPZ

# Accessory USA Replacement AC Power Cord Instruction Manual

For Sharp Aquos LC-48LE551U, LC-39LE551U, LC46SE941U LCD HDTV Models

## 1. INTRODUCTION

---

This instruction manual provides essential information for the safe and effective use of your Accessory USA Replacement AC Power Cord. Please read this manual thoroughly before installation and retain it for future reference. This power cord is designed as a replacement for specific Sharp Aquos LCD HDTV models.

## 2. SAFETY INFORMATION

---

Adherence to the following safety guidelines is crucial for preventing damage to the product and ensuring user safety:

- Our products are CE / FCC / RoHS certified, and tested by the manufacturer to meet or exceed OEM specifications.
- Features OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) for enhanced safety.
- Ensure the power cord is compatible with your device model before purchase and installation.
- Do not use the power cord if it appears damaged or frayed.
- Avoid placing the power cord in areas where it can be tripped over or damaged.
- Always unplug the power cord from the wall outlet before disconnecting it from the device.

## 3. PRODUCT OVERVIEW

---

The Accessory USA Replacement AC Power Cord is a high-quality, non-OEM replacement designed to

supply power to compatible Sharp Aquos LCD HDTVs. It features a standard two-prong AC plug for wall outlets and a C7 connector for the device.



Figure 3.1: Overview of the Accessory USA Replacement AC Power Cord, showing the standard two-prong wall plug and the figure-8 (C7) device connector.

## 4. SETUP AND INSTALLATION

---

Follow these steps to properly install the replacement AC power cord:

1. **Verify Compatibility:** Before proceeding, ensure that your Sharp Aquos TV model is listed as compatible with this power cord. Compatible models include LC-48LE551U, LC-39LE551U, and LC46SE941U.
2. **Power Off Device:** Ensure your television is completely powered off and unplugged from any existing power source.
3. **Locate Power Inlet:** Identify the AC power inlet on the back of your Sharp Aquos TV. This is typically a figure-8 shaped port.
4. **Connect to Device:** Insert the figure-8 (C7) connector end of the new power cord firmly into the power inlet on your television.
5. **Connect to Wall Outlet:** Plug the two-prong end of the power cord into a standard, grounded AC wall outlet.
6. **Power On Device:** You may now power on your television.



Figure 4.1: Close-up view of the power cord's connectors, illustrating the two-prong plug and the C7 (figure-8) connector for device attachment.

## 5. OPERATING INSTRUCTIONS

---

Once the power cord is correctly installed, the operation of your television remains unchanged. The power cord facilitates the electrical connection between the wall outlet and your television. Ensure the cord is not strained or bent sharply during use.

## 6. MAINTENANCE

---

The Accessory USA Replacement AC Power Cord requires minimal maintenance. Follow these guidelines to ensure its longevity:

- Keep the power cord clean and free from dust. Wipe with a dry, soft cloth if necessary.
- Regularly inspect the cord for any signs of damage, such as cuts, fraying, or exposed wires. Discontinue use immediately if damage is observed.
- Avoid coiling the cord too tightly, as this can stress the internal wires.
- Store the cord in a cool, dry place when not in use.

## 7. TROUBLESHOOTING

---

If you encounter issues, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
TV does not power on.	Power cord not fully inserted. Wall outlet not active.	Ensure both ends of the power cord are securely connected. Test the wall outlet with another device.
Power cord feels hot.	Overload or internal damage.	Immediately unplug the cord. Do not use if it feels excessively hot. Contact support if issues persist.
Loose connection.	Improper insertion or worn connectors.	Ensure the cord is fully inserted. If the connection remains loose, the cord or device port may be damaged.

## 8. SPECIFICATIONS

---

- **Product Type:** Replacement AC Power Cord
- **Brand:** Accessory USA
- **Connector Type (Wall):** 2-prong, Type A
- **Connector Type (Device):** C7 (Figure-8)
- **Length:** Approximately 48 inches (1.2 meters)
- **Safety Certifications:** CE, FCC, RoHS compliant
- **Protection Features:** OVP, OCP, SCP

## 9. COMPATIBILITY

---

This replacement AC power cord is compatible with, but not limited to, the following Sharp Aquos LCD HDTV models:

- Sharp Aquos LC-48LE551U
- Sharp Aquos LC-39LE551U
- Sharp Aquos LC46SE941U
- QACCZA076WJPZ
- QACCDA039WJPZ

Please verify your device's model number before purchasing to ensure proper fit and function.

## 10. WARRANTY AND SUPPORT

---

For information regarding warranty coverage or technical support, please refer to the contact information provided by your retailer or the Accessory USA official website. Keep your purchase receipt as proof of purchase.