

Fastrack NM3098SL02/NN3098SL02/NP3098SL02

Fastrack Analog Black Dial Men's Watch
INSTRUCTION MANUAL FOR MODEL NM3098SL02/NN3098SL02/NP3098SL02

- Overview
- Setup
- Operating
- Maintenance
- Introduction
- Product
- Troubleshooting
- Specifications
- Warranty & Support

1. Introduction

Thank you for choosing the Fastrack Analog Black Dial Men's Watch, Model NM3098SL02/NN3098SL02/NP3098SL02. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

2. Product Overview

Your Fastrack watch is a precision analog timepiece featuring a black dial, a durable mineral glass, and a comfortable brown leather strap. It is powered by a reliable quartz movement.



Figure 2.1: Front View of the Fastrack Analog Watch. This image displays the watch face with its black dial, hour markers, and hands. The round case and brown leather strap are also visible.



Figure 2.2: Back View of the Fastrack Analog Watch. This image shows the stainless steel case back, the crown (time-setting knob), and the buckle of the brown leather strap. Engravings on the case back indicate water resistance and brand information.

Key Components:

- **Dial:** The watch face displaying time.
- **Hands:** Hour, minute, and second hands indicating time.
- **Crown:** The knob on the side of the watch case used for setting the time.
- **Strap:** The brown genuine leather band securing the watch to your wrist.
- **Buckle:** The clasp mechanism on the strap for secure fastening.

3. Setup

3.1. Setting the Time

1. Gently pull the crown outwards to the first position.

2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position to start the watch movement.

3.2. Adjusting the Strap

The genuine leather strap features a tang buckle closure. To adjust, simply insert the pin of the buckle into the appropriate hole on the strap that provides a comfortable and secure fit on your wrist.

4. Operating

4.1. Reading the Time

The watch displays time using three hands: a short hand for hours, a long hand for minutes, and a thin hand for seconds. Read the position of these hands against the hour markers on the dial to determine the current time.

4.2. Water Resistance (50 Meters)

Your Fastrack watch is water resistant up to 50 meters (5 ATM). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is *not* suitable for swimming, diving, or prolonged water activities. Ensure the crown is fully pushed in before any contact with water.

5. Maintenance

5.1. Cleaning

- **Case and Glass:** Wipe the watch case and mineral glass with a soft, dry, lint-free cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Leather Strap:** Avoid prolonged exposure to water, direct sunlight, and harsh chemicals, as these can damage the leather. Clean the strap with a dry, soft cloth. Specialized leather cleaners can be used sparingly if necessary.

5.2. Battery Replacement

This watch is powered by a quartz movement requiring a battery. When the watch stops or runs erratically, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5.3. Storage

When not in use, store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from dust and scratches.

6. Troubleshooting

- **Watch Not Running:**
Check: Ensure the crown is fully pushed in. If it is, the battery may need replacement. Refer to Section 5.2.
- **Inaccurate Time:**
Check: Verify the time setting (Section 3.1). Strong magnetic fields can affect quartz watches; move the watch away from such sources. A low battery can also cause inaccurate timekeeping.
- **Water Inside the Watch:**
Action: If condensation or water appears inside the watch, immediately take it to a professional watch service

center. Do not attempt to open the watch yourself, as this can void the warranty and cause further damage.

7. Specifications

Model Name	NM3098SL02/NN3098SL02/NP3098SL02
Brand	Fastrack
Dial Color	Black
Case Shape	Round
Dial Glass Material	Mineral
Band Color	Brown
Band Material	Leather
Movement Type	Quartz
Display Type	Analog
Water Resistance Depth	50 Meters
Item Weight	400 Grams
Power Source Type	Battery Powered

8. Warranty and Support

8.1. Manufacturer's Warranty

Your Fastrack watch comes with a **24 months manufacturer warranty** on manufacturing defects from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from accidents, improper use, unauthorized repairs, or normal wear and tear.

8.2. Customer Support

For warranty claims, service, or any inquiries regarding your Fastrack watch, please refer to the contact information provided with your purchase documentation or visit the official Fastrack website for support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question