

[manuals.plus](#) /› [Blackweb](#) /› [Blackweb BWA17HO011 2.1 PC Speaker System User Manual](#)

## Blackweb BWA17HO011

# Blackweb BWA17HO011 2.1 PC Speaker System User Manual

## 1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Blackweb BWA17HO011 2.1 PC Speaker System. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

## 2. PACKAGE CONTENTS

Verify that all the following items are included in your package:

- 1 x Subwoofer Unit
- 2 x Satellite Speakers
- Necessary Audio and Power Cables (including a wired control puck with integrated audio cable)

## 3. COMPONENTS OVERVIEW

Familiarize yourself with the main components of your Blackweb 2.1 PC Speaker System.



**blackweb**



## PC STEREO SPEAKERS WITH SUBWOOFER WITH EASY-ACCESS VOLUME CONTROL AND 3.5 MM AUDIO INPUT



Figure 1: Blackweb BWA17HO011 2.1 PC Speaker System. This image displays the Blackweb 2.1 PC Speaker System, featuring a central subwoofer unit, two compact satellite speakers, and a small, circular wired control puck. The control puck has an 'AUX IN' port and controls for volume and bass. The overall design is black.

### 3.1 Subwoofer

The central unit that produces deep bass sounds. It houses the main connections for power, satellite speakers, and the audio input from your device.

### 3.2 Satellite Speakers

Two compact speakers designed to deliver clear mid-range and high-frequency audio. These connect to the subwoofer.

### 3.3 Wired Control Puck

A convenient desktop control unit for managing your speaker system. It typically includes:

- **Power Control:** To turn the system on or off.
- **Volume Control:** To adjust the overall sound level.
- **Bass Control:** To adjust the intensity of the bass output.
- **AUX IN (3.5 mm Audio Input):** For connecting external audio devices directly to the control puck.

## 4. SETUP INSTRUCTIONS

Follow these steps to set up your Blackweb 2.1 PC Speaker System:

- Positioning:** Place the subwoofer on the floor or a sturdy surface near your computer or audio source. Position the satellite speakers on either side of your monitor or listening area, ensuring they are facing you for optimal sound.
- Connect Satellite Speakers:** Connect the cables from the two satellite speakers into the corresponding output ports on the back of the subwoofer. Ensure a secure connection.
- Connect Audio Input:** Locate the 3.5 mm audio cable extending from the wired control puck. Plug this cable into the headphone jack or audio output port of your computer, laptop, television, or other audio device. *Note: This model typically uses a single 3.5mm green plug for audio input directly to your device. An additional 'third cord' for older models is generally not required for the BWA17HO011 if the control puck does not have a dedicated input for it.*
- Connect Power:** Plug the power cable from the subwoofer into a standard electrical outlet.
- Power On:** Use the power control on the wired control puck to turn on the speaker system. The power indicator light should illuminate.

## 5. OPERATING YOUR SPEAKER SYSTEM

### 5.1 Power On/Off

Press the power button on the wired control puck to turn the speakers on or off. An indicator light will confirm the power status.

### 5.2 Adjusting Volume

Rotate the volume dial on the wired control puck clockwise to increase volume and counter-clockwise to decrease it. You may also need to adjust the volume on your connected audio device.

### 5.3 Adjusting Bass

Rotate the bass control dial on the wired control puck to increase or decrease the subwoofer's bass output according to your preference.

### 5.4 Using the AUX IN Port

To play audio from a portable device (e.g., smartphone, MP3 player), connect a 3.5 mm audio cable from your device's headphone jack to the AUX IN port on the wired control puck. This input will typically override the main audio input from your computer.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your speaker system, follow these maintenance guidelines:

- Cleaning:** Use a soft, dry cloth to clean the surfaces of the speakers and subwoofer. Do not use liquid cleaners or abrasive materials, as they may damage the finish or internal components.
- Placement:** Avoid placing the speakers in direct sunlight, near heat sources, or in areas with high humidity or dust. Ensure adequate ventilation around the subwoofer.
- Cable Management:** Keep cables organized and free from kinks or excessive bending to prevent damage.

## 7. TROUBLESHOOTING

If you encounter issues with your Blackweb BWA17HO011 speaker system, refer to the following common problems

and solutions:

Problem	Possible Cause	Solution
No sound from speakers	<ul style="list-style-type: none"> <li>Speakers not powered on</li> <li>Volume too low</li> <li>Audio cable disconnected</li> <li>Incorrect audio source selected on device</li> </ul>	<ul style="list-style-type: none"> <li>Ensure power is on via control puck</li> <li>Increase volume on control puck and audio device</li> <li>Check all audio cable connections</li> <li>Verify correct audio output is selected on your computer/device</li> </ul>
Distorted or unclear sound	<ul style="list-style-type: none"> <li>Volume too high (on speakers or source)</li> <li>Loose cable connections</li> <li>Audio source issue</li> </ul>	<ul style="list-style-type: none"> <li>Reduce volume on speakers and/or audio device</li> <li>Check all cable connections for security</li> <li>Test with a different audio source or cable</li> </ul>
Subwoofer not producing bass	<ul style="list-style-type: none"> <li>Bass control set too low</li> <li>Subwoofer not powered</li> </ul>	<ul style="list-style-type: none"> <li>Increase bass level on the control puck</li> <li>Ensure the entire system is powered on</li> </ul>
Power indicator not lit	<ul style="list-style-type: none"> <li>Power cable disconnected</li> <li>Power outlet not active</li> </ul>	<ul style="list-style-type: none"> <li>Check power cable connection to subwoofer and outlet</li> <li>Test outlet with another device</li> </ul>

## 8. SPECIFICATIONS

Model Name	BWA17HO011
Speaker Type	Subwoofer, Satellite
Surround Sound Channel Configuration	2.1
Connectivity Technology	Wired
Power Source	Corded Electric
Control Method	Touch (via control puck)
Speaker Maximum Output Power	100 Watts
Compatible Devices	Desktop, Laptop, Televisions, Music Players
Item Weight	7.2 Pounds
Product Dimensions (LxWxH)	15 x 10.9 x 9.5 inches
Color	Black

## 9. WARRANTY AND SUPPORT

### 9.1 Limited Warranty


This Blackweb BWA17HO011 2.1 PC Speaker System comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers defects in materials and workmanship under normal use.

### 9.2 Customer Support

For technical assistance, warranty claims, or further inquiries, please contact Blackweb customer support. Refer to the product packaging or the official Blackweb website for current contact information.

Blackweb BWA17HO011 User Manual © 2023 Blackweb. All rights reserved.

### Related Documents - BWA17HO011

	<p><a href="#"><u>blackweb 32" Smart Soundbar BWC18SB001 Quick Start Guide and Manual</u></a></p> <p>Get started with your blackweb 32" Smart Soundbar (Model BWC18SB001). This guide provides setup instructions, connection options, maintenance tips, and troubleshooting for your audio device.</p>
	<p><a href="#"><u>Quick Start Guide - BWA18SB001 Soundbar</u></a></p> <p>Concise guide to setting up and connecting the BWA18SB001 soundbar, including package contents, button identification, connection options, and Bluetooth pairing. Features troubleshooting tips.</p>
	<p><a href="#"><u>Blackweb BWB15TA223 Portable Charger 8000 mAh Product Guide</u></a></p> <p>Official product guide for the Blackweb BWB15TA223 Portable Charger 8000 mAh, covering setup, usage, troubleshooting, safety, and warranty information.</p>
	<p><a href="#"><u>blackweb™ BWA16AA003 Hi-Fi Bluetooth Stereo with CD Player &amp; FM Radio - Product Guide</u></a></p> <p>Comprehensive product guide for the blackweb™ BWA16AA003 Hi-Fi Bluetooth Stereo system, featuring CD playback, FM radio, Bluetooth connectivity, USB charging, and ambient lighting. Includes safety instructions, operation guides, and technical specifications.</p>



### [Blackweb 6-Device Universal Remote User Guide \(BWB17AV002\)](#)

Comprehensive user guide for the Blackweb BWB17AV002 6-Device Universal Remote Control, covering setup, programming, features, troubleshooting, FCC information, and warranty details.



### [Blackweb BWB17AV002 6-Device Universal Remote Control User Guide](#)

Comprehensive user guide for the Blackweb BWB17AV002 6-Device Universal Remote Control, covering setup, programming, features, troubleshooting, and warranty information.