Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- **BONECO** /
- > BONECO U330 Warm Mist Ultrasonic Humidifier User Manual

BONECO U330

BONECO U330 Warm Mist Ultrasonic Humidifier

USER MANUAL

Introduction

Thank you for choosing the BONECO U330 Warm Mist Ultrasonic Humidifier. This manual provides important information regarding the safe operation, setup, maintenance, and troubleshooting of your new humidifier. Please read it thoroughly before using the appliance and keep it for future reference.

The BONECO U330 is designed to provide optimal humidity levels in rooms up to 650 sq ft, featuring a convenient top-fill design, integrated humidistat, and warm mist output for enhanced comfort.



Figure 1: The BONECO U330 Warm Mist Ultrasonic Humidifier. This image shows the main unit with its sleek white design, black top, and the blue illuminated control dial at the bottom front.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Always place the humidifier on a firm, flat, level surface.
- Do not block air openings.

- Do not immerse the appliance in water or other liquids.
- Unplug the humidifier from the power outlet when not in use and before cleaning.
- Keep out of reach of children.
- Use only clean, cool tap water. Do not use hot water.
- Do not add essential oils directly into the water tank unless using the designated fragrance tray.

Product Components

The BONECO U330 consists of the following main components:

- · Main Unit with integrated water tank
- · Control Dial with LED indicator
- Mist Outlet
- Water Fill Opening (Top-fill)
- Fragrance Tray
- AQUA Pro Filter (pre-installed or included)
- Power Cord

Setup

- 1. Unpacking: Carefully remove the humidifier from its packaging. Retain packaging for future storage or transport.
- 2. **Placement:** Place the humidifier on a flat, stable, water-resistant surface at least 6 inches (15 cm) away from walls and furniture. Ensure the mist outlet is not directed at walls or furniture.
- 3. Initial Fill:

Open the top cover of the humidifier. Pour clean, cool tap water directly into the water tank through the top opening. Fill up to the MAX line indicated inside the tank. Close the top cover securely.



Figure 2: Easily filling the BONECO U330 from the top. This image illustrates the convenience of the top-fill design, showing water being poured directly into the open top of the humidifier, eliminating the need to lift or carry a heavy water tank.

4. Power Connection: Plug the power cord into a suitable electrical outlet.

Operation

- 1. **Power On/Off:** Turn the control dial clockwise from the "OFF" position to switch on the humidifier. The LED ring around the dial will illuminate. To turn off, rotate the dial counter-clockwise to the "OFF" position.
- 2. Adjusting Humidity Level:

The BONECO U330 features a built-in humidistat. Rotate the control dial to adjust the desired humidity output. Turning the dial towards "MAX" increases the mist output and target humidity. The humidifier will automatically turn on and off to maintain the set humidity level (ideally between 45-60%).

Integrated Hygrostat - How It Works



Solid BlueOperating (Misting)



Fading Blue
Optimal Level Reached
(No Misting)



Blinking Red Add Water (Empty)

Figure 3: Integrated Hygrostat Indicator. This image displays three states of the control dial's LED: Solid Blue (Operating/Misting), Fading Blue (Optimal Level Reached/No Misting), and Blinking Red (Add Water/Empty Tank). This visual guide helps users understand the humidifier's current status.

- 3. **Warm Mist Function:** The BONECO U330 produces warm mist, which exits at approximately 45°C (113°F). Please allow up to 15 minutes for the water to heat up and for warm mist to begin.
- 4. Scented Humidification (Optional):

Locate the small fragrance tray on the side or back of the unit. Add a few drops of your favorite essential oil onto the felt pad within the tray. Do not add essential oils directly into the water tank. The humidifier will diffuse the scent along with the mist.



Figure 4: Adding essential oils for scented humidification. This image shows a hand carefully adding drops of essential oil into the dedicated fragrance tray, highlighting the feature for diffusing scents without contaminating the main water tank.

5. **Low Water Indicator:** When the water level is low, the LED ring around the control dial will blink red, indicating that water needs to be refilled.

Maintenance

Regular cleaning and maintenance are crucial for optimal performance and longevity of your humidifier.

1. Daily Maintenance:

- Empty and rinse the water tank daily.
- Refill with fresh, cool tap water.

2. Weekly Cleaning:

- · Unplug the unit.
- · Empty any remaining water.
- Use the included EZCal Cleaning Solution (follow package instructions) or a descaling agent (e.g., white vinegar) to clean the water tank and base.
- Wipe down all surfaces with a soft, damp cloth.
- · Rinse thoroughly to remove any cleaning solution residue.

3. AQUA Pro Filter:

The 2-in-1 AQUA Pro filter helps ensure pure humidification without residue. The filter life depends on water hardness and usage. Replace the filter when the humidifier's performance decreases or when mineral deposits become

noticeable. Refer to the filter packaging for specific replacement intervals.

4. Storage:

If storing the humidifier for an extended period, ensure it is completely clean and dry. Store it in a cool, dry place, preferably in its original packaging.

Troubleshooting

If you experience issues with your BONECO U330, please consult the following common problems and solutions:

Problem	Possible Cause	Solution
No mist output	Water tank empty Unit not plugged in Humidistat setting too low Mineral buildup on transducer	Refill water tank Check power connection Increase humidistat setting Clean the transducer with EZCal solution
Blinking red light	Low water level	Refill water tank
Unpleasant odor from mist	Stagnant water Dirty water tank/base	Empty and rinse tank daily Clean the unit thoroughly with EZCal solution
White dust around unit	Hard water minerals	Replace AQUA Pro filter or use distilled water

Specifications



Figure 5: Dimensions of the BONECO U330 Humidifier. This image provides a visual representation of the humidifier's size, with measurements of 12.75 inches in height, 12.13 inches in width, and 6.5 inches in depth.

Feature	Detail
Model	BONECO U330
Туре	Warm Mist Ultrasonic Humidifier

Feature	Detail
Capacity	3.17 Gallons (approx. 12 liters)
Output	Up to 3.17 gal/day
Recommended Room Size	Up to 650 sq ft
Operation Mode	Ultrasonic
Mist Temperature	Approx. 45°C / 113°F (Warm Mist)
Noise Level	Whisper quiet operation
Included Components	Power cord, AQUA Pro Filter, EZCal Cleaner packet, quick setup guide
Item Weight	3.27 kg
Color	White
UPC	834546000961

Warranty and Support

BONECO products are manufactured with high quality standards. For information regarding warranty coverage, technical support, or to purchase replacement parts and filters, please visit the official BONECO website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, please refer to the contact information provided with your product packaging or on the manufacturer's official website.

© 2024 BONECO. All rights reserved. Information subject to change without notice.

Related Documents - U330



BONECO 7135 Ultrasonic Humidifier User Manual

User manual for the BONECO 7135 Ultrasonic Humidifier, providing setup, operation, maintenance, and troubleshooting guidance to ensure optimal indoor air quality and comfort.



BONECO U650 Ultrasonic Humidifier User Manual

Comprehensive user manual for the BONECO U650 Ultrasonic Humidifier. Learn how to safely set up, operate, clean, and maintain your humidifier for optimal indoor air quality. Includes troubleshooting tips and essential safety information.



BONECO U350 Humidifier User Manual - Healthy Air

Comprehensive user manual for the BONECO U350 ultrasonic humidifier. Learn about setup, operation, maintenance, and features for optimal healthy room air. Includes technical data and troubleshooting.

BONECO STATEMENT OF THE PROPERTY OF THE PROPER	BONECO U700 Ultrasonic Humidifier Quick Manual Concise quick manual for the BONECO U700 ultrasonic humidifier, covering first use, cleaning, and technical specifications. Download the full manual for detailed information and safety guidelines.
BONECO WEST USO MANUAL Litera and defining from subdiving Litera and defining from subdiving from subdiving Litera and defining from subdiving	BONECO U50 Humidifier User Manual and Instructions Comprehensive user manual for the BONECO U50 ultrasonic humidifier, detailing its features, operation, technical specifications, first use, cleaning, and troubleshooting. Includes safety information and manufacturer details.
BONECO STATE OF THE PROPERTY O	BONECO U330 Humidifier User Manual and Instructions Comprehensive guide for the BONECO U330 humidifier, covering setup, operation, maintenance, and technical specifications. Learn how to use and care for your BONECO U330 for optimal air quality.