

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Salter](#) /

› [Salter EK2408 Individual Filter Coffee Maker to Go Instruction Manual](#)

Salter EK2408

Salter EK2408 Individual Filter Coffee Maker to Go Instruction Manual

Model: EK2408

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Salter EK2408 Individual Filter Coffee Maker to Go. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed for brewing a single cup of filter coffee using ground coffee or coffee pads.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Unplug the appliance from the mains supply when not in use and before cleaning.
- Do not operate the appliance if the power cord or plug is damaged. Contact qualified personnel for repair.
- Avoid contact with hot surfaces. Use handles or knobs.
- This appliance is for household use only. Do not use outdoors.
- Ensure the water reservoir is filled only with cold water.
- **Note:** This item is equipped with a UK plug. An adapter may be required for use in other regions.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Salter EK2408 Coffee Maker:

1. Main Unit (Coffee Maker Base)
2. Water Reservoir (internal)
3. Filter Basket
4. Reusable Filter
5. Lid

6. Power Switch / Indicator Light

7. 420ml Stainless Steel Travel Mug with Lid



Figure 1: Salter EK2408 Coffee Maker with its components, including the main unit and the stainless steel travel mug with its lid removed, ready for use.

SETUP BEFORE FIRST USE

Before using your coffee maker for the first time, follow these steps:

1. Unpack all components and remove any packaging materials.
2. Wipe the exterior of the coffee maker with a damp cloth.
3. Wash the reusable filter and travel mug with warm, soapy water. Rinse thoroughly and dry.
4. Perform a trial run:
 - Fill the water reservoir with cold water up to the MAX fill line.
 - Place the reusable filter into the filter basket (without coffee).
 - Place the travel mug (without its lid) on the drip tray.
 - Close the lid securely.
 - Plug the appliance into a suitable power outlet.

- Press the power switch to start the brewing cycle.
- Allow the water to run through completely. Discard the water.

5. Your coffee maker is now ready for use.

OPERATING INSTRUCTIONS

Follow these steps to brew your coffee:

1. **Prepare the Filter:** Open the lid of the coffee maker. Place the reusable filter into the filter basket.
2. **Add Coffee:** Add your desired amount of ground coffee or a coffee pad into the reusable filter. For optimal taste, refer to coffee packaging for recommended quantities.



Figure 2: Illustration of adding ground coffee into the reusable filter of the Salter EK2408 Coffee Maker.

3. **Add Water:** Fill the water reservoir with cold water. Do not exceed the MAX fill line. The travel mug has a capacity of 420ml, which is the recommended maximum water volume.
4. **Position Mug:** Place the stainless steel travel mug (without its lid) onto the drip tray, ensuring it is centered under the coffee dispenser. Alternatively, a standard coffee mug can be used.



Figure 3: The Salter EK2408 Coffee Maker shown brewing coffee directly into a standard coffee mug, with the travel mug placed beside it.

5. **Close Lid:** Close the lid of the coffee maker securely.
6. **Start Brewing:** Plug the appliance into a suitable power outlet. Press the power switch. The indicator light will illuminate, and brewing will begin.



Figure 4: A hand pressing the power button located on the side of the Salter EK2408 Coffee Maker to initiate brewing.

- Brewing Complete:** The brewing process typically takes 3-4 minutes. The indicator light will turn off when brewing is complete, and the appliance will automatically shut off.
- Serve:** Carefully remove the travel mug. If using the travel mug, secure its lid for on-the-go consumption.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Reusable Filter:** Remove the reusable filter and discard used coffee grounds. Wash the filter with warm, soapy water and rinse thoroughly.
- **Travel Mug:** Wash the travel mug and its lid with warm, soapy water. Rinse well.
- **Exterior:** Wipe the exterior of the coffee maker with a damp cloth. Do not use abrasive cleaners or scouring pads.
- **Descaling:** Depending on water hardness, descaling may be required periodically (e.g., every 2-3 months). Use a commercial descaling solution suitable for coffee makers or a mixture of white vinegar and water (1:1 ratio). Run the solution through a brewing cycle without coffee, then run 2-3 cycles with plain water to rinse.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure appliance is securely plugged in. Check power supply. Try a different outlet.
Coffee is not brewing.	No water in reservoir; lid not closed properly.	Fill water reservoir. Ensure lid is securely closed.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio; coffee grind too coarse/fine.	Adjust amount of coffee. Use appropriate grind for filter coffee.
Slow brewing or clogging.	Mineral buildup (scale); filter clogged.	Descale the coffee maker. Clean the reusable filter thoroughly.

SPECIFICATIONS

- **Model Number:** EK2408
- **Brand:** Salter
- **Power:** 700 W
- **Voltage:** 220 Volts
- **Material:** Stainless Steel (travel mug), Plastic (main unit)
- **Color:** Black/Stainless Steel
- **Product Dimensions (L x W x H):** 17.5 x 13 x 24.5 cm
- **Item Weight:** 850 g
- **Travel Mug Capacity:** 420 ml
- **Special Feature:** Non-disposable filter, Automatic shut-off

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation provided with your purchase or contact Salter customer service directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Salter

Website: www.salter.com (This is a placeholder link, please verify the official support website if available.)