

[Manuals.plus](#) /

› [TENGA](#) /

› TENGAFlex Silky White Instruction Manual

## TENGA FLX-001

# TENGA Flex Silky White Instruction Manual

Model: FLX-001

Brand: TENGA

## INTRODUCTION

The TENGA Flex Silky White is an innovative product designed to provide a unique and flexible experience. Its advanced structure allows for dynamic sensations, adapting to your movements for enhanced pleasure. This manual provides essential information on how to set up, use, clean, and maintain your TENGA Flex Silky White for optimal performance and longevity.

Key features include a special valve for adjustable pressure and vacuum sensation, an hourglass shape for sublime tightness, a thermoplastic elastomer (TPE) sleeve with soft details for gentle stimulation, and a flex-soft elastomer ribbed outer casing designed to twist with every stroke.

## SETUP

### Unboxing and Initial Preparation

Upon unboxing your TENGA Flex Silky White, ensure all components are present: the main outer casing and the inner elastomer sleeve. The product comes with a sample of water-based lubricant for initial use. For optimal experience, additional water-based lubricant is highly recommended.



Figure 1: The TENGA Flex Silky White product.



**Gentle spiraling ribs embrace  
with delightful suction.**


Figure 2: The TENGA Flex Silky White showing the outer casing and removable inner sleeve.

Before first use, it is advisable to rinse the inner sleeve with tepid water. Ensure it is completely dry before applying lubricant.

## OPERATING INSTRUCTIONS

### Using Your TENGA Flex Silky White

To use, first remove the cap and the inner elastomer sleeve from the outer casing. Apply a generous amount of water-based lubricant to the inside of the sleeve and the insertion point. The unique malleable spiral-ribbed casing is designed to unwind as you insert, creating a twisting motion for a distinct sensation. You can control the intensity and suction by covering the air hole at the top of the unit with your finger during use. This creates a strong internal vacuum, enhancing the spiraling sensation.



**Cover the air hole to create an internal vacuum!**  
**Using the item with the air hole covered**  
**also provides a brand new spiraling sensation!**

Figure 3: Covering the air hole to create a vacuum for enhanced sensation.

### Official Product Video: How to Use

Your browser does not support the video tag.

This video demonstrates the proper way to use the TENGA Flex, including how to apply lubricant and how the flexible casing adapts during use. It also shows how to create a vacuum for stronger sensations.

### Cleaning After Use

Proper cleaning is essential for hygiene and to prolong the life of your TENGA Flex Silky White. After each use, carefully remove the inner elastomer sleeve from the outer casing. Wash the sleeve thoroughly under tepid running water with mild soap. Ensure all lubricant residue is removed. The sleeve can be inverted for easier cleaning of the internal textures.

### Drying and Storage

Pat the sleeve dry with a clean, lint-free cloth. To air dry completely, invert the cap and use it as a stand. Place the elastomer sleeve onto this stand to allow for proper air circulation. Once fully dry, place the sleeve back into the outer casing and close the cap for storage. Store in a cool, dry place away from direct sunlight and extreme temperatures.



**Invert the Stand Cap to use as a drying stand.  
Place Elastomer Sleeve on the Stand Cap to air dry.**

Figure 4: The inverted cap serves as a convenient drying stand for the elastomer sleeve.

### Official Product Video: How to Wash

Your browser does not support the video tag.

This video illustrates the step-by-step process for cleaning and drying the TENGA Flex, ensuring proper hygiene and product longevity.

Common Issues and Solutions

- Reduced Suction:** Ensure the air hole at the top of the unit is fully covered with your finger during use to create the desired vacuum effect.
- Discomfort/Too Tight:** Apply a generous amount of water-based lubricant to both the inside of the sleeve and the insertion point. If discomfort persists, ensure the product is suitable for your personal preferences.
- Difficulty Cleaning:** Ensure the inner sleeve is fully inverted and rinsed thoroughly with tepid water and mild soap. Allow ample time for air drying on the inverted cap stand.

For any persistent issues not covered here, please refer to the support section or contact customer service.

PRODUCT SPECIFICATIONS

| Feature                        | Detail                        |
|--------------------------------|-------------------------------|
| Model Number                   | FLX-001                       |
| Brand                          | TENGA                         |
| Color                          | White                         |
| Material                       | Thermoplastic Elastomer (TPE) |
| Product Dimensions (L x W x H) | 6.93 x 2.89 x 2.89 inches     |
| Item Weight                    | 4.23 ounces                   |
| Country of Origin              | Japan                         |
| Date First Available           | June 1, 2017                  |

WARRANTY AND SUPPORT

Warranty Information

TENGA products are manufactured to high-quality standards. Please retain your proof of purchase for any warranty claims. Specific warranty details and coverage periods may vary by region and retailer. For the most accurate and up-to-date warranty information, please visit the official TENGA website or consult the documentation included with your purchase.

Customer Support

For further assistance, product inquiries, or technical support, please contact TENGA customer service. Contact information can typically be found on the product packaging, the official TENGA website ([TENGA Store](#)), or through authorized retailers. When contacting support, please have your product model number (FLX-001) and purchase details ready.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**