

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hauck](#) /

› [Hauck Sirocco Pedal Go Kart Instruction Manual - Model T90704](#)

Hauck T90704

Hauck Sirocco Pedal Go Kart Instruction Manual

Model: T90704 | Brand: Hauck

1. INTRODUCTION

The Hauck Sirocco Pedal Go Kart is designed to provide an authentic driving experience for young riders. This manual contains important information regarding the assembly, safe operation, and maintenance of your Go Kart. Please read it thoroughly before use and retain it for future reference.



Figure 1.1: The Hauck Sirocco Pedal Go Kart, featuring its sporty design and pedal-powered mechanism.

2. SAFETY INFORMATION

Always prioritize safety when operating the Go Kart. Failure to follow safety instructions may result in injury.

- **Adult Supervision:** Always ensure an adult supervises children during operation.
- **Protective Gear:** Riders should wear a helmet, knee pads, and elbow pads.
- **Operating Environment:** Use the Go Kart on flat, even surfaces away from traffic, steep inclines, and water.
- **Weight Limit:** Do not exceed the maximum weight capacity of 132 lbs.
- **Age Recommendation:** Suitable for children aged 4 to 12 years.

3. SETUP AND ASSEMBLY

The Hauck Sirocco Pedal Go Kart requires assembly. Follow these general steps. Refer to the detailed assembly guide included in the product packaging for specific instructions and diagrams.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify all components are present against the parts list.
2. **Attach Wheels:** Securely attach the low-profile rubber tires to the axle using the provided hardware.
3. **Install Steering Column:** Connect the steering column to the front axle and steering wheel.
4. **Mount Seat:** Attach the ergonomic seat to the frame. Ensure it is securely fastened.
5. **Adjust Seat Position:** The seat is adjustable to accommodate different rider heights. Adjust the seat forward or backward for a comfortable and safe pedaling position.
6. **Final Checks:** Before first use, ensure all nuts, bolts, and fasteners are tight and secure.




Figure 3.1: Key features including the adjustable seat mechanism and the hand brake lever for controlled stopping.

4. OPERATING INSTRUCTIONS

The Sirocco Pedal Go Kart is operated using pedal power and a steering wheel.

- **Starting:** Sit comfortably in the seat with your feet on the pedals. Use your feet to push the pedals in a circular motion to move forward.
- **Steering:** Use the steering wheel to control the direction of the Go Kart. Turn the wheel left to go left and right to go right.
- **Braking:** The Go Kart features a hand brake lever located near the seat. Squeeze the lever to engage the brake and slow down or stop.
- **Auto-Clutch Free-Ride:** The auto-clutch system allows for free-wheeling when not pedaling, providing a smooth ride.

Your browser does not support the video tag.

Video 4.1: Official product video demonstrating the Hauck Sirocco Pedal Go Kart in action, highlighting its features and ease of use.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your Go Kart.

- **Cleaning:** Clean the Go Kart with a damp cloth and mild soap. Avoid harsh chemicals.
- **Lubrication:** Periodically lubricate moving parts such as the chain and axle bearings.
- **Inspections:** Regularly check for loose bolts, worn tires, or damaged parts. Replace any damaged components immediately.
- **Storage:** Store the Go Kart in a dry, covered area to protect it from weather elements.

6. TROUBLESHOOTING

If you encounter issues with your Go Kart, refer to the following common problems and solutions:

- **Difficulty Pedaling:** Check if the chain is properly aligned and lubricated. Ensure no debris is obstructing the pedals or wheels.
- **Steering Issues:** Verify the steering column is securely attached and not bent. Check for any obstructions preventing smooth steering.
- **Brake Malfunction:** Inspect the brake lever and cable for damage or looseness. Adjust the brake tension if necessary.

7. SPECIFICATIONS



Figure 7.1: Visual representation of the Go Kart's dimensions.

Feature	Detail
Model Number	T90704
Product Dimensions	47.6 x 28.3 x 28.3 inches (L x W x H)
Item Weight	28 pounds
Recommended Age	4 - 12 years
Maximum Weight Capacity	132 lbs
Tire Type	Low-profile rubber tires with bearings
Drive System	Pedal power with auto-clutch free-ride
Seat	Adjustable ergonomic seat with high backrest

8. WHAT'S IN THE Box

- Hauck Sirocco Pedal Go Kart (unassembled)

- Assembly Hardware
- Instruction Manual



Figure 8.1: The product packaging, indicating the contents and key features.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Hauck customer service. Details can typically be found on the product packaging or the official Hauck website. Keep your purchase receipt as proof of purchase.

© 2025 Hauck. All rights reserved.