

Manuals.plus /

› MIUFLY /

› MIUFLY EH15-64GB Body Camera Instruction Manual

MIUFLY EH15-64GB

MIUFLY EH15-64GB Body Camera Instruction Manual

Model: EH15-64GB

INTRODUCTION

Thank you for choosing the MIUFLY EH15-64GB Body Camera. This device is designed for reliable full-HD video recording in various indoor and outdoor environments, offering advanced features such as GPS tracking, night vision, and password protection. Please read this manual thoroughly to ensure proper operation and maintenance of your body camera.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- MIUFLY EH15-64GB Body Camera
- USB Cable
- Charging Dock
- Universal Metal Clip
- Epaulet Clip
- User Manual



Image: The MIUFLY EH15-64GB Body Camera, user manual, USB cable, universal metal clip, epaulet clip, and charging dock are included in the package.

SETUP

1. Initial Charging

Before first use, fully charge the body camera. Connect the USB cable to the charging dock and then to a power source. Place the camera into the charging dock. The charging indicator will show the charging status.



Image: The MIUFLY EH15-64GB Body Camera is shown seated in its charging dock, indicating it is ready for charging.

2. Attaching the Clip

The camera comes with a universal metal clip and an epaulet clip. Select the appropriate clip for your intended use. The universal metal clip allows for 360-degree rotation for flexible mounting options on belts, pockets, or shoulder straps.

360 Degree Rotatable Clip



Image: The back of the MIUFLY EH15-64GB Body Camera is displayed, highlighting its 360-degree rotatable clip for versatile attachment.

OPERATING INSTRUCTIONS

1. Power On/Off

Press and hold the Power button to turn the camera on or off. The 2-inch LCD screen will activate upon power-on.

2. Video Recording

To start video recording, press the dedicated video record button. Press it again to stop. The camera supports 1296p video capture resolution.

3. Audio Recording

To record audio only, press the dedicated audio record button. Press it again to stop.

4. Taking Photos

Press the dedicated photo button to capture still images. The camera supports various photo resolutions up to 32M.

5. Night Vision Activation

The camera features infrared night vision. This can be set to manual, auto, or off via the camera settings. In manual mode, press the night vision button to activate or deactivate.

6. GPS Functionality

The built-in GPS allows you to view the movement track on a compatible GPS player. This feature can be toggled on or off in the settings.

7. Password Protection

For enhanced security, you can set a password for the camera to prevent unauthorized access to recorded files. This setting is configurable in the camera menu.

8. Car DV Mode and Loop Recording

The camera supports Car DV Mode for use as a dashcam, and loop recording to continuously record by overwriting the oldest files when memory is full. These modes can be enabled in the settings.

9. Motion Detection

Activate motion detection in the settings to automatically start recording when movement is sensed, conserving battery and storage space.

MAINTENANCE

1. Cleaning

Use a soft, dry cloth to clean the camera body and lens. Avoid using harsh chemicals or abrasive materials that could damage the device.

2. Storage

Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before long-term storage to maintain battery health.

3. Firmware Updates

Periodically check the MIUFLY official website for any available firmware updates to ensure optimal performance and access to new features. Follow the instructions provided with the update carefully.

TROUBLESHOOTING

Camera Not Powering On

- Ensure the battery is fully charged. Connect to the charging dock and verify the charging indicator.
- If the camera vibrates uncontrollably or makes unusual noises, this may indicate a hardware issue. Disconnect from power and contact customer support.

Recording Issues

- **Video/Audio Quality:** Ensure the lens is clean and free from obstructions. Check the selected resolution settings in the camera menu.
- **Missing Footage:** Verify that recording was properly initiated and stopped. Check storage capacity (64GB built-in).
- **Audio Interference:** If using in a vehicle with a power connection, some interference may occur. Test recording in different environments.

File Transfer/Deletion

- Connect the camera to a computer via USB. The camera should be recognized as an external hard drive.
- Files can be deleted directly from the camera via the menu options.

SPECIFICATIONS

Feature	Detail
Model Number	EH15-64GB
Video Capture Resolution	1296p
Screen Size	2 Inches
Internal Memory	64GB (Flash Memory Type: Micro SD)
Battery	3200mAh Lithium Polymer (up to 10 hours recording)
Dimensions	3.66 x 1.18 x 2.17 inches
Item Weight	6.5 ounces
Photo Sensor Technology	CMOS
Video Capture Format	MP4
Supported Audio Format	WAV
Connectivity Technology	Wired

WARRANTY INFORMATION

The MIUFLY EH15-64GB Body Camera comes with a standard manufacturer's warranty. Please refer to the product packaging or the official MIUFLY website for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your MIUFLY EH15-64GB Body Camera that are not covered in this manual, please contact MIUFLY customer support through the official website or your retailer. Provide your model number and a detailed description of the issue for efficient assistance.