

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Alarm.com](#) /

> [Alarm.com ADC-V723 1080p Outdoor Wi-Fi Camera User Manual](#)

Alarm.com ADC-V723x

Alarm.com ADC-V723 Outdoor Wi-Fi Camera User Manual

Model: ADC-V723x

1. PRODUCT OVERVIEW

The Alarm.com ADC-V723 is a high-definition 1080p outdoor Wi-Fi camera designed to provide reliable surveillance for your property. Featuring High Dynamic Range (HDR) and powerful Video Analytics, it can detect and alert you to people, vehicles, and animals. Its robust design ensures performance in various lighting conditions and environments. This manual provides comprehensive instructions for installation, operation, and maintenance.



Image: Front view of the Alarm.com ADC-V723 Outdoor Wi-Fi Camera, showing its compact, bullet-style design and lens.

2. SAFETY INFORMATION

- Ensure the camera is installed in a location that complies with local building codes and regulations.
- Use only the power adapter supplied with the camera.

- Do not expose the camera to extreme temperatures outside its operating range.
- Avoid placing the camera near sources of strong electromagnetic interference.
- Disconnect power before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Alarm.com ADC-V723 Outdoor Wi-Fi Camera
- Mounting Plate
- Mounting Screws and Wall Anchors
- Power Adapter
- Installation Guide (this document)

4. SETUP AND INSTALLATION

4.1 Choosing a Location

Select an outdoor location that provides the desired viewing angle and is within range of your Wi-Fi network. The camera is designed for outdoor use and is IP67 rated for weather resistance. Consider areas with good lighting or where the camera's night vision capabilities can be maximized.

4.2 Mounting the Camera

1. Secure the mounting plate to the desired surface using the provided screws and wall anchors. Ensure the plate is level.
2. Attach the camera to the mounting plate by aligning the camera with the plate and twisting until it locks securely.
3. Adjust the camera's angle to achieve the optimal field of view.



Image: Exploded view showing the Alarm.com ADC-V723 camera, its mounting plate, and a screw with wall anchor, illustrating the assembly process.

4.3 Powering On and Connecting to Wi-Fi

1. Connect the power adapter to the camera and plug it into a suitable outdoor power outlet.
2. Wait for the camera's LED indicator to show a specific status (refer to the LED status guide in Section 5.2).
3. Download the Alarm.com mobile application from your device's app store.
4. Follow the in-app instructions to add the ADC-V723 camera to your Alarm.com system and connect it to your Wi-Fi network. This typically involves scanning a QR code on the camera or entering its MAC address.

5. OPERATING THE CAMERA

5.1 Live View and Recording

Access live video feeds and recorded clips through the Alarm.com mobile app or web portal. You can view real-time footage, initiate manual recordings, and review event-triggered clips.

5.2 LED Status Indicators

The camera features an LED indicator that communicates its current status:

- **Solid Green:** Connected to Wi-Fi and operating normally.
- **Flashing Green:** Attempting to connect to Wi-Fi.
- **Solid Red:** Not connected to Wi-Fi or an error has occurred.
- **Flashing Red:** Firmware update in progress or factory reset.

5.3 Video Analytics and Alerts

The ADC-V723 supports advanced Video Analytics. Configure detection zones and rules within the Alarm.com app to receive specific alerts for people, vehicles, or animals entering designated areas. Alerts can be customized to send notifications to your mobile device.

5.4 Night Vision and HDR

The camera is equipped with infrared night vision, allowing clear video capture up to 40 feet in low-light conditions. High Dynamic Range (HDR) technology enhances video quality by balancing bright and dark areas, providing clearer images in challenging lighting environments.

6. MAINTENANCE

- Regularly clean the camera lens with a soft, damp cloth to ensure clear image quality. Do not use harsh chemicals.
- Periodically check the mounting hardware to ensure the camera remains securely fastened.
- Ensure the power cable is free from damage and properly secured.
- Keep the camera's firmware updated through the Alarm.com app to ensure optimal performance and access to new features.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera not powering on	No power, faulty adapter, loose connection.	Check power outlet, ensure connections are secure, try a different outlet.
Cannot connect to Wi-Fi	Incorrect Wi-Fi password, camera too far from router, network interference.	Verify Wi-Fi password, move camera closer to router, reduce interference, restart router.
Poor video quality	Dirty lens, low bandwidth, poor lighting.	Clean lens, check internet speed, ensure adequate lighting or rely on night vision.
No motion alerts	Incorrect Video Analytics settings, notifications disabled.	Review and adjust Video Analytics rules in the app, enable notifications for the camera.

8. SPECIFICATIONS

Feature	Detail
Model Number	ADC-V723x
Video Capture Resolution	1080p (1920x1080)
Connectivity	Wi-Fi
Power Source	Corded Electric
Indoor/Outdoor Usage	Outdoor
Viewing Angle	167 Degrees
Night Vision Range	40 Feet
Material	Metal
Dimensions (L x W x H)	2.5 x 2.5 x 4.5 inches
Item Weight	1.32 pounds
International Protection Rating	IP67
Special Feature	Motion Sensor, HDR


9. WARRANTY AND SUPPORT

For warranty information and technical support, please contact your Alarm.com service provider or visit the official Alarm.com website. Do not attempt to repair the device yourself, as this may void the warranty.

For additional resources and FAQs, please refer to the Alarm.com support portal.

© 2025 Alarm.com. All rights reserved.

Related Documents - ADC-V723x




[Alarm.com ADC-V723 1080p Outdoor Wi-Fi Camera Quick Start Guide](#)

Quick start guide for the Alarm.com ADC-V723 1080p Outdoor Wi-Fi Camera, detailing pre-installation requirements, setup via AP or WPS modes, LED indicator meanings, and troubleshooting tips.



[Alarm.com Stream Video Recorder \(ADC-SVR100\) FAQs](#)

Frequently asked questions about the Alarm.com Stream Video Recorder (ADC-SVR100), covering camera compatibility, network requirements, internet connectivity, video playback, storage, and hard drive configuration.




[Alarm.com ADC-V723/723X: SD Card Functionality and Onboard Recording Setup](#)

Learn how to use the SD card slot on Alarm.com ADC-V723 and ADC-V723X cameras for continuous onboard recording. This guide covers installation and setting up recording rules via the MobileTech app, Customer website, and Customer app.




[Alarm.com ADC-V523 1080p Indoor Wi-Fi HDR Video Camera - Specifications and Features](#)

Detailed specifications, features, and LED guide for the Alarm.com ADC-V523 1080p Indoor Wi-Fi Video Camera with High Dynamic Range (HDR). Learn about its capabilities, requirements, and included accessories.



[Alarm.com Outdoor Wi-Fi Camera ADC-V723 Installation Guide](#)


Installation guide for the Alarm.com Outdoor Wi-Fi Camera (ADC-V723), detailing setup procedures for WPS and AP modes, LED status indicators, troubleshooting steps, and regulatory compliance information from FCC and ISED.



[1080p Outdoor Wi-Fi Camera ADC-V723 Quick Start Guide](#)

This guide provides instructions for installing and connecting the Alarm.com 1080p Outdoor Wi-Fi Camera (ADC-V723) using either Access Point (AP) mode or Wi-Fi Protected Setup (WPS) mode. It includes a pre-installation checklist, an overview of the camera components, and troubleshooting tips.

Documents - Alarm.com – ADC-V723x




[\[pdf\] Declaration of Conformity](#)

Daidra Briel Alarm ADC V723X 1080p Outdoor Wi Fi Video Camera with HDR CE DoC RED V723x alarm about international doc |||

RED Declaration of Conformity DoC Alarm.com 8281 Greensboro Drive Tysons, VA 22102 USA Product Name : 1080p Outdoor Wi-Fi Video Camera with HDR Model : **ADC-V723X** This declaration is issued under the sole responsibility of the manufacturer. The object of the declaration described above is in c...

lang:en score:35 filesize: 152.47 K page_count: 1 document date: 2023-08-07



[\[pdf\] Quick Start Guide Installation Guide Guide Catalog](#)

V723 User Guide EN6 indd HEREProduct Help Outdoor Wi Fi Camera Comporium SecurityV723 Guide3cdn shopify s files 1 1795 4839 Guide3 v 1629817348 Alarm ADC V723X Installation GuideHEREAlarm 1080p Snap OneProduct onlineV723 Guide3snapav wcsstore ExtendedSitesCatalogAssetStore attachments documents Surveillance ManualsAndGuides onlinecdn |||

||| 1080p Outdoor Wi-Fi Camera Quick Start Guide ADC-V723 Pre-installation checklist ADC-V723 camera included . AC power adapter included . Wireless 2.4 or 5 GHz connection to broadband Cable, DSL, or Fiber Optic internet. A computer, tablet, o

1080p Outdoor Wi-Fi Camera Quick Start Guide ADC-V723 Pre-installation checklist ADC-V723 camera included . AC power adapter included . Wireless 2.4 or 5 GHz connection to broadband Cable, DSL, or Fiber Optic internet. A computer, tablet, or smartphone with Wi-Fi is required if the router ...

lang:en score:25 filesize: 512.09 K page_count: 7 document date: 2020-09-03

