

Corsair K63

Corsair K63 Mechanical Gaming Keyboard User Manual

Model: K63

INTRODUCTION

The Corsair K63 Mechanical Gaming Keyboard is designed for high-performance gaming, offering precision and responsiveness. It features 100% Cherry MX Red mechanical switches, programmable red LED backlighting, and a compact tenkeyless design for optimal desk space and portability. Dedicated multimedia and volume controls allow for on-the-fly adjustments without interrupting your gaming session. The keyboard also boasts 100% anti-ghosting with full key rollover over USB, ensuring every keystroke is registered accurately.

SETUP

Follow these steps to set up your Corsair K63 Mechanical Gaming Keyboard:

1. **Unpack the Keyboard:** Carefully remove the keyboard from its packaging.
2. **Connect to PC:** Plug the USB connector from the keyboard into an available USB 2.0 port on your computer.
3. **Driver Installation:** Your operating system should automatically detect and install the necessary drivers.
4. **Install Corsair iCUE Software:** For advanced customization, including lighting effects, macro programming, and performance settings, download and install the Corsair iCUE software from the official Corsair website.



Image: Angled view of the Corsair K63 Mechanical Gaming Keyboard, showcasing its compact design and red backlighting.




Image: Top-down view of the Corsair K63 Mechanical Gaming Keyboard, positioned on a desk mat alongside a Corsair gaming mouse and headset, illustrating a complete gaming setup.

OPERATING INSTRUCTIONS

The Corsair K63 keyboard offers various features for an enhanced gaming and typing experience:

- **Cherry MX Red Switches:** Experience fast, linear actuation with minimal resistance, ideal for rapid keystrokes in gaming.
- **Red LED Backlighting:** The keyboard features individual key backlighting. Use the dedicated brightness control key (usually located near the F-keys or multimedia keys) to adjust the intensity or turn off the lighting. Further customization is available via the iCUE software.

- **Dedicated Multimedia Controls:** Located on the top left of the keyboard, these buttons allow you to control media playback (Stop, Previous, Play/Pause, Next) without minimizing your game or application.
- **Volume Controls:** On the top right, dedicated buttons allow you to mute, decrease, or increase the volume quickly.
- **Windows Key Lock:** A dedicated button (often with a lock icon) allows you to disable the Windows key to prevent accidental presses during gameplay.
- **Anti-Ghosting and N-Key Rollover:** The keyboard supports 100% anti-ghosting with full N-Key Rollover, meaning all simultaneous key presses will be registered accurately.



Image: Close-up view of the dedicated multimedia control buttons on the top left of the keyboard, including Stop, Previous, Play/Pause, and Next track.



Image: Close-up view of the dedicated volume control buttons on the top right of the keyboard, including Mute, Volume Down, and Volume Up.




Image: Detailed close-up of the Cherry MX Red mechanical switches beneath the keycaps, highlighting the red stem and LED for backlighting.

Video: An official product video showcasing the Corsair K63 Mechanical Gaming Keyboard's features, including its compact design, Cherry MX switches, multimedia controls, iCUE software customization, and compatibility with the K63 Wireless Gaming Lapboard for living room gaming.

MAINTENANCE

To ensure the longevity and optimal performance of your Corsair K63 keyboard:

- **Regular Cleaning:** Use compressed air to remove dust and debris from between the keycaps.
- **Surface Cleaning:** Wipe the keyboard surface with a soft, damp cloth. Avoid harsh chemicals or abrasive materials.
- **Keycap Removal (Optional):** If necessary, keycaps can be carefully removed for deeper cleaning using a keycap puller (not included). Be gentle to avoid damaging the switches.
- **Cable Management:** Ensure the USB cable is not excessively bent or strained to prevent damage.

TROUBLESHOOTING

If you encounter issues with your Corsair K63 keyboard, try the following solutions:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely connected to both the keyboard and your computer.
 - Try plugging the keyboard into a different USB port.
 - Restart your computer.
- **Backlighting Not Working:**
 - Check the brightness control key on the keyboard to ensure the lighting is not turned off or set to minimum brightness.
 - Verify that the Corsair iCUE software is running and that no lighting profiles are conflicting or disabling the lighting.
 - Perform a soft reset of the keyboard (refer to Corsair support for specific instructions if needed).
- **Keys Not Registering or Double-Typing:**
 - Clean the affected key switch using compressed air.
 - Ensure the iCUE software is up to date.
 - Test the keyboard on another computer to rule out a system-specific issue.
- **iCUE Software Issues:**
 - Ensure you have the latest version of iCUE installed.
 - Try reinstalling the iCUE software.
 - Check Corsair's support website for known issues or updates.

SPECIFICATIONS

Feature	Detail
Brand	Corsair
Model Name	K63
Switch Type	Cherry MX Red Mechanical

Backlighting	Red LED, Per-Key Programmable
Layout	Italian QWERTY
Connectivity	USB 2.0
Anti-Ghosting	100% with Full Key Rollover
Dedicated Controls	Multimedia, Volume
Design	Compact, Tenkeyless
Product Dimensions	37L x 17l x 4H cm
Color	Black

WARRANTY AND SUPPORT

Your Corsair K63 Mechanical Gaming Keyboard comes with a manufacturer's warranty. For detailed information regarding warranty terms, duration, and conditions, please refer to the warranty card included with your product or visit the official Corsair website.

For technical support, driver downloads, firmware updates, and frequently asked questions, please visit the Corsair support page:

www.corsair.com/support

You can also find additional resources and community forums on the Corsair website.