



Manuals.plus /

› wellclima /

› LG Series 6711A200** Compatible Remote Control User Manual

wellclima 6711A200

wellclima Remote Control User Manual

Model: 6711A200 Series Compatible

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your wellclima replacement remote control for LG air conditioners. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

This remote control is designed to be a direct replacement for various LG air conditioner models in the 6711A200** series. It is compatible with many specific models such as 6711A20010A, 6711A20025N, 6711A20038A, and others listed in the product description. Please verify that the remote control and its buttons correspond to your original unit for full compatibility.

SETUP

1. Battery Installation

The remote control requires two 1.5V AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the cover back into place until it clicks securely.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage.

2. Initial Use (No Programming Required)

This wellclima remote control is pre-programmed and ready to use with compatible LG air conditioner models. No manual programming or code searching is required. Simply install the batteries, point the remote at your air conditioner, and begin operation.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions:





Image 1: Front view of the wellclima remote control. This image shows the main display area and the most frequently used buttons, including power, mode selection, fan speed, and temperature adjustment buttons. The display indicates a temperature of 25 degrees Celsius and various operational icons.





Image 2: Front view of the wellclima remote control with the lower sliding cover open. This reveals additional buttons for advanced functions such as ON/OFF timer settings, SET/CANCEL buttons, and a RESET button. These buttons are typically used for more specific control over the air conditioning unit's operation.

Button Functions:

- **Power Button (Red):** Turns the air conditioner ON or OFF.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment Buttons (Up/Down Arrows):** Increases or decreases the set temperature.
- **Fan Speed Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Button:** Controls the louver swing function.
- **Timer ON/OFF Buttons:** Sets the automatic ON/OFF time for the unit (located under the sliding cover).
- **SET/CANCEL Buttons:** Used for confirming or canceling timer settings and other advanced functions (located under the sliding cover).
- **RESET Button:** Resets the remote control to factory defaults (located under the sliding cover, may require a pointed object to press).

Note: The specific icons and button layout may vary slightly depending on the exact LG model your remote is replacing, but the core functions remain consistent.

MAINTENANCE

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, use a slightly damp cloth with a mild detergent, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or benzene, as these can damage the surface.

Battery Replacement

Replace batteries when the remote control's range decreases or the display becomes dim. Always replace both batteries at the same time with new ones of the same type (AAA 1.5V Alkaline).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead or incorrectly installed. Obstruction between remote and AC unit. Remote control is out of range. Infrared sensor on AC unit is blocked.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit (max range 10 meters). Clear any blockage from the AC unit's sensor.
Specific button not responding.	Button stuck or damaged. Remote control malfunction.	Gently press the button multiple times. Try resetting the remote (if applicable, using the RESET button). If problem persists, contact customer support.
Display is dim or blank.	Low battery power.	Replace batteries.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact wellclima customer support for assistance.

SPECIFICATIONS

- **Brand:** wellclima
- **Model:** 6711A200
- **Compatible Devices:** LG Air Conditioners (6711A200** series)
- **Connectivity Technology:** Infrared
- **Battery Type:** 2 x AAA 1.5V Alkaline (not included)
- **Dimensions:** Approximately 11.5 x 4.5 x 1.6 cm
- **Weight:** Approximately 45.4 g (without batteries)
- **Maximum Range:** 10 meters
- **Special Feature:** No programming required

WARRANTY AND SUPPORT

wellclima products are designed for reliability and performance. For information regarding warranty coverage, please refer to the product packaging or the official wellclima website. As a brand committed to quality, wellclima ensures that all products undergo rigorous testing.

For any questions, technical support, or assistance with your remote control, please contact wellclima customer service. You can find contact details on the official wellclima website or through your point of purchase. We are dedicated to providing prompt responses and dedicated assistance to ensure your satisfaction.

Note: This product is from a small or medium-sized enterprise registered with the Amazon Brand Registry or an artisan part of Amazon Handmade based in Italy. Your purchase supports small and medium-sized businesses.



