

[Manuals.plus](#) /

› [Superer](#) /

› Superer AC Charger Instruction Manual for Asus Transformer Tablets (Models TF101, TF201, TF700, SL101, A1, B1, TF101G, TF201-B1-GR, TF201-C1-GR, TF700T, TF700T-B1-GR, TF700T-B1-CG, Eee Pad Slider Prime)

Superer ZH00025

Superer AC Charger Instruction Manual

For Asus Transformer Tablets (Model ZH00025)

1. INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your Superer AC Charger, model ZH00025. This charger is specifically designed to provide power to a range of Asus Transformer tablets. Please read this manual thoroughly before use and retain it for future reference.

CHARGING PORT

Check the shape of your charging port before purchase




Image 1.1: Superer AC Charger with 40-pin cable.


2. COMPATIBILITY

The Superer AC Charger (Model ZH00025) is compatible with the following Asus Transformer tablet models:

- Asus Transformer TF101
- Asus Transformer TF201
- Asus Transformer TF700
- Asus SL101
- Asus A1
- Asus B1
- Asus TF101G

- Asus TF201-B1-GR
- Asus TF201-C1-GR
- Asus TF700T
- Asus TF700T-B1-GR
- Asus TF700T-B1-CG
- Asus TF700T-C1-GR
- Asus TF700T-C1-CG
- Eee Pad Slider Prime

This charger is designed for tablets requiring 15V and 1.2A (18W) power input. It is not compatible with devices requiring 5V and 2A (10W) or other specifications.



Compatibility

15V	1.2A	18W	✓
5V	2A	10W	✗

Image 2.1: Charger compatibility specifications.

3. SETUP INSTRUCTIONS

Follow these steps to properly set up your Superer AC Charger:

1. **Verify Charging Port:** Before connecting, ensure your tablet has the correct 40-pin charging port. This charger is not compatible with micro-USB or other port types.




Image 3.1: Correct 40-pin charging port for Asus Transformer tablets.

2. **Connect to Tablet:** Carefully insert the 40-pin connector of the charger cable into the charging port of your Asus Transformer tablet. Ensure a firm and secure connection.
3. **Connect to Power Outlet:** Plug the AC adapter into a standard wall power outlet. The tablet should indicate that it is charging.

Safety Protection




Image 3.2: Charger connected to a tablet and power source.

4. OPERATING INSTRUCTIONS

Once connected, the Superer AC Charger will provide a consistent and stable power supply to your Asus Transformer tablet, enabling efficient charging and operation. This charger supports fast charging for compatible devices.

Positive Customer Support

Refund Within 30 Days of Purchase
and Replace Service Within 12 Months



12

Replace Service Within 12 Months

Worry-free after sales



Replace Service
Within 12 Months



Refund Within
30 Days of Purchase



Quick feedback
to any problems

Image 4.1: Consistent power supply during tablet charging.

5. SAFETY AND PROTECTION FEATURES

Your Superer AC Charger is equipped with multiple safety features to protect your device and ensure reliable operation:

- **Overheating Protection:** Prevents the charger from reaching excessive temperatures.
- **Overvoltage Protection:** Safeguards against damage from voltage spikes.
- **Electrostatic Protection:** Protects against electrostatic discharge.

- **Short Circuit Protection:** Automatically shuts off power in case of a short circuit.
- **Overcurrent Protection:** Prevents damage from excessive current flow.
- **Overcharge Protection:** Protects your tablet battery from overcharging.

ITEM DIMENSION

Size:2.30"*1.67"*0.96"




Image 5.1: Built-in safety protection mechanisms.

6. MAINTENANCE

To ensure the longevity and optimal performance of your charger, follow these maintenance guidelines:

- Keep the charger and cable dry. Avoid exposure to liquids or high humidity.
- Do not expose the charger to extreme temperatures (hot or cold).
- Handle the cable and connector gently. Avoid bending or twisting the cable sharply.
- Clean the charger and cable with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the charger in a cool, dry place when not in use.

7. TROUBLESHOOTING

If you encounter issues with your Superer AC Charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Tablet not charging	Loose connection, faulty outlet, incompatible tablet model, damaged charger/cable.	Ensure all connections are secure. Try a different power outlet. Verify tablet model compatibility. Inspect charger and cable for visible damage.
Slow charging	Tablet in heavy use during charging, background apps, charger not fully compatible (though listed).	Close unnecessary applications on the tablet. Avoid heavy usage during charging. Ensure the charger is providing the correct output (15V, 1.2A).
Charger feels warm	Normal operation, poor ventilation, excessive load.	A slight warmth is normal. Ensure the charger is in a well-ventilated area. If it becomes excessively hot, disconnect immediately and contact support.

8. PRODUCT SPECIFICATIONS

- **Model Number:** ZH00025
- **Input:** AC 100-240V, 50/60Hz
- **Output:** 15V, 1.2A (18 Watts)
- **Connector Type:** 40 Pin Barrel Connector
- **Included Components:** AC Adapter, 40 Pin Cable
- **Item Weight:** Approximately 0.81 ounces (23 grams)
- **Adapter Dimensions (L x W x H):** Approximately 2.30 x 1.67 x 0.96 inches
- **Special Feature:** Fast Charging

Consistent Power Supply

Provide consistent & stable power for your tablet



Image 8.1: Charger adapter dimensions.

9. WARRANTY AND SUPPORT

Superer provides the following support for this product:

- **Refund Policy:** Refund available within 30 days of purchase.
- **Replacement Service:** Free replacement service available within 12 months of purchase.

For any inquiries or support needs, please refer to your purchase platform or contact Superer customer service

directly.

© 2024 Superer. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question