

Remington AC5912 (PHNRMGAC5912)

Remington AIR COMPACT AC5912 Hair Dryer User Manual

Model: AC5912

1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:
 - Always unplug this appliance immediately after using.
 - Do not use while bathing or in a shower.
 - Do not place or store appliance where it can fall or be pulled into a tub or sink.
 - Do not place in or drop into water or other liquid.
 - If an appliance falls into water, unplug it immediately. Do not reach into the water.

- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
 - This appliance should never be left unattended when plugged in.
 - Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities. Keep out of reach of children.
 - Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
 - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water.
 - Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
 - Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
 - Never use while sleeping.
 - Never drop or insert any object into any opening.
 - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
 - Do not direct hot air towards eyes or other heat-sensitive areas.
 - Attachments may be hot during use. Allow them to cool before handling.
 - Do not place appliance on any surface while it is operating.

- While using the appliance, keep your hair away from the air inlets.
- Avoid overheating the appliance.

2. PRODUCT OVERVIEW

The Remington AIR COMPACT AC5912 is a powerful 2200W hair dryer designed for efficient hair drying and styling. It features a compact design, ionic technology for frizz-free results, and multiple heat and speed settings.



Figure 1: Remington AIR COMPACT AC5912 Hair Dryer with concentrator.

Key Features:

- Powerful 2200 Watts for fast drying.
- Ionic technology for reduced frizz and enhanced shine.
- Lightweight and compact design for comfortable handling.
- Removable air filter for easy cleaning and maintenance.
- Low noise operation.
- Includes a concentrator attachment for precise styling.
- Multiple speed settings.

3. SETUP

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Attach Concentrator (Optional):** To attach the concentrator, align it with the front barrel of the hair dryer and push it firmly into place. Ensure it is securely attached before use.
4. **Plug In:** Insert the power cord into a suitable electrical outlet. Ensure your hands are dry before plugging in the appliance.

4. OPERATING INSTRUCTIONS

The Remington AIR COMPACT AC5912 Hair Dryer offers various settings to suit your styling needs.

1. **Power On/Off:** Locate the ON/OFF switch on the handle. Slide it to the 'ON' position to start the hair dryer and to the 'OFF' position to turn it off.
2. **Adjust Speed:** The hair dryer features 2 speed settings. Use the speed switch to select your desired airflow:
 - **Low Speed:** For gentle drying and styling.
 - **High Speed:** For fast drying.
3. **Adjust Heat:** The hair dryer typically includes multiple heat settings. Select the appropriate heat level for your hair type and desired style.
 - **Cool Shot:** Press and hold the cool shot button (if available) to deliver a burst of cool air. This helps to set your style and add shine.
4. **Styling with Concentrator:** For precise styling, attach the concentrator nozzle. Direct the airflow to specific sections of your hair while brushing.
5. **Ionic Function:** The integrated ionic technology helps to reduce static and frizz, leaving your hair smoother and shinier. This function operates automatically when the dryer is on.
6. **After Use:** Once finished, switch the hair dryer off and unplug it from the power outlet. Allow the appliance to cool down completely before storing.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your hair dryer.

1. **Cleaning the Air Filter:**
 - Ensure the appliance is switched off and unplugged from the power outlet.
 - Grip the rear air filter cover and twist or pull it off (depending on the design).
 - Remove any accumulated dust, lint, or hair from the filter using a soft brush or cloth.
 - Replace the air filter cover by aligning it and twisting or pushing it back into place until it clicks securely.
 - Clean the filter regularly, especially if you notice a decrease in airflow or the dryer becoming excessively hot.
2. **General Cleaning:** Wipe the exterior of the hair dryer with a damp cloth. Do not use abrasive cleaners or solvents.
3. **Storage:** Store the appliance in a cool, dry place. Do not wrap the cord tightly around the appliance, as this can cause damage over time.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Hair dryer does not turn on.	Not plugged in, power outlet issue, internal fault.	Ensure the plug is fully inserted. Test the outlet with another appliance. If still not working, contact customer support.
Low airflow or weak performance.	Blocked air filter, motor issue.	Clean the removable air filter as described in the Maintenance section.
Hair dryer overheats and shuts off.	Blocked air filter, prolonged use, internal safety cut-out activated.	Unplug the dryer and allow it to cool down for at least 10-15 minutes. Clean the air filter. Ensure air inlets/outlets are not blocked during use.
Unusual noise or smell.	Internal component issue.	Immediately unplug the appliance and discontinue use. Contact customer support.

7. SPECIFICATIONS

- **Brand:** Remington
- **Model Name:** AC5912
- **Item Model Number:** PHNRMGAC5912
- **ASIN:** B073LPQN7Y
- **Power:** 2200 Watts
- **Power Source:** Corded Electric
- **Color:** Black
- **Material:** Plastic
- **Number of Speeds:** 2
- **Special Features:** Low noise, Removable air filter, Lightweight, Ionic technology
- **Recommended Uses:** Hair drying, Hair styling
- **Included Components:** Concentrator
- **Package Dimensions:** 23 x 14.9 x 7.9 cm; 1 Kilogram
- **Manufacturer:** Remington

8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please refer to the warranty card included with your product or visit the official Remington website. Keep your proof of purchase for warranty claims. For further assistance, please contact Remington customer service.