

[Manuals.plus](#) /

› [Vanity Planet](#) /

› Vanity Planet Forever Young Face Massager - Hot & Cold Rejuvenating Facial Wand User Manual

Vanity Planet VP59272-0100

Vanity Planet Forever Young Face Massager - Hot & Cold Rejuvenating Facial Wand User Manual

Model: VP59272-0100

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Vanity Planet Forever Young Hot & Cold Rejuvenating Facial Wand. Please read this manual thoroughly before operating the device and retain it for future reference. The Forever Young wand is designed to enhance your skincare routine by utilizing temperature changes and sonic vibrations to optimize product absorption and improve skin appearance.

PRODUCT OVERVIEW

The Vanity Planet Forever Young Facial Wand combines hot, cold, and sonic vibration modes to address various skincare needs. Its ergonomic design ensures comfortable handling.



Figure 1: The Vanity Planet Forever Young Hot & Cold Rejuvenating Facial Wand. This image displays the device from the front, highlighting its sleek white design, metallic treatment head, and control buttons.

Key Features:

- **Hot Mode:** Helps open pores to boost absorption of serums, creams, and moisturizers.
- **Cool Mode:** Helps shrink pores, lessen the appearance of fine lines, soothe skin, and reduce redness and puffiness.
- **Sonic Vibration Mode:** Invigorates and rejuvenates skin with a gentle massage.
- **Teardrop-shaped Head:** Designed for precise application, especially around the under-eye areas.
- **Wireless and Portable:** Includes a USB charging cord and travel pouch for convenience.

Say hello to true beauty



3 changeable modes



Cool Mode

Shrinks pores, helps reduce red spots and puffiness, while soothing your skin



Hot mode

Opens your pores to boost absorption of serums, creams and moisturizers



Sonic Vibration Mode

Rejuvenates and invigorates the skin with a gentle sonic massage

Figure 2: Illustration of the three changeable modes: Cool Mode, Hot Mode, and Sonic Vibration Mode, detailing their respective benefits for skin care.

SETUP

Charging the Device:

1. Before first use, fully charge the device. Connect the provided USB charging cord to the charging port on the device and to a compatible USB power source.
2. The charging indicator light will illuminate during charging.
3. A full charge typically takes approximately 3 hours. Ensure the device is fully charged before initial operation to maximize battery life.



Figure 3: Close-up view of the charging port located at the base of the device, where the USB charging cord is connected.

Initial Preparation:

- Ensure your skin is clean and free of makeup before using the device.
- Apply your preferred serum, cream, or moisturizer to your face as desired before using the hot mode for enhanced absorption.

OPERATING INSTRUCTIONS

Power On/Off:

- To turn on the device, press and hold the power button for approximately 2 seconds.
- To turn off the device, press and hold the power button for approximately 2 seconds.
- The device is equipped with an automatic timer and will shut off after a few minutes of continuous use. This is a normal function to prevent overuse. You may restart the device if further treatment is desired.

Selecting Modes:

Once the device is powered on, short press the power button to cycle through the available modes:

1. **Hot Mode:** The red indicator light will illuminate. Use this mode to help open pores and enhance the absorption of skincare products.
2. **Cool Mode:** The blue indicator light will illuminate. Use this mode to help shrink pores, reduce puffiness, and soothe the skin.
3. **Sonic Vibration Mode:** The green indicator light will illuminate. This mode can be used independently or in conjunction with hot or cool modes for a gentle massage.

Application Guidance:

- Gently glide the treatment head across your face and neck in upward and outward motions.
- For the under-eye area, use the teardrop-shaped head with light, gentle movements.
- Avoid prolonged contact with one area of the skin. Keep the device moving.
- Follow the recommended duration for each mode as indicated by the device's automatic shut-off feature.

MAINTENANCE

Cleaning the Device:

1. Always ensure the device is turned off and has cooled down completely before cleaning.
2. Wipe the stainless-steel treatment head with a slightly damp, soft cloth.
3. Carefully clean around the edges of the treatment head to remove any residue from skincare products.
4. Do not immerse the device in water or use abrasive cleaners.
5. Allow the device to air dry completely before storing.

Storage:

- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- Use the provided travel pouch for protection when not in use or during travel.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or not charged.	Ensure the device is fully charged using the provided USB cord. Charge for at least 3 hours.

Problem	Possible Cause	Solution
Device turns off automatically during use.	Automatic timer activated.	This is a normal safety feature. If further treatment is desired, simply turn the device back on.
No heat/cold sensation.	Incorrect mode selected or device malfunction.	Ensure the correct mode (red for hot, blue for cold) is selected. If the issue persists after charging, contact customer support.

SPECIFICATIONS

- **Model Number:** VP59272-0100
- **Product Dimensions:** 2 x 6 x 1.5 inches (5.08 x 15.24 x 3.81 cm)
- **Weight:** 6.4 ounces (181.4 grams)
- **Battery:** 1 Lithium Polymer battery (included)
- **UPC:** 812485024835
- **Manufacturer:** Vanity Planet



Official Vanity Planet Forever Young Packaging



Figure 4: Image illustrating the dimensions of the Forever Young Facial Wand, showing its length of approximately 6.2 inches (15 cm).

SAFETY INFORMATION

- Do not use the device on broken, irritated, or infected skin.
- Consult a physician before use if you have any skin conditions, medical implants, or are pregnant.
- Keep out of reach of children.
- Do not use while charging.
- Avoid dropping the device or subjecting it to strong impacts.
- If the device appears damaged or malfunctions, discontinue use immediately and contact customer support.

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Vanity Planet customer service directly. Refer to the product packaging or the official Vanity Planet website for the most current contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question