

Stagg PBF23 BKP SBK

Stagg PBF23 BKP SBK Fixed Height Piano Bench User Manual

Model: PBF23 BKP SBK - Highgloss Black with Black Vinyl Top

1. PRODUCT OVERVIEW

The Stagg PBF23 BKP SBK is a fixed-height piano bench designed for comfort and durability. It features a highgloss black finish, a comfortable black vinyl top, and a convenient storage compartment for sheet music and accessories. Constructed with an oak wood structure, this bench provides stable support for musicians.

Key Features:

- Oak wood structure for durability.
- Fixed height of 18.9 inches (48 cm).
- Integrated storage compartment.
- Highgloss black finish.
- Black vinyl top for comfort.



Figure 1: Stagg PBF23 BKP SBK Fixed Height Piano Bench. This image displays the overall appearance of the highgloss black piano bench with its black vinyl top.

2. PACKAGE CONTENTS

Please check the package carefully to ensure all components are present and undamaged. If any items are missing or damaged, contact your retailer immediately.

- Piano Bench Top with Storage Compartment (1)
- Bench Legs (4)
- Assembly Hardware (screws, washers, wrench) (1 set)
- Instruction Manual (this document) (1)

3. SAFETY INFORMATION

Read all instructions before assembly and use. Keep this manual for future reference.

- **Weight Limit:** Do not exceed the maximum weight recommendation of 440 pounds (200 kg).
- **Stable Surface:** Always place the bench on a flat, stable, and level surface to prevent tipping.
- **Assembly:** Ensure all screws are securely tightened before use. Periodically check and re-tighten hardware.

- **Children:** Keep small parts and packaging materials away from children to prevent choking hazards.
- **Moving:** When moving the bench, lift it rather than dragging to prevent damage to the legs or floor.

4. SETUP AND ASSEMBLY

Assembly of the Stagg PBF23 BKP SBK piano bench is straightforward and typically requires only a few steps.

Tools Required:

- Included Allen wrench (or similar tool for screws)

Assembly Steps:

1. Carefully unpack all components and verify against the package contents list.
2. Place the bench top (with the storage compartment facing down) on a soft, clean surface to prevent scratches.
3. Attach each of the four legs to the designated corner brackets on the underside of the bench top. Align the screw holes.
4. Insert the provided screws and washers into the holes and tighten them securely using the included wrench. Do not overtighten, but ensure the legs are firm and do not wobble.
5. Once all legs are attached, carefully turn the bench upright.
6. Test the stability of the bench by gently applying pressure to all corners. If any wobbling occurs, re-check the tightness of the leg screws.



Figure 2: Stagg PBF23 BKP SBK Piano Bench Dimensions. This image illustrates the product dimensions: 21.3 inches (length), 12.6 inches (width), and 18.9 inches (height).

5. OPERATING INSTRUCTIONS

Using the Storage Compartment:

- To access the storage compartment, gently lift the hinged seat top.
- Place sheet music, accessories, or other small items inside.
- To close, carefully lower the seat top until it rests securely on the bench frame. Avoid slamming the lid.

Positioning the Bench:

- Place the bench directly in front of your piano or keyboard.
- Adjust your distance from the instrument to achieve a comfortable playing posture, ensuring your feet are flat on the floor and your arms are at a comfortable angle to the keys.

6. MAINTENANCE

Proper care will extend the life and appearance of your piano bench.

Cleaning:

- For the highgloss black finish, wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- For the black vinyl top, wipe with a damp cloth and mild soap if necessary. Dry thoroughly.
- Do not use excessive water, as it can damage the wood structure.

General Care:

- Periodically check all screws and bolts to ensure they remain tight. Re-tighten as needed.
- Avoid exposing the bench to extreme temperatures or humidity, which can cause wood to warp or crack.
- Protect the bench from direct sunlight to prevent fading or damage to the finish and vinyl.

7. TROUBLESHOOTING

If you encounter any issues with your piano bench, refer to the following common problems and solutions.

Bench is Wobbly:

- **Solution:** Ensure all leg attachment screws are securely tightened. Check that the bench is placed on a flat, even surface. If the floor is uneven, consider using small felt pads under the shorter legs to stabilize.

Storage Compartment Lid Does Not Close Properly:

- **Solution:** Check for any items obstructing the closing mechanism or the compartment itself. Ensure the hinges are not bent or damaged.

Scratches or Dents on Finish:

- **Solution:** For minor scratches, specialized furniture repair kits or touch-up pens designed for highgloss black finishes may be used. For significant damage, professional repair might be necessary.

8. SPECIFICATIONS

Feature	Detail
Model Number	PBF23 BKP SBK
Dimensions (L x W x H)	21.3" x 12.6" x 18.9" (54.1 cm x 32 cm x 48 cm)
Seat Height	18.9" (48 cm)
Weight	15.4 lbs (7 kg)
Maximum Weight Recommendation	440 lbs (200 kg)
Material	Oak Wood, Vinyl
Finish	Highgloss Black
Seat Material	Black Vinyl

Storage	Integrated Compartment
---------	------------------------

9. WARRANTY AND SUPPORT

Stagg products are manufactured to high-quality standards. For specific warranty details and terms, please refer to the warranty information provided at the time of purchase or contact your retailer.

Customer Support:

If you have questions, require assistance, or need to report a defect, please contact your authorized Stagg dealer or the point of purchase. Please have your model number (PBF23 BKP SBK) and purchase date available when contacting support.