

[Manuals.plus](#) /

› [mabe](#) /

› Mabe EM7620BAIS1 Floor Stove User Manual

mabe EM7620BAIS1

Mabe EM7620BAIS1 Floor Stove User Manual

Model: EM7620BAIS1

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, maintenance, and troubleshooting of your Mabe EM7620BAIS1 Floor Stove. Please read these instructions carefully before using the appliance and keep them for future reference.



Image: Front view of the Mabe EM7620BAIS1 Floor Stove, showcasing its silver finish and six burners.

SETUP AND INSTALLATION

Proper installation is crucial for the safe operation of your stove. It is highly recommended that installation be performed by a qualified professional, especially for gas connections.

Placement

Ensure the stove is placed on a level, stable surface. Maintain adequate clearance from combustible materials. Refer to the dimensions provided for proper space planning.




Image: Side view of the Mabe EM7620BAIS1 Floor Stove with key dimensions labeled: 96.52 cm height, 71.12 cm depth, and 76.2 cm width.

Gas Connection

This appliance is designed for use with Liquefied Petroleum Gas (LPG). Ensure the gas supply line is correctly installed and free of leaks. All gas connections must comply with local codes and regulations.

Electrical Connection

The stove operates on 120 Volts. Ensure the electrical outlet meets the appliance's requirements and is properly

grounded.

OPERATING INSTRUCTIONS

Your Mabe EM7620BAIS1 Floor Stove is equipped with six burners and an oven with a panoramic door and Termocontrol for precise temperature management.

Burner Operation

1. Ensure the burner grates are properly seated.
2. Push and turn the desired burner knob counter-clockwise to the 'HIGH' position.
3. Ignite the burner using an external igniter or match. Hold the knob in for a few seconds after ignition to allow the flame sensor to activate.
4. Adjust the flame size by turning the knob between 'HIGH' and 'LOW' settings.



Image: Close-up view of the stove's six gas burners with their sturdy wire grates.

Oven Operation (Termocontrol)

The oven features Termocontrol, allowing you to select from 5 temperature ranges for various cooking needs.

1. Open the panoramic oven door to place food inside.
2. Turn the oven control knob to the desired temperature setting. The available ranges are typically indicated on the knob (e.g., 140°, 170°, 190°, 220°, 260° Celsius).
3. Allow the oven to preheat to the selected temperature before placing food inside.
4. Monitor cooking progress through the panoramic door without opening it, which helps maintain consistent oven temperature.



Image: Detailed view of the Mabe stove's control panel, showing the burner knobs and the oven temperature control knob with its various settings.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your stove.

General Cleaning

- Always ensure the stove is cool before cleaning.
- Use mild soap and water with a soft cloth for exterior surfaces. Avoid abrasive cleaners that can scratch the finish.
- For stubborn stains, use a non-abrasive kitchen cleaner specifically designed for stove surfaces.

Burner Grates and Caps

The wire grates are designed for durability. Remove them along with the burner caps for cleaning. Wash them with warm, soapy water and dry thoroughly before replacing.



Image: Top-down view of the Mabe stove, highlighting the six burners and their robust wire grates, designed for easy cleaning and durability.

Oven Interior

Clean the oven interior regularly to prevent grease buildup. For best results, clean spills as soon as the oven cools. Refer to the specific cleaning instructions for your oven type.

TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and solutions:

- **Burner not lighting:** Check if the gas supply is on. Ensure burner caps are correctly seated. Clean any food debris from the burner ports.
- **Uneven flame:** Clean burner ports to remove any blockages. Ensure the burner cap is correctly aligned.
- **Oven not heating:** Verify the oven control knob is set to a temperature. Ensure the gas supply to the oven is active.
- **Excessive smoke from oven:** This may indicate food spills or grease buildup. Clean the oven interior thoroughly.

If problems persist after attempting these solutions, please contact customer support.

PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	EM7620BAIS1
Brand	Mabe
Material	Alloy Steel
Dimensions (D x W x H)	28prof. x 30an. x 38alt. centimeters (approx. 71.12 x 76.2 x 96.52 cm)
Item Weight	36.5 Kilograms
Voltage	120 Volts
Fuel Type	Liquefied Petroleum Gas (LPG)
Heating Element Type	Gas
Form Factor	Freestanding
Installation Method	Freestanding
Drawer Type	Storage
UPC	757638829960, 757638396790

WARRANTY INFORMATION

The Mabe EM7620BAIS1 Floor Stove comes with a **1-year product warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or contact customer support.

CUSTOMER SUPPORT

For technical assistance, service, or any inquiries regarding your Mabe EM7620BAIS1 Floor Stove, please contact Mabe

customer service:

- **Telephone:** 461 471 7000
- **WhatsApp:** 55 41635939

Our support team is available to help you with installation, repairs, and maintenance services.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question